



FS-3540MFP

FS-3640MFP

SERVICE

MANUAL

Published in April 2011
2MDSM061
Rev.1

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	6 April 2011	CONTENTS, 1-1-2, 1-1-3, 1-2-2, 1-2-4, 1-3-2, 1-3-7, 1-3-8, 1-3-21, 1-3-22, 1-3-31, 1-3-58 to 1-3-62, 1-4-8, 1-4-10 to 1-4-12, 1-4-27 to 1-4-29, 1-5-18 to 1-5-25, 1-5-44, 2-3-9, 2-3-13 to 2-3-15, 2-4-3, 2-4-7, INSTALLATION GUIDE	


This page is intentionally left blank.


Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions


Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle () symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

 indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

 indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current.
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities.













CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury.
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock.
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire.
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance.
- Always handle the machine by the correct locations when moving it.
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury.
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention.
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook.


















2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 



CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
 - Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
 - Ventilate the room well while using grease or solvents.
 - Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
 - Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 
- Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. 

This page is intentionally left blank.

CONTENTS

1-1 Specifications

1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-5
(1) Overall	1-1-5
(2) Operation panel	1-1-6
1-1-3 Machine cross section	1-1-7

1-2 Installation

1-2-1 Installation environment.....	1-2-1
1-2-2 Unpacking.....	1-2-2
(1) Unpacking.....	1-2-2
(2) Removing the tapes.....	1-2-3
1-2-3 Installing the expansion memory (option).....	1-2-7
1-2-4 Installing the memory card (option).....	1-2-8

1-3 Maintenance Mode

1-3-1 Maintenance mode	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance modes item list	1-3-2
(3) Contents of the maintenance mode items	1-3-5
1-3-2 Service mode.....	1-3-56
(1) Executing a service mode	1-3-56
(2) Description of service mode	1-3-57

1-4 Troubleshooting

1-4-1 Paper misfeed detection.....	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection condition	1-4-1
1-4-2 Self-diagnostic function	1-4-4
(1) Self-diagnostic function	1-4-4
(2) Self diagnostic codes.....	1-4-5
1-4-3 Image formation problems	1-4-13
(1) Completely blank printout.....	1-4-14
(2) All-black printout.....	1-4-15
(3) Dropouts.....	1-4-16
(4) Black dots.....	1-4-16
(5) Black horizontal streaks.....	1-4-16
(6) Black vertical streaks.....	1-4-17
(7) Unsharpness.....	1-4-17
(8) Gray background.....	1-4-17
(9) Dirt on the top edge or back of the paper.....	1-4-18
(10) Undulated printing at the right edge (scanning start position).....	1-4-18
1-4-4 Electric problems	1-4-19
1-4-5 Mechanical problems.....	1-4-25
1-4-6 Send error code.....	1-4-27
(1) Scan to SMB error codes	1-4-27
(2) Scan to FTP error codes	1-4-28
(3) Scan to E-mail error codes	1-4-29

1-4-7 Error codes	1-4-30
(1) Error code	1-4-30
(2) Table of general classification	1-4-31
(2-1) U004XX error code table: Interrupted phase B	1-4-33
(2-2) U006XX error code table: Problems with the unit	1-4-33
(2-3) U008XX error code table: Page transmission error.....	1-4-33
(2-4) U009XX error code table: Page reception error	1-4-33
(2-5) U010XX error code table: G3 transmission.....	1-4-34
(2-6) U011XX error code table: G3 reception	1-4-35
(2-7) U017XX error code table: V.34 transmission	1-4-36
(2-8) U018XX error code table: V.34 reception.....	1-4-36
(2-9) U044XX error code table: Encrypted transmission	1-4-36
 1-5 Assembly and disassembly	
1-5-1 Precautions for assembly and disassembly.....	1-5-1
(1) Precautions.....	1-5-1
(2) Drum.....	1-5-1
(3) Toner	1-5-1
(4) How to tell a genuine Kyocera Mita toner container	1-5-2
1-5-2 Outer covers	1-5-3
(1) Detaching and refitting the right cover and left cover	1-5-3
1-5-3 Paper feed section.....	1-5-6
(1) Detaching and refitting the paper feed assembly (paper feed roller and pickup roller)	1-5-6
(2) Detaching and refitting the retard roller assembly	1-5-7
(3) Detaching and refitting the upper registration and lower roller	1-5-8
(4) Detaching and refitting the MP paper feed roller	1-5-10
1-5-4 Optical section	1-5-11
(1) Detaching and refitting the Document processor	1-5-11
(2) Detaching and refitting the scanner unit	1-5-13
(3) Detaching and refitting the laser scanner unit	1-5-16
(4) Replacing the image scanner unit (ISU).....	1-5-19
1-5-5 Developing section	1-5-26
(1) Detaching and refitting the developing unit	1-5-26
1-5-6 Drum section	1-5-27
(1) Detaching and refitting the drum unit.....	1-5-27
(2) Detaching and refitting the main charger unit.....	1-5-27
1-5-7 Transfer/separation section	1-5-28
(1) Detaching and refitting the transfer roller and separation brush unit.....	1-5-28
1-5-8 Fuser section	1-5-30
(1) Detaching and refitting the fuser unit.....	1-5-30
1-5-9 PWBs.....	1-5-31
(1) Detaching and refitting the engine PWB.....	1-5-31
(2) Detaching and refitting the main PWB.....	1-5-35
(3) Detaching and refitting the power source PWB.....	1-5-38
(4) Detaching and refitting the FAX control PWB.....	1-5-43
1-5-10 Others	1-5-44
(1) Detaching and refitting the paper feed drive unit.....	1-5-44
(2) Detaching and refitting the main drive unit	1-5-46
(3) Direction of installing the principal fan motors	1-5-47

1-5-11 Document processor	1-5-48
(1) Detaching and refitting the DP rear cover and DP front cover	1-5-48
(2) Detaching and refitting the DP drive PWB.....	1-5-49
(3) Detaching and refitting the DP forwarding pulley assembly and DP separation pad assembly.1-5-50	

1-6 Requirements on PWB Replacement

1-6-1 Upgrading the firmware	1-6-1
1-6-2 Remarks on engine PWB replacement	1-6-2

2-1 Mechanical Construction

2-1-1 Paper feed/conveying section	2-1-1
(1) Cassette paper feed section	2-1-1
(2) MP tray paper feed section.....	2-1-3
(3) Paper conveying section	2-1-4
2-1-2 Drum section	2-1-5
2-1-3 Optical section	2-1-6
(1) Scanner unit	2-1-6
(2) Image scanner unit (ISU).....	2-1-7
(3) Laser scanner unit	2-1-9
2-1-4 Developing section	2-1-11
2-1-5 Transfer/Separation section	2-1-13
2-1-6 Cleaning section	2-1-14
2-1-7 Fuser section	2-1-16
2-1-8 Eject/Rear unit section.....	2-1-18
2-1-9 Duplex conveying section.....	2-1-20
2-1-10 Document processor	2-1-21
(1) Original feed section.....	2-1-21
(2) Original conveying section.....	2-1-22
(3) Original switchback/eject sections.....	2-1-23

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout	2-2-1
(1) PWBs.....	2-2-1
(2) Switches and sensors.....	2-2-3
(3) Motors.....	2-2-5
(4) Other electrical components.....	2-2-6
(5) Document processor	2-2-7

2-3 Operation of the PWBs

2-3-1 Power source PWB	2-3-1
2-3-2 Engine PWB	2-3-3
2-3-3 Main PWB.....	2-3-8
2-3-4 Connect-L PWB.....	2-3-16
2-3-5 Connect-R PWB	2-3-20
2-3-6 DP drive PWB.....	2-3-23

2-4 Appendixes

2-4-1 Appendixes 2-4-1

 (1) Wiring diagram 2-4-1

 (2) Repetitive defects gauge 2-4-4

 (3) Maintenance kits..... 2-4-5

 (4) Firmware Environment Commands 2-4-6

 (5) Maintenance Commands..... 2-4-12

INSTALLATION GUIDE

Card Authentication Kit (C)

1-1-1 Specifications

Basic functions

Item		Specifications	
		3 in 1 model (without FAX)	4 in 1 model (with FAX)
Type		Desktop	
Printing method		Electrophotography by semiconductor laser, single drum system	
Originals		Sheet, Book, 3-dimensional objects (maximum original size: Folio/Legal)	
Original feed system		Contact glass: fixed	
Paper weight	Cassette	60 to 120 g/m ² (Duplex: 60 to 120 g/m ²)	
	MP tray	60 to 220 g/m ²	
Paper type	Cassette	Plain, Recycled, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, High Quality, Custom 1 to 8 (Duplex: Same as simplex)	
	MP tray	Plain, Transparency, Rough, Vellum, Labels, Recycled, Preprinted, Bond, Cardstock, Color (Colour), Prepunched, Letterhead, Thick, Envelope, High Quality, Custom 1 to 8	
Paper size	Cassette	A4, B5, A5, A6, Legal, Letter, Statement, Executive, Oficio II, Folio, 16K, Custom	
	MP tray	A4, B5, B5(ISO), A5, A6, B6, Envelope #10, Envelope #9, Envelope #6, Envelope Monarch, Envelope DL, Envelope C5, Hagaki, Oufuku Hagaki, Youkei 2, Youkei 4, Legal, Letter, Statement, Executive, Oficio II, Folio, 16K, Custom	
Zoom level		Manual mode: 25 - 400%, 1% increments Auto mode: 400%, 200%, 141%, 129%, 115%, 90%, 86%, 78%, 70%, 64%, 50%, 25%	
Copying speed	Simplex	A4R : 40 ppm LetterR : 42 ppm Legal : 33 ppm B5R : 33 ppm A5R/A6R : 22 ppm	
	Duplex	A4R : 24.5 ppm LetterR : 26 ppm Legal : 16.5 ppm B5R : 24 ppm A5R : 21 ppm	
First copy time (A4, feed from cassette)		7.0 second or less	
Warm-up time (22°C/71.6°F, 60%RH)		Power on: 22 second or less	
Paper capacity	Cassette	500 sheets (80g/m ²)	
	MP tray	100 sheets (80 g/m ² , plain paper, Letter/A4 or smaller)	
Output tray capacity		500 sheets (80g/m ²)	
Continuous printing		1 to 999 sheets	
Scanning system		Flat bed scanning by CCD image sensor	

Item		Specifications	
		3 in 1 model (without FAX)	4 in 1 model (with FAX)
Photoconductor		a-Si drum (diameter 30 mm)	
Image write system		Semiconductor laser (1 beam)	
Charging system		Contact charger roller method (positive charging)	
Developing system		Mono component dry developing method Toner replenishing: Automatic from the toner container	
Transfer system		Transfer roller (negative-charged)	
Separation system		Small diameter separation, discharger brush (negative-charged)	
Cleaning system		Counter blade cleaning + cleaning roller	
Charge erasing system		Exposure by eraser lamp (LED)	
Fusing system		Heat roller system Heat source: halogen heater Abnormally high temperature protection devices: thermostat	
CPU		PowerPC464 (800MHz)	
Memory	Standard	1024MB	
	Maximum	2048MB	
Interface		USB: 1 port (Hi-speed USB 2.0) USB host: 2 port Ethernet: 1 port (10BASE-T/100BASE-TX/1000BASE-TX)	
Resolution		600×600 dpi	
Operating environment	Temperature	10 to 32.5 °C/50 to 90.5 °F	
	Humidity	15 to 80%	
	Altitude	2,500 m/8,202 ft maximum	
	Brightness	1,500 lux maximum	
Dimensions (W × D × H)		494 × 497.1 × 566.5 mm 19 7/16" × 19 9/16" × 22 5/16"	
Weight		Approx. 26.38 kg / 58.16 lbs	Approx. 26.68 kg / 58.82 lbs
Space Space required (W × D)		Without MP tray: 494 × 497.1 mm 19 7/16" × 19 9/16" With MP tray : 494 × 656.1 mm 19 7/16" × 25 13/16"	
Power source		120 V AC, 60 Hz, more than 10.0 A 220 - 240 V AC, 50/60 Hz, more than 6.0A	
Options		Paper feeder × 3, Expanded memory	

Document processor functions

Item	Specifications
Original feed method	Automatic feed
Supported original types	Sheet originals
Original sizes	Maximum: Legal/A4 Minimum: Statement/A5
Original weights	Simplex: 50 to 120 g/m ² Duplex: 50 to 110 g/m ²
Loading capacity	50 sheets (50 to 80 g/m ²) maximum
Dimensions (W × D × H)	490 × 339 × 104 mm 19 5/16" × 13 5/16" × 4 1/8"
Weight	3 kg or less / 6.6 lbs. or less

Printing functions

Item	Specifications
Printing speed	Same as copying speed.
First print time (A4, feed from cassette)	9.5 seconds or less
Resolution	Fast 1200, 600 dpi
Operating system	Windows 2000, Windows XP, Windows XP Professional, Windows Server 2003, Windows Server 2003 x64 Edition, Windows Vista x86 Edition, Windows Vista x64 Edition, Windows 2008 Server, Windows Server 2008 x64 Edition, Windows 7, Apple Macintosh OS 10.x
Interface	USB: 1 port (Hi-speed USB 2.0) USB host: 1 port Ethernet: 1 port (10BASE-T/100BASE-TX/1000BASE-TX)
Page description language	PRESCRIBE

Scanning functions

Item	Specifications
Compatible operation system	Windows 2000 (Service Pack 4), Windows XP, Windows Vista, Windows Server 2003, Windows Server 2008, Windows 7
System requirements	IBM PC/AT compatible CPU: Celeron 600MHz or higher RAM: 128MB or more HDD free space: 20MB or more Interface: USB
Resolution	600 dpi, 400 dpi, 300 dpi, 200 dpi, 200×400 dpi, 200×100 dpi
File format	JPEG, TIFF, PDF, XPS

Item	Specifications
Scanning speed	1-sided: B/W 35 images/min Color 13 images/min (A4 landscape, 600 dpi, Image quality: Text/Photo original)
Interface	Ethernet (10 BASE-T/100 BASE-TX/1000BASE-TX) USB2.0 (Hi-Speed USB)
Network protocol	TCP/IP
Transmission system	PC transmission SMB Scan to SMB FTP Scan to FTP, FTP over SSL E-mail transmission SNMP Scan to E-mail TWAIN scan WIA scan

Fax functions : 4in1 model (with FAX) only

Item	Specifications
Compatibility	Super G3
Communication line	Subscriber telephone line
Transmission time	3 seconds or less (33600 bps, JBIG, ITU-T A4 #1 chart)
Transmission speed	33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/9600/ 7200/4800/2400 bps
Coding scheme	JBIG/MMR/MR/MH
Error correction	ECM
Original size	Max. width: 8 1/2"/215 mm Max. length: 14"/355.6 mm
Automatic document feed	Max. 50 sheets
Scanner resolution	Horizontal × Vertical 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super fine (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra fine (16 dot/mm × 15.4 line/mm)
Printing resolution	600×600 dpi
Gradations	256 shades (Error diffusion)
One-Touch key	100 keys
Multi-Station transmission	Max. 100 destinations
Substitute memory reception	256 sheets or more (when using ITU-T A4 #1)
Image memory capacity	3.5 MB (standard) (for incoming faxed originals)
Report output	Sent result report, FAX RX result report, Activity report, Status page

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names

(1) Overall




Figure 1-1-1

- 1. Platen (contact glass)
- 2. Original size Indicator plate
- 3. Operation panel
- 4. Front upper cover
- 5. Front cover
- 6. USB Interface connector (front)
- 7. Drum unit
- 8. Lock lever
- 9. Toner container
- 10. Inner tray
- 11. Paper length guide

- 12. Paper width guides
- 13. Cassette
- 14. Paper width guides (MP tray)
- 15. MP (Multi-Purpose) tray
- 16. MP tray extension
- 17. Rear unit
- 18. Main power switch
- 19. Power cord connector
- 20. USB Interface connector (rear)
- 21. Network Interface connector
- 22. Line connector (L1) *

- 23. Tel connector (T1) *
- 24. DP top cover
- 25. Original width guides
- 26. Original table
- 27. Original eject table
- 28. Opening handle

* 4in1 model (with FAX) only

(2) Operation panel




Figure 1-1-2

- | | | |
|------------------------------|--------------------------|--------------------------|
| 1. System menu/Counter key | 10. Black and White key | 19. Enter key |
| 2. Status/Job cancel key | 11. Message display | 20. Processing indicator |
| 3. Favorites/application key | 12. Numeric keys | 21. Memory indicator |
| 4. Document box key | 13. Logout key | 22. Attention indicator |
| 5. Copy key | 14. Reset key | 23. Start key |
| 6. Send key | 15. Power key | 24. Stop key |
| 7. FAX key* | 16. Main power LED | 25. IC Card reader box |
| 8. Auto color key | 17. Clear key | |
| 9. Full color key | 18. Quick No. Search key | |

*: 4 in 1 model (with FAX) only

1-1-3 Machine cross section




Figure 1-1-3

- | | |
|---------------------------------|--------------------------------|
| 1. Cassette | 9. Transfer/separation section |
| 2. MP tray | 10. Fuser unit |
| 3. Paper feed/conveying section | 11. Rear unit |
| 4. Toner container | 12. Eject section |
| 5. Developing unit | 13. Duplex/conveying section |
| 6. Main charger unit | 14. Scanner unit |
| 7. Drum unit | |
| 8. Laser scanner unit (LSU) | |




Figure 1-1-4

- 15. Image scanner unit (ISU)
- 16. Document processor (DP)

1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80%RH
3. Power supply: 120 V AC, 10.0 A
220 - 240 V AC, 6.0A
4. Power source frequency: 50 Hz $\pm 2\%$ /60 Hz $\pm 2\%$
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NO_x, SO_x gases and chlorine-based organic solvents.

Select a well-ventilated location.

6. Allow sufficient access for proper operation and maintenance of the machine.




Figure 1-2-1

1-2-2 Unpacking

(1) Unpacking




Figure 1-2-2

- | | | |
|-------------------|-----------------------------|---------------------------|
| 1. Machine | 10. Accessory spacer | 19. Cassette cover |
| 2. Outer case | 11. Hinge joints | 20. Plastic bag (250×600) |
| 3. Bottom case | 12. Plastic bag (250×600) | 21. Operation labels |
| 4. Bottom pad L | 13. Toner container | 22. Operation label pad |
| 5. Bottom pad R | 14. Waste toner box | 23. Modular cable * |
| 6. Machine spacer | 15. Power cord | 24. Ferrite core |
| 7. Machine cover | 16. Plastic bag (240×350) | 25. Plastic bag |
| 8. Top pad L | 17. Installation guide etc. | 26. Machine spacer B |
| 9. Top pad R | 18. CD-ROM * | |

* 120V/240V AC model only.

(2) Removing the tapes

<Procedure>

1. Remove the tape.




Figure 1-2-3

2. Open the DP.
3. Remove the plastic bag by pulling upwards.
4. Remove two tapes.
5. Remove the sheet and paper.




Figure 1-2-4

6. Remove the tape A.
7. Move the lock lever to the position of release.
 * : When turning on power if the lock lever is not released, the error message is displayed.
8. Close the DP.
9. Remove ten tapes B.
10. Open the left side cover and then remove the tape C and spacer.
11. Close the left side cover.






Figure 1-2-5

12. Remove the tape.




Figure 1-2-6

13. Remove the protection film.






Figure 1-2-7

14. Open the front cover.
15. Remove the tape and pad.

**Figure 1-2-8**

16. Remove the tape.
17. Close the front cover.

**Figure 1-2-9**

1-2-3 Installing the expansion memory (option)

<Procedure>

1. Turn off the main power switch.
Caution: Do not insert or remove expansion memory while machine power is on.
Doing so may cause damage to the machine and the expansion memory.
2. Remove the right side cover.




Figure 1-2-10

3. Remove the screw.
4. Open the memory slot cover and then remove the connector of the controller fan motor.
5. Remove the memory slot cover.
6. Insert the expansion memory into the memory socket so that the notches on the memory align with the corresponding protrusions in the slot.
7. Connect the connector of the controller fan motor and then close the memory slot cover.
8. Secure the screw.
9. Refit the right side cover.
10. Print a status page to check the memory expansion.
If memory expansion has been properly performed, information on the installed memory is printed with the total memory capacity has been increased. Standard memory capacity 256 MB.





Figure 1-2-11

1-2-4 Installing the memory card (option)

<Procedure>


1. Turn off the main power switch.
Caution: Do not insert or remove memory card while machine power is on.
Doing so may cause damage to the machine and the memory card.
2. Remove two screws and then remove the option interface slot cover.
3. Install the memory card into the option interface slot.
4. Refit the option interface slot cover by two screws.



1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting
General	U000	Outputting an own-status report	-
	U002	Setting the factory default data	-
	U004	Setting the machine number	-
Operation panel and support equipment	U201	Initializing the touch panel	-
	U203	Checking DP operation	-
	U222	Setting the IC card type	Other
	U224	Panel sheet extension	-
Mode setting	U250	Setting the maintenance cycle	100000
	U251	Checking/clearing the maintenance count	-
	U252	Setting the destination	-
	U253	Switching between double and single counts	Double count
	U260	Selecting the timing for copy counting	EJECT
	U285	Setting service status page	ON
	U332	Setting the size conversion factor	1.0
	U345	Setting the value for maintenance due indication	0
Image processing	U411	Adjusting the scanner automatically	-
	U425	Setting the target	-
Fax	U600	Initializing all data	-
	U601	Initializing permanent data	-
	U603	Setting user data 1	DTMF
	U604	Setting user data 2	2 (120 V) 1 (220-240 V)
	U605	Clearing data	-
	U610	Setting system 1	
		Setting the number of lines to be ignored when receiving a fax at 100% magnification	3
		Setting the number of lines to be ignored when receiving a fax in the auto reduction mode	0
	U611	Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode	0
		Setting system 2	
		Setting the number of adjustment lines for automatic reduction	7
		Setting the number of adjustment lines for automatic reduction when A4 paper is set	22
		Setting the number of adjustment lines for automatic reduction when letter size paper is set	26

Section	Item No.	Content of maintenance item	Initial setting
Fax	U612	Setting system 3 Selecting if auto reduction in the auxiliary direction is to be performed Setting the automatic printing of the protocol list	ON OFF
	U620	Setting the remote switching mode	ONE
	U625	Setting the transmission system 1 Setting the auto redialing interval Setting the auto redialing interval	3 (120 V) 2 (220-240 V) 2 (120 V) 3 (220-240 V)
	U630	Setting communication control 1 Setting the communication starting speed Setting the reception speed Setting the waiting period to prevent echo problems at the sender Setting the waiting period to prevent echo problems at the receiver	14400bps/V17 14400bps 300 75
	U631	Setting communication control 2 Setting ECM transmission Setting ECM reception Setting the frequency of the CED signal	ON ON 2100
	U632	Setting communication control 3 Setting the DIS signal to 4 bytes Setting the short protocol transmission Setting the reception of a short protocol transmission Setting the CNG detection times in the fax/telephone auto select mode	OFF ON ON 2TIME
	U633	Setting communication control 4 Enabling/disabling V.34 communication Setting the V.34 symbol speed (3429 Hz) Setting the number of times of DIS signal reception Setting the reference for RTN signal output	ON ON ONCE 15%
	U634	Setting communication control 5	0
	U640	Setting communication time 1 Setting the one-shot detection time for remote switching Setting the continuous detection time for remote switching	7 80
	U641	Setting communication time 2 Setting the T0 time-out time Setting the T1 time-out time Setting the T2 time-out time Setting the Ta time-out time Setting the Tb1 time-out time Setting the Tb2 time-out time Setting the Tc time-out time Setting the Td time-out time	56 36 69 30 20 80 60 9 (120 V) 6 (220-240 V)

Section	Item No.	Content of maintenance item	Initial setting
Fax	U650	Setting modem 1 Setting the G3 transmission cable equalizer Setting the G3 reception cable equalizer Setting the modem detection level	0dB 0dB 43dBm
	U651	Setting modem 2 Modem output level DTMF output level (main value) DTMF output level (level difference)	9 (120 V) 10 (220-240 V) 5 (120 V) 10.5 (220-240 V) 2 (120 V) 2.5 (220-240 V)
	U660	Setting the NCU Setting the connection to PBX/PSTN Setting PSTN dial tone detection Setting busy tone detection Setting for a PBX Setting the loop current detection before dialing	PSTN ON ON LOOP ON
	U670	Outputting lists	-
	U695	FAX function customize	ON/OFF
	U699	Setting the software switches	-
Others	U910	Clearing the black ratio data	-
	U917	Setting backup data reading/writing	-
	U927	Clearing the all copy counts and machine life counts (one time only)	-
	U977	Data capture mode	-

(3) Contents of the maintenance mode items

Item No.	Description																
U000	<p>Outputting an own-status report</p> <p>Description Outputs lists of the current settings of the maintenance items and paper jam and service call occurrences. Outputs the event log. Also sends output data to the USB memory. Printing a report is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p>Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output. <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>MAINTENANCE</td><td>List of the current settings of the maintenance modes</td></tr> <tr> <td>EVENT</td><td>Outputs the event log</td></tr> <tr> <td>ALL</td><td>Outputs the all reports</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. A list is output. <p>Method: Send to the USB memory</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the item to be send. 7. Select [TEXT] or [HTML]. <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>Print</td><td>Outputs the report</td></tr> <tr> <td>USB (TEXT)</td><td>Sends output data to the USB memory (text type)</td></tr> <tr> <td>USB (HTML)</td><td>Sends output data to the USB memory (HTML type)</td></tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Output will be sent to the USB memory. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	MAINTENANCE	List of the current settings of the maintenance modes	EVENT	Outputs the event log	ALL	Outputs the all reports	Display	Output list	Print	Outputs the report	USB (TEXT)	Sends output data to the USB memory (text type)	USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list																
MAINTENANCE	List of the current settings of the maintenance modes																
EVENT	Outputs the event log																
ALL	Outputs the all reports																
Display	Output list																
Print	Outputs the report																
USB (TEXT)	Sends output data to the USB memory (text type)																
USB (HTML)	Sends output data to the USB memory (HTML type)																

Item No.	Description				
U000	Detail of event log				
	No.	Items	Description		
	(1)	System version			
	(2)	System date			
	(3)	Engine soft version			
	(4)	Engine boot version			
	(5)	Operation panel mask version			
	(6)	Machine serial number			
	(7)	Paper Jam Log	#	Count.	Event
			Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence excesseds 16, the oldest occurrence is removed.	The total page count at the time of the paper jam.	Log code (2 digit, hexadecimal, 5 categories) (a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject
			(a) Cause of paper jam (Hexadecimal)		
			Refer to P.1-4-1 for paper jam location 0010: Paper does not arrive at the registration sensor. (MP tray) 0010: Paper does not arrive at the registration sensor. (Cassette) 0010: Paper does not arrive at the registration sensor. (Paper feeder) 0010: Paper does not arrive at the registration sensor. (Duplex) 0011: Paper does not pass the registration sensor 0012: Paper remains at the registration sensor when power is turned on. 0020: Paper does not arrive at the eject sensor. 0021: Paper does not pass the eject sensor. 0022: Paper remains at the eject sensor when power is turned on. 0030: Paper does not arrive at the PF paper feed sensor 1. (Paper feeder 1) 0030: Paper does not arrive at the PF paper feed sensor 1. (Paper feeder 2) 0031: Paper does not pass the PF paper feed sensor 1. (Paper feeder 1) 0032: Paper remains at the PF paper feed sensor 1 when power is turned on. (Paper feeder 1) 0040: Paper does not arrive at the PF paper feed sensor 2. (Paper feeder 2) 0041: Paper does not pass the PF paper sensor 2.(Paper feeder 2) 0042: Paper remains at the PF paper feed sensor 2 when power is turned on. (Paper feeder 2) 0050: Paper does not arrive at the PF paper feed sensor 3. (Paper feeder 3) 0051: Paper does not pass the PF paper sensor 3.(Paper feeder 3) 0052: Paper remains at the PF paper feed sensor 3 when power is turned on. (Paper feeder 3)		

Item No.	Description		
U000			
	No.	Items	Description
	(7) cont.	Paper Jam Log	9000: No original feed 9401: An original jam in the original conveying section 1. 9001: An original jam in the original conveying section 2. 9003: An original jam in the original switchback section. 9004: An original jam in the original switchback/feed section. 9011: Top cover open. 00A1: Paper does not arrive at the duplex sensor. 00A2: Paper does not pass the duplex sensor. 00A3: Paper does not arrive at the duplex jam sensor. 00A4: Paper does not pass the duplex jam sensor. 00A5: Paper remains at the duplex sensor or the duplex jam sensor when power is turned on. 00E0: Paper misfeed occurs due to forced stop when an error occurs during printing. 00F0: Paper does not arrive at the paper full sensor. 00F1: Paper misfeed by system error. 00F2: Paper misfeed by system error.
	(b) Detail of paper source (Hexadecimal)		
	00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 04: Cassette 4 (paper feeder 3) 05 to 09: Reserved		
	(c) Detail of paper size (Hexadecimal)		
00: (Not specified) 0B: B4 22: Special 1 01: Monarch 0C: Ledger 23: Special 2 02: Business 0D: A5R 24: A3 wide 03: International DL 0E: A6 25: Ledger wide 04: International C5 0F: B6 26: Full bleed paper 05: Executive 10: Commercial #9 (12 x 8) 06: Letter-R 11: Commercial #6 27: 8K 86: Letter-E 12: ISO B5 28: 16K-R 07: Legal 13: Custom size A8: 16K-E 08: A4R 1E: C4 32: Statement-R 88: A4E 1F: Postcard B2: Statement-E 09: B5R 20: Reply-paid post- 33: Folio 89: B5E card 34: Western type 2 0A: A3 21: Oficio II 35: Western type 4			

Item No.	Description			
U000				
	No.	Items	Description	
	(7) cont.	Paper Jam Log	(d) Detail of paper type (Hexadecimal)	
			01: Plain	0A: Color
			02: Transparency	0B: Prepunched
			03: Preprinted	0C: Envelope
			04: Labels	0D: Cardstock
			05: Bond	0E: Coated
			06: Recycled	0F: 2nd side
			07: Vellum	10: Media 16
			08: Rough	11: High quality
			09: Letterhead	15: Custom 1
			(e) Detail of paper eject location (Hexadecimal)	
			01: Face down (FD)	
	(8)	Service Call Log	#	Count.
			Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.	The total page count at the time of the self diagnostics error.
				Service Code
				Self diagnostic error code (See page 1-4-5)
	(9)	Maintenance Log	#	Count.
			Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.	The total page count at the time of the replacement of the toner container.
				Item
				Code of maintenance replacing item (1 byte, 2 categories)
				First byte (Replacing item)
				01: Toner container
				02: Maintenance kit
				Second byte (Type of replacing item)
				00: Black
				01: MK-350/MK-370

Item No.	Description			
U000				
	No.	Items	Description	
	(10)	Unknown Toner Log	<div>#</div> <div>Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.</div>	<div>Count.</div> <div>The total page count at the time of the [Toner Empty] error with using an unknown toner container.</div>
			<div>Item</div> <div>Unknown toner log code (1 byte, 2 categories)</div> <div>First byte 01: Fixed (Toner container)</div> <div>Second byte 00: Fixed (Black)</div>	
(11)	Counter Log	(f) Paper jam	(g) Self diagnostic error	(h) Maintenance item replacing
		<div>Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.</div> <div>Indicates the log counter of paper jams depending on location.</div> <div>Refer to Paper Jam Log.</div> <div>All instances including those are not occurred are displayed.</div>	<div>Indicates the log counter of self diagnostics errors depending on cause.</div> <div>(See page 1-4-5)</div> <div>Example: C6000: 4</div> <div>Self diagnostics error 6000 has happened four times.</div>	<div>Indicates the log counter depending on the maintenance item for maintenance.</div> <div>T: Toner container 00: Black M: Maintenance kit 00: MK-350/MK-370</div> <div>Example: T00: 1 The toner container has been replaced once.</div>

Item No.	Description										
U002	<p>Setting the factory default data</p> <p>Description Restores the machine conditions to the factory default settings.</p> <p>Purpose To move the image scanner unit to the home position. (position in which the frame can be fixed).</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [MODE1(ALL)]. 3. Press the start key. The image scanner returns to the home position. 4. Turn the main power switch off and on. * : An error code is displayed in case of an initialization error. When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U002. <p>Error codes</p> <table> <tr> <th>Codes</th><th>Description</th></tr> <tr> <td>0001</td><td>Controller error</td></tr> <tr> <td>0020</td><td>Engine error</td></tr> <tr> <td>0040</td><td>Scanner error</td></tr> </table>	Codes	Description	0001	Controller error	0020	Engine error	0040	Scanner error		
Codes	Description										
0001	Controller error										
0020	Engine error										
0040	Scanner error										
U004	<p>Setting the machine number</p> <p>Description Sets or displays the machine number.</p> <p>Purpose To check or set the machine number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. If the machine serial number of engine PWB matches with that of main PWB <table> <tr> <th>Display</th><th>Operation</th></tr> <tr> <td>MACHINE No.</td><td>Displays the machine serial number</td></tr> </table> <p>If the machine serial number of engine PWB does not match with that of main PWB</p> <table> <tr> <th>Display</th><th>Operation</th></tr> <tr> <td>MACHINE No. (MAIN)</td><td>Displays the machine serial number of main</td></tr> <tr> <td>MACHINE No.</td><td>Displays the machine serial number of engine</td></tr> </table> <p>Setting Carry out if the machine serial number does not match.</p> <ol style="list-style-type: none"> 1. Press [EXECUTE]. 2. Press the start key. Writing of serial No. starts. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MACHINE No.	Displays the machine serial number	Display	Operation	MACHINE No. (MAIN)	Displays the machine serial number of main	MACHINE No.	Displays the machine serial number of engine
Display	Operation										
MACHINE No.	Displays the machine serial number										
Display	Operation										
MACHINE No. (MAIN)	Displays the machine serial number of main										
MACHINE No.	Displays the machine serial number of engine										

Item No.	Description						
U201	<p data-bbox="288 244 628 275">Initializing the touch panel</p> <p data-bbox="288 313 440 342">Description</p> <p data-bbox="288 347 1174 376">Automatically correct the positions of the X- and Y-axes of the touch panel.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1273 445">To automatically correct the display positions on the touch panel after it is replaced.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 711 584" style="list-style-type: none"> 1. Press the start key. 2. Select the [Initialize] or [Check]. <table data-bbox="347 593 1412 719"> <tr> <th data-bbox="355 600 651 633">Display</th><th data-bbox="651 600 1404 633">Description</th></tr> <tr> <td data-bbox="355 640 651 674">Initialize</td><td data-bbox="651 640 1404 674">Adjusts the display on the panel automatically.</td></tr> <tr> <td data-bbox="355 680 651 714">Check</td><td data-bbox="651 680 1404 714">Checks the display on the touch panel.</td></tr> </table> <p data-bbox="288 768 509 797">Method: Initialize</p> <ol data-bbox="308 801 1300 972" style="list-style-type: none"> 1. Press the start key. 2. Press the center of the + keys. Be sure to press three + keys displayed in order. The touch panel is adjusted automatically. 3. Press the indicated three + keys, and then check the display. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p data-bbox="288 1010 485 1039">Method: Check</p> <ol data-bbox="308 1043 1374 1180" style="list-style-type: none"> 1. Press the start key. 2. Press the indicated three + keys, and then check the display. When adjusting the display, press [INITIALIZE] to execute the adjustment automatically. 3. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p data-bbox="288 1218 440 1247">Completion</p> <p data-bbox="288 1252 1254 1281">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Initialize	Adjusts the display on the panel automatically.	Check	Checks the display on the touch panel.
Display	Description						
Initialize	Adjusts the display on the panel automatically.						
Check	Checks the display on the touch panel.						

Item No.	Description																
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Place an original in the DP if running this simulation with paper. 3. Select the speed to be operated. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>NORMAL SPEED</td><td>Normal reading (600 dpi)</td></tr> <tr> <td>HIGH SPEED</td><td>High-speed reading</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. 5. Select the item to be operated. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>CCD ADP (NON P)</td><td>Without paper, single-sided original of CCD (continuous operation)</td></tr> <tr> <td>CCD ADP</td><td>With paper, single-sided original of CCD</td></tr> <tr> <td>CCD RADP (NON P)</td><td>Without paper, double-sided original of CCD (continuous operation)</td></tr> <tr> <td>CCD RADP</td><td>With paper, double-sided original of CCD</td></tr> </tbody> </table> <ol style="list-style-type: none"> 6. Press the start key. The operation starts. 7. To stop continuous operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	NORMAL SPEED	Normal reading (600 dpi)	HIGH SPEED	High-speed reading	Display	Description	CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)	CCD ADP	With paper, single-sided original of CCD	CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)	CCD RADP	With paper, double-sided original of CCD
Display	Description																
NORMAL SPEED	Normal reading (600 dpi)																
HIGH SPEED	High-speed reading																
Display	Description																
CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)																
CCD ADP	With paper, single-sided original of CCD																
CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)																
CCD RADP	With paper, double-sided original of CCD																

Item No.	Description						
U222	<p data-bbox="290 241 592 275">Setting the IC card type</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 579 374">Sets the type of IC card.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 647 443">To change the type of IC card.</p> <p data-bbox="290 486 383 515">Setting</p> <ol data-bbox="308 519 890 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item using the cursor up/down keys. <table data-bbox="338 598 1401 741"> <tr> <th data-bbox="338 598 641 645">Display</th><th data-bbox="641 598 1401 645">Description</th></tr> <tr> <td data-bbox="338 645 641 692">Other</td><td data-bbox="641 645 1401 692">The type of IC card is SSFC.</td></tr> <tr> <td data-bbox="338 692 641 741">SSFC</td><td data-bbox="641 692 1401 741">The type of IC card is not SSFC.</td></tr> </table> <p data-bbox="338 752 608 781">* : Initial setting: Other</p> <ol data-bbox="308 786 782 815" style="list-style-type: none"> 3. Press the start key. The setting is set. <p data-bbox="290 855 440 884">Completion</p> <p data-bbox="290 889 1254 918">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Other	The type of IC card is SSFC.	SSFC	The type of IC card is not SSFC.
Display	Description						
Other	The type of IC card is SSFC.						
SSFC	The type of IC card is not SSFC.						

Item No.	Description														
U224	<p>Panel sheet extension</p> <p>Description Changes the image data and the message of the opening screen at the machine startup and the image data and the message of the service call screen to user specified data.</p> <p>Purpose Set according to the preference of the user.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Write the image data or the message data to the USB memory. 2. Insert USB memory in USB memory slot of the machine. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the [Install] or [UnInstall]. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Install</td><td>Installs the image data or the message data</td></tr> <tr> <td>UnInstall</td><td>Restores the original image data or message data</td></tr> </tbody> </table> <ol style="list-style-type: none"> 1. Select the item. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Call Msg Top</td><td>Service call screen 1</td></tr> <tr> <td>Call Msg Detail</td><td>Service call screen 2</td></tr> <tr> <td>Call Msg TEL No.</td><td>TEL No. for service call.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 1. Press the start key. Installation or uninstallation is started. 2. When normally completed, [Complete] is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Install	Installs the image data or the message data	UnInstall	Restores the original image data or message data	Display	Description	Call Msg Top	Service call screen 1	Call Msg Detail	Service call screen 2	Call Msg TEL No.	TEL No. for service call.
Display	Description														
Install	Installs the image data or the message data														
UnInstall	Restores the original image data or message data														
Display	Description														
Call Msg Top	Service call screen 1														
Call Msg Detail	Service call screen 2														
Call Msg TEL No.	TEL No. for service call.														

Item No.	Description						
U250	<p>Setting the maintenance cycle</p> <p>Description Displays, clears and changes the maintenance cycle.</p> <p>Purpose To check and change the maintenance cycle.</p> <p>Method 1. Press the start key. The currently set maintenance cycle is displayed.</p> <p>Setting 1. Select [M.CNT A]. 2. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance cycle</td><td>0 to 9999999</td><td>100000</td></tr></table> <p>3. Press the start key. The value is set.</p> <p>Clearing 1. Select [CLEAR]. 2. Press the start key. The count is cleared.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance cycle	0 to 9999999	100000
Description	Setting range	Initial setting					
Maintenance cycle	0 to 9999999	100000					

Item No.	Description						
U251	Checking/clearing the maintenance count						
	Description						
	Displays, clears and changes the maintenance count.						
	Purpose						
	To check the maintenance count.						
	Also to clear the count during maintenance service (replacing the maintenance kit).						
	Method						
	1. Press the start key. The maintenance count is displayed.						
	Setting						
	1. Select [M.CNT A].						
2. Change the setting using the cursor left/right keys or numeric keys.							
	<table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance count</td><td>0 to 9999999</td><td>0</td></tr></table>	Description	Setting range	Initial setting	Maintenance count	0 to 9999999	0
Description	Setting range	Initial setting					
Maintenance count	0 to 9999999	0					
	3. Press the start key. The count is set.						
Clearing							
	1. Select [CLEAR].						
	2. Press the start key. The count is cleared.						
Completion							
	Press the stop key. The screen for selecting a maintenance item No. is displayed.						

Item No.	Description														
U252	<p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after initializing the backup RAM, in order to return the setting to the value before replacement or initialization.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" data-bbox="347 629 1412 920"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Inch</td><td>Inch (North America) specifications</td></tr> <tr> <td>Europe Metric</td><td>Metric (Europe) specifications</td></tr> <tr> <td>Asia Pacific</td><td>Metric (Asia Pacific) specifications</td></tr> <tr> <td>Australia</td><td>Australia specifications</td></tr> <tr> <td>China</td><td>China specifications</td></tr> <tr> <td>Korea</td><td>Korea specifications</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. 4. Turn the main power switch off and on. <p>Supplement The specified initial settings are provided according to the destinations in the maintenance items below. To change the initial settings in those items, be sure to run maintenance item U021 after changing the destination.</p>	Display	Description	Inch	Inch (North America) specifications	Europe Metric	Metric (Europe) specifications	Asia Pacific	Metric (Asia Pacific) specifications	Australia	Australia specifications	China	China specifications	Korea	Korea specifications
Display	Description														
Inch	Inch (North America) specifications														
Europe Metric	Metric (Europe) specifications														
Asia Pacific	Metric (Asia Pacific) specifications														
Australia	Australia specifications														
China	China specifications														
Korea	Korea specifications														
U253	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose Used to select, according to the preference of the user (copy service provider), if folio size paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the count system. <table border="1" data-bbox="336 1644 1401 1789"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SGL (ALL)</td><td>Single count for all size paper</td></tr> <tr> <td>DBL (FOLIO)</td><td>Double count for Folio size or larger</td></tr> </tbody> </table> <p>* : Initial setting: DBL COUNT(FOLIO)</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SGL (ALL)	Single count for all size paper	DBL (FOLIO)	Double count for Folio size or larger								
Display	Description														
SGL (ALL)	Single count for all size paper														
DBL (FOLIO)	Double count for Folio size or larger														

Item No.	Description						
U260	<p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user request.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FEED</td><td>When secondary paper feed starts</td></tr> <tr> <td>EJECT</td><td>When the paper is ejected</td></tr> </tbody> </table> <p>* : Initial setting: EJECT</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FEED	When secondary paper feed starts	EJECT	When the paper is ejected
Display	Description						
FEED	When secondary paper feed starts						
EJECT	When the paper is ejected						
U285	<p>Setting service status page</p> <p>Description Determines displaying the digital dot coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Displays the digital dot coverage</td></tr> <tr> <td>OFF</td><td>Not to display the digital dot coverage</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the digital dot coverage	OFF	Not to display the digital dot coverage
Display	Description						
ON	Displays the digital dot coverage						
OFF	Not to display the digital dot coverage						

Item No.	Description								
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Change the setting using the cursor left/right keys or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Calc. Rate</td><td>Size parameter</td><td>0.1 to 3.0</td><td>1.0</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Calc. Rate	Size parameter	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting						
Calc. Rate	Size parameter	0.1 to 3.0	1.0						
U345	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p>Purpose To change the time for maintenance due indication.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select [COUNT].3. Change the setting using the cursor left/right keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td><td>0 to 9999</td><td>0</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Clearing</p> <ol style="list-style-type: none">1. Select [CLEAR].2. Press the start key. The value is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0		
Description	Setting range	Initial setting							
Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0							

Item No.	Description												
U411	<p>Adjusting the scanner automatically</p> <p>Description Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections. Scanner section: Original size magnification, leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix DP scanning section: Original size magnification, leading edge timing, center line</p> <p>Purpose To perform automatic adjustment of various items in the scanner and the DP scanning sections.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. The screen for executing is displayed. <table><tr><th>Display</th><th>Description</th><th>Original to be used for adjustment (P/N)</th></tr><tr><td>ALL</td><td>Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section</td><td>302FZ56990/ 303LJ57010</td></tr><tr><td>ADJUST TABLE</td><td>Automatic adjustment in the scanner section</td><td>302FZ56990</td></tr><tr><td>ADJUST DP</td><td>Automatic adjustment in the DP scanning section:</td><td>303LJ57010</td></tr></table> <p>Method: TABLE</p> <ol style="list-style-type: none">1. Enter the target values which are shown on the specified original (P/N: 302FZ56990) executing maintenance item U425.2. Set a specified original (P/N: 302FZ56990) on the platen.3. Enter maintenance item U411.4. Select [ADJUST TABLE] using the cursor up/down keys.5. Press the start key. Auto adjustment starts.6. When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.7. To return to the screen for selecting an item, press the stop key. <p>Method: DP</p> <ol style="list-style-type: none">1. Select [ADJUST DP] using the cursor up/down keys.2. Set a specified original (P/N: 303LJ57010) in the DP.3. Press the start key. Auto adjustment starts.4. When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.5. To return to the screen for selecting an item, press the stop key.	Display	Description	Original to be used for adjustment (P/N)	ALL	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	302FZ56990/ 303LJ57010	ADJUST TABLE	Automatic adjustment in the scanner section	302FZ56990	ADJUST DP	Automatic adjustment in the DP scanning section:	303LJ57010
Display	Description	Original to be used for adjustment (P/N)											
ALL	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	302FZ56990/ 303LJ57010											
ADJUST TABLE	Automatic adjustment in the scanner section	302FZ56990											
ADJUST DP	Automatic adjustment in the DP scanning section:	303LJ57010											

Item No.	Description																																																					
U411	Error Codes																																																					
	Codes	Description	01	Black band detection error (scanner leading edge registration)	02	Black band detection error (scanner center line)	03	Black band detection error (scanner main scanning direction magnification)	04	Black band is not detected (scanner leading edge registration)	05	Black band is not detected (scanner center line)	06	Black band is not detected (scanner main scanning direction magnification)	07	Black band is not detected (scanner auxiliary scanning direction magnification)	08	Black band is not detected (DP main scanning direction magnification far end)	09	Black band is not detected (DP main scanning direction magnification near end)	0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)	0e	DMA time out	0f	Auxiliary scanning direction magnification error	10	Auxiliary scanning direction leading edge detection error	11	Auxiliary scanning direction trailing edge detection error	12	Auxiliary scanning direction skew 1.5 error	13	Maintenance request error	14	Main scanning direction center line error	15	Main scanning direction skew 1.5 error	16	Main scanning direction magnification error	17	Service call error	18	DP paper misfeed error	19	PWB replacement error	1a	Original error
	Codes	Description																																																				
	01	Black band detection error (scanner leading edge registration)																																																				
	02	Black band detection error (scanner center line)																																																				
	03	Black band detection error (scanner main scanning direction magnification)																																																				
	04	Black band is not detected (scanner leading edge registration)																																																				
	05	Black band is not detected (scanner center line)																																																				
	06	Black band is not detected (scanner main scanning direction magnification)																																																				
	07	Black band is not detected (scanner auxiliary scanning direction magnification)																																																				
	08	Black band is not detected (DP main scanning direction magnification far end)																																																				
	09	Black band is not detected (DP main scanning direction magnification near end)																																																				
	0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)																																																				
	0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)																																																				
	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)																																																				
	0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)																																																				
	0e	DMA time out																																																				
	0f	Auxiliary scanning direction magnification error																																																				
	10	Auxiliary scanning direction leading edge detection error																																																				
	11	Auxiliary scanning direction trailing edge detection error																																																				
	12	Auxiliary scanning direction skew 1.5 error																																																				
	13	Maintenance request error																																																				
	14	Main scanning direction center line error																																																				
	15	Main scanning direction skew 1.5 error																																																				
	16	Main scanning direction magnification error																																																				
	17	Service call error																																																				
	18	DP paper misfeed error																																																				
	19	PWB replacement error																																																				
1a	Original error																																																					
Completion Press the stop key. The screen for selecting a maintenance item is displayed.																																																						

Item No.	Description																																		
U425	<p>Setting the target</p> <p>Description Enters the lab values that is indicated on the back of the chart (P/N: 302FZ56990) used for adjustment.</p> <p>Purpose Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p>Method</p> <p>1. Press the start key.</p> <p>2. Select the item to be set using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>N875</td><td>Setting the N875 patch for the original for adjustment</td></tr><tr><td>N475</td><td>Setting the N475 patch for the original for adjustment</td></tr><tr><td>N125</td><td>Setting the N125 patch for the original for adjustment</td></tr><tr><td>CYAN</td><td>Setting the cyan patch for the original for adjustment</td></tr><tr><td>MAGENTA</td><td>Setting the magenta patch for the original for adjustment</td></tr><tr><td>YELLOW</td><td>Setting the yellow patch for the original for adjustment</td></tr><tr><td>RED</td><td>Setting the red patch for the original for adjustment</td></tr><tr><td>GREEN</td><td>Setting the green patch for the original for adjustment</td></tr><tr><td>BLUE</td><td>Setting the blue patch for the original for adjustment</td></tr><tr><td>ADJUST ORIGINAL</td><td>Setting the main and auxiliary scanning directions</td></tr></table> <p>3. Select the item to be set using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th></tr><tr><td>L</td><td>Setting the L value</td><td>0.0 to 100.0</td></tr><tr><td>a</td><td>Setting the a value</td><td>-200.0 to 200.0</td></tr><tr><td>b</td><td>Setting the b value</td><td>-200.0 to 200.0</td></tr></table> <p>4. Enters the value that is indicated on the back of the chart using the cursor left/right keys or numeric keys.</p> <p>5. Press the start key. The value is set.</p>	Display	Description	N875	Setting the N875 patch for the original for adjustment	N475	Setting the N475 patch for the original for adjustment	N125	Setting the N125 patch for the original for adjustment	CYAN	Setting the cyan patch for the original for adjustment	MAGENTA	Setting the magenta patch for the original for adjustment	YELLOW	Setting the yellow patch for the original for adjustment	RED	Setting the red patch for the original for adjustment	GREEN	Setting the green patch for the original for adjustment	BLUE	Setting the blue patch for the original for adjustment	ADJUST ORIGINAL	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	a	Setting the a value	-200.0 to 200.0	b	Setting the b value	-200.0 to 200.0
Display	Description																																		
N875	Setting the N875 patch for the original for adjustment																																		
N475	Setting the N475 patch for the original for adjustment																																		
N125	Setting the N125 patch for the original for adjustment																																		
CYAN	Setting the cyan patch for the original for adjustment																																		
MAGENTA	Setting the magenta patch for the original for adjustment																																		
YELLOW	Setting the yellow patch for the original for adjustment																																		
RED	Setting the red patch for the original for adjustment																																		
GREEN	Setting the green patch for the original for adjustment																																		
BLUE	Setting the blue patch for the original for adjustment																																		
ADJUST ORIGINAL	Setting the main and auxiliary scanning directions																																		
Display	Description	Setting range																																	
L	Setting the L value	0.0 to 100.0																																	
a	Setting the a value	-200.0 to 200.0																																	
b	Setting the b value	-200.0 to 200.0																																	

Item No.	Description
U425	<p>Setting: [ADJUST ORIGINAL]</p> <ol style="list-style-type: none"> 1. Measure the distance from the left edge to the black belt (a) of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (a) of the original at A (30 mm from the leading edge), B (148.5 mm from the leading edge) and C (267 mm from the leading edge), respectively. 2) Apply the following formula for the values obtained: $((A + C) / 2 + B) / 2$ 2. Enter the values solved using the cursor left/right keys or numeric keys in [MAIN]. 3. Press the start key. The value is set. 4. Measure the distance from the leading edge to the black belt (b) of the original at D, E and F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (b) of the original at D (35 mm from the left edge), E (110 mm from the left edge) and F (185 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((D + F) / 2 + E) / 2$ 5. Enter the values solved using the cursor left/right keys or numeric keys in [SUB LEAD]. 6. Press the start key. The value is set. 7. Measure the length (G) from the edge of the black belt (b) to edge of the black belt (c) of the original. 8. Enter the measured value using the cursor left/right keys or numeric keys in [SUB TAIL]. 9. Press the start key. The value is set. <div data-bbox="280 1025 1434 1697"> <div data-bbox="1217 1361 1434 1615" style="border: 1px solid black; padding: 5px;"> <p>[MAIN] = $((A + C) / 2 + B) / 2$</p> <p>[SUB LEAD] = $((D + F) / 2 + E) / 2$</p> <p>[SUB TAIL] = G</p> </div> </div> <p style="text-align: center;">Original for adjustment (P/N: 302FZ56990)</p> <p style="text-align: center;">Figure 1-3-2</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																																																																												
U600	<p>Initializing all data</p> <p>Description Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination and OEM. Executes the check of the file system, when abnormality of the file system is detected, initializes the file system, communication past record and register setting contents.</p> <p>Purpose To initialize the FAX control PWB.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select [Execute]. The screen for entering the destination code and OEM code is displayed.3. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on following for the destination code).4. Press the start key. There is no operation necessary on this screen. The destination code and the OEM code are displayed with the values currently set.5. Press the start key. Data initialization starts. To cancel data initialization, press the stop key.6. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. <p>Destination code list</p> <table><tr><th>Code</th><th>Destination</th><th>Code</th><th>Destination</th></tr><tr><td>000</td><td>Japan</td><td>253</td><td>CTR21 (European nations)</td></tr><tr><td>009</td><td>Australia</td><td></td><td>Italy</td></tr><tr><td>038</td><td>China</td><td></td><td>Germany</td></tr><tr><td>080</td><td>Hong Kong</td><td></td><td>Spain</td></tr><tr><td>084</td><td>Indonesia</td><td></td><td>U.K.</td></tr><tr><td>088</td><td>Israel</td><td></td><td>Netherlands</td></tr><tr><td>097</td><td>Korea</td><td></td><td>Sweden</td></tr><tr><td>108</td><td>Malaysia</td><td></td><td>France</td></tr><tr><td>126</td><td>New Zealand</td><td></td><td>Austria</td></tr><tr><td>136</td><td>Peru</td><td></td><td>Switzerland</td></tr><tr><td>137</td><td>Philippines</td><td></td><td>Belgium</td></tr><tr><td>152</td><td>Middle East</td><td></td><td>Denmark</td></tr><tr><td>156</td><td>Singapore</td><td></td><td>Finland</td></tr><tr><td>159</td><td>South Africa</td><td></td><td>Portugal</td></tr><tr><td>169</td><td>Thailand</td><td></td><td>Ireland</td></tr><tr><td>181</td><td>U.S.A.</td><td></td><td>Norway</td></tr><tr><td>242</td><td>South America</td><td>254</td><td>Taiwan</td></tr><tr><td>243</td><td>Saudi Arabia</td><td></td><td></td></tr></table>	Code	Destination	Code	Destination	000	Japan	253	CTR21 (European nations)	009	Australia		Italy	038	China		Germany	080	Hong Kong		Spain	084	Indonesia		U.K.	088	Israel		Netherlands	097	Korea		Sweden	108	Malaysia		France	126	New Zealand		Austria	136	Peru		Switzerland	137	Philippines		Belgium	152	Middle East		Denmark	156	Singapore		Finland	159	South Africa		Portugal	169	Thailand		Ireland	181	U.S.A.		Norway	242	South America	254	Taiwan	243	Saudi Arabia		
Code	Destination	Code	Destination																																																																										
000	Japan	253	CTR21 (European nations)																																																																										
009	Australia		Italy																																																																										
038	China		Germany																																																																										
080	Hong Kong		Spain																																																																										
084	Indonesia		U.K.																																																																										
088	Israel		Netherlands																																																																										
097	Korea		Sweden																																																																										
108	Malaysia		France																																																																										
126	New Zealand		Austria																																																																										
136	Peru		Switzerland																																																																										
137	Philippines		Belgium																																																																										
152	Middle East		Denmark																																																																										
156	Singapore		Finland																																																																										
159	South Africa		Portugal																																																																										
169	Thailand		Ireland																																																																										
181	U.S.A.		Norway																																																																										
242	South America	254	Taiwan																																																																										
243	Saudi Arabia																																																																												

Item No.	Description								
U601	<p>Initializing permanent data</p> <p>Description Initializes software switches on the FAX control PWB according to the destination and OEM.</p> <p>Purpose To initialize the FAX control PWB without changing user registration data.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. The screen for entering the destination code and OEM code is displayed. 3. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on page 1-3-25 for the destination code). 4. Press the start key. There is no operation necessary on this screen. The destination code and the OEM code are displayed with the values currently set. 5. Press the start key. Data initialization starts. To cancel data initialization, press the back key. 6. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. 								
U603	<p>Setting user data 1</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose To be run after installation of the facsimile kit if necessary.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [LINE TYPE] and press the start key. 3. Select the setting. <table border="1" data-bbox="338 1303 1401 1496"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DTMF</td><td>DTMF</td></tr> <tr> <td>10PPS</td><td>10 PPS</td></tr> <tr> <td>20PPS</td><td>20 PPS</td></tr> </tbody> </table> <p>* : Initial setting: DTMF</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DTMF	DTMF	10PPS	10 PPS	20PPS	20 PPS
Display	Description								
DTMF	DTMF								
10PPS	10 PPS								
20PPS	20 PPS								

Item No.	Description						
U604	<p>Setting user data 2</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose Use this if the user wishes to adjust the number of rings that occur before the unit switches into fax receiving mode when fax/telephone auto-select is enabled.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select [RINGS(F/P)#].3. Change the setting using the cursor left/right keys or numeric keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of fax/telephone rings</td><td>0 to 15</td><td>2 (120 V)/1 (220-240 V)</td></tr></table> <p>* : If you set this to 0, the unit will start fax reception without any ringing.</p> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)
Description	Setting range	Initial setting					
Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)					
U605	<p>Clearing data</p> <p>Description Initializes data related to the fax transmission such as transmission history.</p> <p>Purpose To clear the transmission history.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select [CLEAR COM.REC.].3. Press the start key. Initialization processing starts. When processing is finished, [Completed] is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						

Item No.	Description																								
U610	<p>Setting system 1</p> <p>Description Makes settings for fax reception regarding the sizes of the fax paper and received images and automatic printing of the protocol list.</p> <p>Method 1. Press the start key. 2. Select the item to be set.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>CUT LINE:100%</td><td>Sets the number of lines to be ignored when receiving a fax at 100% magnification.</td></tr><tr><td>CUT LINE:AUTO</td><td>Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.</td></tr><tr><td>CUT LINE:A4</td><td>Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.</td></tr></table> <p>Setting the number of lines to be ignored when receiving a fax at 100% magnification Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification. If the number of excess lines is below the setting, those lines are ignored. If over the setting, they are recorded on the next page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving at 100%</td><td>0 to 22</td><td>3</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a blank second page is output, and decrease it if the received image does not include the entire transmitted data.</p> <p>2. Press the start key. The value is set.</p> <p>Setting the number of lines to be ignored when receiving a fax in the auto reduction mode Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving in the auto reduction mode</td><td>0 to 22</td><td>0</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p>2. Press the start key. The value is set.</p>	Display	Description	CUT LINE:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.	CUT LINE:AUTO	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.	CUT LINE:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines
Display	Description																								
CUT LINE:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.																								
CUT LINE:AUTO	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.																								
CUT LINE:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.																								
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines																						
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines																						

Item No.	Description								
U610	<p>Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode</p> <p>Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or LetterR paper under the conditions below.</p> <p>If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode</td><td>0 to 22</td><td>0</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p>2. Press the start key. The value is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines
Description	Setting range	Initial setting	Change in value per step						
Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines						

Item No.	Description																										
U611	<p>Setting system 2</p> <p>Description Sets the number of adjustment lines for automatic reduction.</p> <p>Method 1. Press the start key. 2. Select the item to be set.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ADJ LINES</td><td>Sets the number of adjustment lines for automatic reduction.</td></tr><tr><td>ADJ LINES(A4)</td><td>Sets the number of adjustment lines for automatic reduction when A4 paper is set.</td></tr><tr><td>ADJ LINES(LT)</td><td>Sets the number of adjustment lines for automatic reduction when letter size paper is set.</td></tr></table> <p>Setting the number of adjustment lines for automatic reduction Sets the number of adjustment lines for automatic reduction. 1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction</td><td>0 to 22</td><td>7</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Setting the number of adjustment lines for automatic reduction when A4 paper is set Sets the number of adjustment lines for automatic reduction when A4 paper is set. 1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction when A4 paper is set</td><td>0 to 22</td><td>22</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Setting the number of adjustment lines for automatic reduction when letter size paper is set Sets the number of adjustment lines for automatic reduction when letter size paper is set. 1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction when letter size paper is set</td><td>0 to 26</td><td>26</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ADJ LINES	Sets the number of adjustment lines for automatic reduction.	ADJ LINES(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.	ADJ LINES(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction	0 to 22	7	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26
Display	Description																										
ADJ LINES	Sets the number of adjustment lines for automatic reduction.																										
ADJ LINES(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.																										
ADJ LINES(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.																										
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction	0 to 22	7																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26																									

Item No.	Description																				
U612	<p>Setting system 3</p> <p>Description Makes settings for fax transmission regarding operation and automatic printing of the protocol list.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Auto Reduction</td><td>Selects if auto reduction in the auxiliary direction is to be performed.</td></tr> <tr> <td>Protocol List</td><td>Sets the automatic printing of the protocol list.</td></tr> </tbody> </table> <p>Selecting if auto reduction in the auxiliary direction is to be performed Sets whether to receive a long document by automatically reducing it in the auxiliary direction or at 100% magnification.</p> <ol style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>On</td><td>Auto reduction is performed if the received document is longer than the fax paper.</td></tr> <tr> <td>Off</td><td>Auto reduction is not performed.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting the automatic printing of the protocol list Sets if the protocol list is automatically printed out.</p> <ol style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>On</td><td>The protocol list is automatically printed out after communication.</td></tr> <tr> <td>Off</td><td>The protocol list is not printed out automatically.</td></tr> <tr> <td>Err</td><td>The protocol list is automatically printed out after communication only if a communication error occurs.</td></tr> </tbody> </table> <p>* : Initial setting: OFF</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting how trailing edge margins are detected This determines whether trailing edge margin is detected (to prevent image from being mutilated) while printing a received Fax.</p>	Display	Description	Auto Reduction	Selects if auto reduction in the auxiliary direction is to be performed.	Protocol List	Sets the automatic printing of the protocol list.	Display	Description	On	Auto reduction is performed if the received document is longer than the fax paper.	Off	Auto reduction is not performed.	Display	Description	On	The protocol list is automatically printed out after communication.	Off	The protocol list is not printed out automatically.	Err	The protocol list is automatically printed out after communication only if a communication error occurs.
Display	Description																				
Auto Reduction	Selects if auto reduction in the auxiliary direction is to be performed.																				
Protocol List	Sets the automatic printing of the protocol list.																				
Display	Description																				
On	Auto reduction is performed if the received document is longer than the fax paper.																				
Off	Auto reduction is not performed.																				
Display	Description																				
On	The protocol list is automatically printed out after communication.																				
Off	The protocol list is not printed out automatically.																				
Err	The protocol list is automatically printed out after communication only if a communication error occurs.																				

Item No.	Description						
U612	<p>1. Select On or Off using the cursor left/right keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>On</td><td>Detects trailing edge margin</td></tr> <tr> <td>Off</td><td>Does not detect trailing edge margin</td></tr> </tbody> </table> <p>* : Initial setting: On</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Detects trailing edge margin	Off	Does not detect trailing edge margin
Display	Description						
On	Detects trailing edge margin						
Off	Does not detect trailing edge margin						
U620	<p>Setting the remote switching mode</p> <p>Description Sets the signal detection method for remote switching. Be sure to change the setting according to the type of telephone connected to the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Select [REMORT MODE] and press the start key. Select the mode. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ONE</td><td>One-shot detection</td></tr> <tr> <td>CONT</td><td>Continuous detection</td></tr> </tbody> </table> <p>* : Initial setting: ONE</p> <p>4. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ONE	One-shot detection	CONT	Continuous detection
Display	Description						
ONE	One-shot detection						
CONT	Continuous detection						
U625	<p>Setting the transmission system 1</p> <p>Description Makes settings for the auto redialing interval and the number of times of auto redialing.</p> <p>Purpose Change the setting to prevent the following problems: fax transmission is not possible due to too short redial interval, or fax transmission takes too much time to complete due to too long redial interval.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>INTERVAL</td><td>Setting the auto redialing interval</td></tr> <tr> <td>TIMES</td><td>Setting the number of times of auto redialing</td></tr> </tbody> </table>	Display	Description	INTERVAL	Setting the auto redialing interval	TIMES	Setting the number of times of auto redialing
Display	Description						
INTERVAL	Setting the auto redialing interval						
TIMES	Setting the number of times of auto redialing						

Item No.	Description									
U625	Setting the auto redialing interval 1. Change the setting using the cursor left/right keys.									
	Description	Setting range	Initial setting	Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)				
	Description	Setting range	Initial setting							
	Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)							
	2. Press the start key. The value is set.									
	Setting the number of times of auto redialing 1. Change the setting using the cursor left/right keys or numeric keys.									
	Description	Setting range	Initial setting	Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)				
	Description	Setting range	Initial setting							
	Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)							
	2. Press the start key. The value is set.									
Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.										
U630	Setting communication control 1									
	Description Makes settings for fax transmission regarding the communication.									
	Method 1. Press the start key. 2. Select the item to be set.									
	Display	Description	TX SPEED	Sets the communication starting speed.	RX SPEED	Sets the reception speed.	TX ECHO	Sets the waiting period to prevent echo problems at the sender.	RX ECHO	Sets the waiting period to prevent echo problems at the receiver.
	Display	Description								
	TX SPEED	Sets the communication starting speed.								
	RX SPEED	Sets the reception speed.								
	TX ECHO	Sets the waiting period to prevent echo problems at the sender.								
	RX ECHO	Sets the waiting period to prevent echo problems at the receiver.								
Setting the communication starting speed Sets the initial communication speed when starting transmission. When the destination unit has V.34 capability, V.34 is selected for transmission, regardless of this setting.										
1. Select the setting.										
Display	Description	14400bps/V17	V.17, 14400 bps	9600bps/V29	V.17, 9600 bps	4800bps/V27ter	V.27ter, 4800 bps	2400bps/V27ter	V.27ter, 2400 bps	
Display	Description									
14400bps/V17	V.17, 14400 bps									
9600bps/V29	V.17, 9600 bps									
4800bps/V27ter	V.27ter, 4800 bps									
2400bps/V27ter	V.27ter, 2400 bps									
* : Initial setting: 14400bps/V17										
2. Press the start key. The setting is set.										

Item No.	Description																						
U630	<p>Setting the reception speed</p> <p>Sets the reception speed that the sender is informed of using the DIS or NSF signal. When the destination unit has V.34 capability, V.34 is selected, regardless of the setting.</p> <p>1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>14400bps</td><td>V.17, V.33, V.29, V.27ter</td></tr> <tr> <td>9600bps</td><td>V.29, V.27ter</td></tr> <tr> <td>4800bps</td><td>V.27ter</td></tr> <tr> <td>2400bps</td><td>V.27ter (fallback only)</td></tr> </tbody> </table> <p>* : Initial setting: 14400bps</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the waiting period to prevent echo problems at the sender</p> <p>Sets the period before a DCS signal is sent after a DIS signal is received. Used when problems occur due to echoes at the sender.</p> <p>1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>500</td><td>Sends a DCS 500 ms after receiving a DIS.</td></tr> <tr> <td>300</td><td>Sends a DCS 300 ms after receiving a DIS.</td></tr> </tbody> </table> <p>* : Initial setting: 300</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the waiting period to prevent echo problems at the receiver</p> <p>Sets the period before an NSF, CSI or DIS signal is sent after a CED signal is received. Used when problems occur due to echoes at the receiver.</p> <p>1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>500</td><td>Sends an NSF, CSI or DIS 500 ms after receiving a CED.</td></tr> <tr> <td>75</td><td>Sends an NSF, CSI or DIS 75 ms after receiving a CED.</td></tr> </tbody> </table> <p>* : Initial setting: 75</p> <p>2. Press the start key. The setting is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	14400bps	V.17, V.33, V.29, V.27ter	9600bps	V.29, V.27ter	4800bps	V.27ter	2400bps	V.27ter (fallback only)	Display	Description	500	Sends a DCS 500 ms after receiving a DIS.	300	Sends a DCS 300 ms after receiving a DIS.	Display	Description	500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.	75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.
Display	Description																						
14400bps	V.17, V.33, V.29, V.27ter																						
9600bps	V.29, V.27ter																						
4800bps	V.27ter																						
2400bps	V.27ter (fallback only)																						
Display	Description																						
500	Sends a DCS 500 ms after receiving a DIS.																						
300	Sends a DCS 300 ms after receiving a DIS.																						
Display	Description																						
500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.																						
75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.																						

Item No.	Description																										
U631	<p>Setting communication control 2</p> <p>Description Makes settings regarding fax transmission.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ECM TX</td><td>Sets ECM transmission.</td></tr> <tr> <td>ECM RX</td><td>Sets ECM reception.</td></tr> <tr> <td>CED FREQ.</td><td>Sets the frequency of the CED signal.</td></tr> </tbody> </table> <p>Setting ECM transmission To be set to OFF when reduction of transmission costs is of higher priority than image quality. This should not be set to OFF when connecting to the IP (Internet Protocol) telephone line.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>ECM transmission is enabled.</td></tr> <tr> <td>OFF</td><td>ECM transmission is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting ECM reception To be set to OFF when reduction of transmission costs is of higher priority than image quality. This should not be set to OFF when connecting to the IP (Internet Protocol) telephone line.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>ECM reception is enabled.</td></tr> <tr> <td>OFF</td><td>ECM reception is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting the frequency of the CED signal Sets the frequency of the CED signal. Used as one of the measures to improve transmission performance for international communications.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>2100</td><td>2100 Hz</td></tr> <tr> <td>1100</td><td>1100 Hz</td></tr> </tbody> </table> <p>* : Initial setting: 2100</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ECM TX	Sets ECM transmission.	ECM RX	Sets ECM reception.	CED FREQ.	Sets the frequency of the CED signal.	Display	Description	ON	ECM transmission is enabled.	OFF	ECM transmission is disabled.	Display	Description	ON	ECM reception is enabled.	OFF	ECM reception is disabled.	Display	Description	2100	2100 Hz	1100	1100 Hz
Display	Description																										
ECM TX	Sets ECM transmission.																										
ECM RX	Sets ECM reception.																										
CED FREQ.	Sets the frequency of the CED signal.																										
Display	Description																										
ON	ECM transmission is enabled.																										
OFF	ECM transmission is disabled.																										
Display	Description																										
ON	ECM reception is enabled.																										
OFF	ECM reception is disabled.																										
Display	Description																										
2100	2100 Hz																										
1100	1100 Hz																										


Item No.	Description																												
U632	<p>Setting communication control 3</p> <p>Description Makes settings for fax transmission regarding the communication.</p> <p>Method 1. Press the start key. 2. Select the item to be set.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DIS 4BYTE</td><td>Sets the DIS signal to 4 bytes.</td></tr> <tr> <td>SHORT PRTCL TX</td><td>Sets the short protocol transmission.</td></tr> <tr> <td>SHORT PRTCL RX</td><td>Sets the reception of short protocol transmission.</td></tr> <tr> <td>NUM OF CNG(F/T)</td><td>Sets the CNG detection times in the fax/telephone auto select mode.</td></tr> </tbody> </table> <p>Setting the DIS signal to 4 bytes Sets if bit 33 and later bits of the DIS/DTC signal are sent. 1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Bit 33 and later bits of the DIS/DTC signal are not sent.</td></tr> <tr> <td>OFF</td><td>Bit 33 and later bits of the DIS/DTC signal are sent.</td></tr> </tbody> </table> <p>* : Initial setting: OFF 2. Press the start key. The setting is set.</p> <p>Setting the short protocol transmission Sets if short protocol transmission is performed. 1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Short protocol transmission is performed.</td></tr> <tr> <td>OFF</td><td>Short protocol transmission is not performed.</td></tr> </tbody> </table> <p>* : Initial setting: ON 2. Press the start key. The setting is set.</p> <p>Setting the reception of a short protocol transmission Selects whether to receive or ignore transmission using short protocol. If a short protocol transmission is received when an auto switching device is attached to the machine, communication problems, including auto switching inability, sometimes occur. Change the setting to ignore short protocol transmission to prevent such problems. 1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Receives short protocol transmission.</td></tr> <tr> <td>OFF</td><td>Ignores short protocol transmission.</td></tr> </tbody> </table> <p>* : Initial setting: ON 2. Press the start key. The setting is set.</p>	Display	Description	DIS 4BYTE	Sets the DIS signal to 4 bytes.	SHORT PRTCL TX	Sets the short protocol transmission.	SHORT PRTCL RX	Sets the reception of short protocol transmission.	NUM OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.	Display	Description	ON	Bit 33 and later bits of the DIS/DTC signal are not sent.	OFF	Bit 33 and later bits of the DIS/DTC signal are sent.	Display	Description	ON	Short protocol transmission is performed.	OFF	Short protocol transmission is not performed.	Display	Description	ON	Receives short protocol transmission.	OFF	Ignores short protocol transmission.
Display	Description																												
DIS 4BYTE	Sets the DIS signal to 4 bytes.																												
SHORT PRTCL TX	Sets the short protocol transmission.																												
SHORT PRTCL RX	Sets the reception of short protocol transmission.																												
NUM OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.																												
Display	Description																												
ON	Bit 33 and later bits of the DIS/DTC signal are not sent.																												
OFF	Bit 33 and later bits of the DIS/DTC signal are sent.																												
Display	Description																												
ON	Short protocol transmission is performed.																												
OFF	Short protocol transmission is not performed.																												
Display	Description																												
ON	Receives short protocol transmission.																												
OFF	Ignores short protocol transmission.																												

Item No.	Description																				
U632	<p>Setting the CNG detection times in the fax/telephone auto select mode</p> <p>Sets the CNG detection times in the fax/telephone auto select mode.</p> <ol style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>1TIME</td><td>Detects CNG once.</td></tr> <tr> <td>2TIMES</td><td>Detects CNG twice.</td></tr> </tbody> </table> <p>* : Initial setting: 2TIMES</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	1TIME	Detects CNG once.	2TIMES	Detects CNG twice.														
Display	Description																				
1TIME	Detects CNG once.																				
2TIMES	Detects CNG twice.																				
U633	<p>Setting communication control 4</p> <p>Description</p> <p>Makes settings for fax transmission regarding the communication.</p> <p>Purpose</p> <p>To reduce transmission errors when a low quality line is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>V.34</td><td>Enables or disables V.34 communication.</td></tr> <tr> <td>V.34-3429Hz</td><td>Sets the V.34 symbol speed (3429 Hz).</td></tr> <tr> <td>DIS 2RES</td><td>Sets the number of times of DIS signal reception.</td></tr> <tr> <td>RTN CHECK</td><td>Sets the reference for RTN signal output.</td></tr> </tbody> </table> <p>Enabling/disabling V.34 communication</p> <p>Sets whether V.34 communication is enabled/disabled for transmission and reception.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>V.34 communication is enabled for both transmission and reception.</td></tr> <tr> <td>TX</td><td>V.34 communication is enabled for transmission only.</td></tr> <tr> <td>RX</td><td>V.34 communication is enabled for reception only.</td></tr> <tr> <td>OFF</td><td>V.34 communication is disabled for both transmission and reception.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	V.34	Enables or disables V.34 communication.	V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).	DIS 2RES	Sets the number of times of DIS signal reception.	RTN CHECK	Sets the reference for RTN signal output.	Display	Description	ON	V.34 communication is enabled for both transmission and reception.	TX	V.34 communication is enabled for transmission only.	RX	V.34 communication is enabled for reception only.	OFF	V.34 communication is disabled for both transmission and reception.
Display	Description																				
V.34	Enables or disables V.34 communication.																				
V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).																				
DIS 2RES	Sets the number of times of DIS signal reception.																				
RTN CHECK	Sets the reference for RTN signal output.																				
Display	Description																				
ON	V.34 communication is enabled for both transmission and reception.																				
TX	V.34 communication is enabled for transmission only.																				
RX	V.34 communication is enabled for reception only.																				
OFF	V.34 communication is disabled for both transmission and reception.																				

Item No.	Description																						
U633	<p>Setting the V.34 symbol speed (3429 Hz) Sets if the V.34 symbol speed 3429 Hz is used.</p> <p>1. Select the setting.</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>ON</td><td>V.34 symbol speed 3429 Hz is used.</td></tr> <tr> <td>OFF</td><td>V.34 symbol speed 3429 Hz is not used.</td></tr> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the number of times of DIS signal reception Sets the number of times to receive the DIS signal to once or twice. Used as one of the correction measures for transmission errors and other problems.</p> <p>1. Select the setting.</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>ONCE</td><td>Responds to the first signal.</td></tr> <tr> <td>TWICE</td><td>Responds to the second signal.</td></tr> </table> <p>* : Initial setting: ONCE</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the reference for RTN signal output Sets the error line rate as the reference for RTN signal output. If transmission errors occur frequently due to the quality of the line, they can be reduced by lowering this setting.</p> <p>1. Select the setting.</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>5%</td><td>Error line rate of 5%</td></tr> <tr> <td>10%</td><td>Error line rate of 10%</td></tr> <tr> <td>15%</td><td>Error line rate of 15%</td></tr> <tr> <td>20%</td><td>Error line rate of 20%</td></tr> </table> <p>* : Initial setting: 15%</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	V.34 symbol speed 3429 Hz is used.	OFF	V.34 symbol speed 3429 Hz is not used.	Display	Description	ONCE	Responds to the first signal.	TWICE	Responds to the second signal.	Display	Description	5%	Error line rate of 5%	10%	Error line rate of 10%	15%	Error line rate of 15%	20%	Error line rate of 20%
Display	Description																						
ON	V.34 symbol speed 3429 Hz is used.																						
OFF	V.34 symbol speed 3429 Hz is not used.																						
Display	Description																						
ONCE	Responds to the first signal.																						
TWICE	Responds to the second signal.																						
Display	Description																						
5%	Error line rate of 5%																						
10%	Error line rate of 10%																						
15%	Error line rate of 15%																						
20%	Error line rate of 20%																						

Item No.	Description																		
U634	<p>Setting communication control 5</p> <p>Description Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Used as a measure to ease transmission conditions if transmission errors occur.</p> <p>Setting 1. Press the start key. 2. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of allowed error bytes when detecting TCF</td><td>0 to 255</td><td>0</td></tr></table> <p>3. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of allowed error bytes when detecting TCF	0 to 255	0												
Description	Setting range	Initial setting																	
Number of allowed error bytes when detecting TCF	0 to 255	0																	
U640	<p>Setting communication time 1</p> <p>Description Sets the detection time when one-shot detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.) Sets the detection time when continuous detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p>Method 1. Press the start key. 2. Select the item to be set.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>TIME (ONE)</td><td>Sets the one-shot detection time for remote switching.</td></tr><tr><td>TIME (CONT)</td><td>Sets the continuous detection time for remote switching.</td></tr></table> <p>Setting the one-shot detection time for remote switching 1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>One-shot detection time for remote switching</td><td>0 to 255</td><td>7</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Setting the continuous detection time for remote switching 1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Continuous detection time for remote switching</td><td>0 to 255</td><td>80</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	TIME (ONE)	Sets the one-shot detection time for remote switching.	TIME (CONT)	Sets the continuous detection time for remote switching.	Description	Setting range	Initial setting	One-shot detection time for remote switching	0 to 255	7	Description	Setting range	Initial setting	Continuous detection time for remote switching	0 to 255	80
Display	Description																		
TIME (ONE)	Sets the one-shot detection time for remote switching.																		
TIME (CONT)	Sets the continuous detection time for remote switching.																		
Description	Setting range	Initial setting																	
One-shot detection time for remote switching	0 to 255	7																	
Description	Setting range	Initial setting																	
Continuous detection time for remote switching	0 to 255	80																	

Item No.	Description																														
U641	<p>Setting communication time 2</p> <p>Description Sets the time-out time for fax transmission.</p> <p>Purpose To improve transmission performance for international communications mainly.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. <table><tr><th>Display</th><th>Description</th></tr><tr><td>T0 TIME OUT</td><td>Sets the T0 time-out time.</td></tr><tr><td>T1 TIME OUT</td><td>Sets the T1 time-out time.</td></tr><tr><td>T2 TIME OUT</td><td>Sets the T2 time-out time.</td></tr><tr><td>Ta TIME OUT</td><td>Sets the Ta time-out time.</td></tr><tr><td>Tb1 TIME OUT</td><td>Sets the Tb1 time-out time.</td></tr><tr><td>Tb2 TIME OUT</td><td>Sets the Tb2 time-out time.</td></tr><tr><td>Tc TIME OUT</td><td>Sets the Tc time-out time.</td></tr><tr><td>Td TIME OUT</td><td>Sets the Td time-out time.</td></tr></table> <p>Setting the T0 time-out time Sets the time before detecting a CED or DIS signal after a dialing signal is sent. Depending on the quality of the exchange, or when the auto select function is selected at the destination unit, a line can be disconnected. Change the setting to prevent this problem.</p> <ol style="list-style-type: none">1. Change the setting using the cursor left/right keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>T0 time-out time</td><td>30 to 90 s</td><td>56</td></tr></table> <ol style="list-style-type: none">2. Press the start key. The value is set. <p>Setting the T1 time-out time Sets the time before receiving the correct signal after call reception. No change is necessary for this maintenance item.</p> <ol style="list-style-type: none">1. Change the setting using the cursor left/right keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>T1 time-out time</td><td>30 to 90 s</td><td>36</td></tr></table> <ol style="list-style-type: none">2. Press the start key. The value is set.	Display	Description	T0 TIME OUT	Sets the T0 time-out time.	T1 TIME OUT	Sets the T1 time-out time.	T2 TIME OUT	Sets the T2 time-out time.	Ta TIME OUT	Sets the Ta time-out time.	Tb1 TIME OUT	Sets the Tb1 time-out time.	Tb2 TIME OUT	Sets the Tb2 time-out time.	Tc TIME OUT	Sets the Tc time-out time.	Td TIME OUT	Sets the Td time-out time.	Description	Setting range	Initial setting	T0 time-out time	30 to 90 s	56	Description	Setting range	Initial setting	T1 time-out time	30 to 90 s	36
Display	Description																														
T0 TIME OUT	Sets the T0 time-out time.																														
T1 TIME OUT	Sets the T1 time-out time.																														
T2 TIME OUT	Sets the T2 time-out time.																														
Ta TIME OUT	Sets the Ta time-out time.																														
Tb1 TIME OUT	Sets the Tb1 time-out time.																														
Tb2 TIME OUT	Sets the Tb2 time-out time.																														
Tc TIME OUT	Sets the Tc time-out time.																														
Td TIME OUT	Sets the Td time-out time.																														
Description	Setting range	Initial setting																													
T0 time-out time	30 to 90 s	56																													
Description	Setting range	Initial setting																													
T1 time-out time	30 to 90 s	36																													

Item No.	Description																						
U641	<p>Setting the T2 time-out time</p> <p>The T2 time-out time decides the following.</p> <p>From CFR signal output to image data reception</p> <p>From image data reception to the next signal reception</p> <p>In ECM, from RNR signal detection to the next signal reception</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>T2 time-out time</td><td>1 to 255</td><td>69</td><td>100 ms</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Setting the Ta time-out time</p> <p>In the fax/telephone auto select mode, sets the time to continue ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-3). A fax signal is received within the Ta set time, or the fax mode is selected automatically when the time elapses. In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Ta time-out time</td><td>1 to 255</td><td>30</td></tr></table> <p>2. Press the start key. The value is set.</p> <div></div> <p>Figure 1-3-3 Ta/Tb1/Tb2 time-out time</p> <p>Setting the Tb1 time-out time</p> <p>In the fax/telephone auto select mode, sets the time to start sending the ring back tone after receiving a call as a fax machine (see figure 1-3-3). In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Tb1 time-out time</td><td>1 to 255</td><td>20</td><td>100 ms</td></tr></table> <p>2. Press the start key. The value is set.</p>	Description	Setting range	Initial setting	Change in value per step	T2 time-out time	1 to 255	69	100 ms	Description	Setting range	Initial setting	Ta time-out time	1 to 255	30	Description	Setting range	Initial setting	Change in value per step	Tb1 time-out time	1 to 255	20	100 ms
Description	Setting range	Initial setting	Change in value per step																				
T2 time-out time	1 to 255	69	100 ms																				
Description	Setting range	Initial setting																					
Ta time-out time	1 to 255	30																					
Description	Setting range	Initial setting	Change in value per step																				
Tb1 time-out time	1 to 255	20	100 ms																				

Item No.	Description							
U641	Setting the Tb2 time-out time In the fax/telephone auto select mode, sets the time to start ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-3). In the fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. 1. Change the setting using the cursor left/right keys.							
	Description	Setting range	Initial setting	Change in value per step	Tb2 time-out time	1 to 255	80	100 ms
	Description	Setting range	Initial setting	Change in value per step				
	Tb2 time-out time	1 to 255	80	100 ms				
	2. Press the start key. The value is set.							
	Setting the Tc time-out time In the TAD mode, set the time to check if there are any triggers for shifting to fax reception after a connected telephone receives a call. Only the telephone function is available if shifting is not made within the set Tc time. In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.							
	1. Change the setting using the cursor left/right keys.							
	Description	Setting range	Initial setting	Tc time-out time	1 to 255	60		
	Description	Setting range	Initial setting					
	Tc time-out time	1 to 255	60					
2. Press the start key. The value is set.								
Setting the Td time-out time Sets the length of the time required to determine silent status (fax), one of the triggers for Tc time check. In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set it too short; otherwise, the mode may be shifted to fax while the unit is being used as a telephone.								
1. Change the setting using the cursor left/right keys.								
Description	Setting range	Initial setting	Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)			
Description	Setting range	Initial setting						
Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)						
2. Press the start key. The value is set.								
Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.								

Item No.	Description								
U650	<p>Setting modem 1</p> <p>Description Sets the G3 cable equalizer. Sets the modem detection level.</p> <p>Purpose Perform the following adjustment to make the equalizer compatible with the line characteristics. To improve the transmission performance when a low quality line is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>REG. G3 TX EQR</td><td>Sets the G3 transmission cable equalizer.</td></tr> <tr> <td>REG. G3 RX EQR</td><td>Sets the G3 reception cable equalizer.</td></tr> <tr> <td>RX MODEM LEVEL</td><td>Sets the modem detection level.</td></tr> </tbody> </table> <p>Setting the G3 transmission cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB]. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the G3 reception cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB]. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the modem detection level</p> <ol style="list-style-type: none"> 1. Select [33dBm], [38dBm], [43dBm] or [48dBm]. * : Initial setting: 43dBm 2. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	REG. G3 TX EQR	Sets the G3 transmission cable equalizer.	REG. G3 RX EQR	Sets the G3 reception cable equalizer.	RX MODEM LEVEL	Sets the modem detection level.
Display	Description								
REG. G3 TX EQR	Sets the G3 transmission cable equalizer.								
REG. G3 RX EQR	Sets the G3 reception cable equalizer.								
RX MODEM LEVEL	Sets the modem detection level.								

Item No.	Description																
U651	<p>Setting modem 2</p> <p>Description Sets the modem output level. Sets the DTMF output level of a push-button dial telephone.</p> <p>Purpose Used if problems occur when sending a signal with a push-button dial telephone.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set.3. Change the setting using the cursor left/right keys or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>SGL LV MDM</td><td>Modem output level</td><td>1 to 15</td><td>9 (120 V) 10 (220-240 V)</td></tr><tr><td>DTMF LV(C)</td><td>DTMF output level (main value)</td><td>0 to 15.0</td><td>5 (120 V) 10.5 (220-240 V)</td></tr><tr><td>DTMF LV(D)</td><td>DTMF output level (level difference)</td><td>0 to 5.5</td><td>2 (120 V) 2.5 (220-240 V)</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	SGL LV MDM	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)	DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)	DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)
Display	Description	Setting range	Initial setting														
SGL LV MDM	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)														
DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)														
DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)														

Item No.	Description																								
U660	<p>Setting the NCU</p> <p>Description Makes setting regarding the network control unit (NCU).</p> <p>Purpose To be set when installing the facsimile kit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>EXCHANGE</td><td>Sets the connection to PBX/PSTN.</td></tr> <tr> <td>DIAL TONE</td><td>Sets PSTN dial tone detection.</td></tr> <tr> <td>BUSY TONE</td><td>Sets busy tone detection.</td></tr> <tr> <td>PBX SETTING</td><td>Setting for a PBX.</td></tr> <tr> <td>DC LOOP</td><td>Sets the loop current detection before dialing.</td></tr> </tbody> </table> <p>Setting the connection to PBX/PSTN Selects if a fax is to be connected to either a PBX or public switched telephone network.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>PSTN</td><td>Connected to the public switched telephone network.</td></tr> <tr> <td>PBX</td><td>Connected to a PBX.</td></tr> </tbody> </table> <p>* : Initial setting: PSTN</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Setting PSTN dial tone detection Selects if the dial tone is detected to check the telephone is off the hook when a fax is connected to a public switched telephone network.</p> <ol style="list-style-type: none"> 1. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Detects the dial tone.</td></tr> <tr> <td>OFF</td><td>Does not detect the dial tone.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	EXCHANGE	Sets the connection to PBX/PSTN.	DIAL TONE	Sets PSTN dial tone detection.	BUSY TONE	Sets busy tone detection.	PBX SETTING	Setting for a PBX.	DC LOOP	Sets the loop current detection before dialing.	Display	Description	PSTN	Connected to the public switched telephone network.	PBX	Connected to a PBX.	Display	Description	ON	Detects the dial tone.	OFF	Does not detect the dial tone.
Display	Description																								
EXCHANGE	Sets the connection to PBX/PSTN.																								
DIAL TONE	Sets PSTN dial tone detection.																								
BUSY TONE	Sets busy tone detection.																								
PBX SETTING	Setting for a PBX.																								
DC LOOP	Sets the loop current detection before dialing.																								
Display	Description																								
PSTN	Connected to the public switched telephone network.																								
PBX	Connected to a PBX.																								
Display	Description																								
ON	Detects the dial tone.																								
OFF	Does not detect the dial tone.																								

Item No.	Description																				
U660	<p>Setting busy tone detection</p> <p>When a fax signal is sent, sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time. Fax transmission may fail due to incorrect busy tone detection. When set to 2, this problem may be prevented. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="338 495 1401 638"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Detects busy tone.</td></tr> <tr> <td>OFF</td><td>Does not detect busy tone.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p>Setting for a PBX</p> <p>Selects the mode to connect an outside call when connected to a PBX. According to the type of the PBX connected, select the mode to connect an outside call.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="338 898 1401 1090"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>EARTH</td><td>Earth mode</td></tr> <tr> <td>FLASH</td><td>Flashing mode</td></tr> <tr> <td>LOOP</td><td>Code number mode</td></tr> </tbody> </table> <p>* : Initial setting: LOOP</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the loop current detection before dialing</p> <p>Sets if the loop current detection is performed before dialing.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="338 1319 1401 1462"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Performs loop current detection before dialing.</td></tr> <tr> <td>OFF</td><td>Does not perform loop current detection before dialing.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Detects busy tone.	OFF	Does not detect busy tone.	Display	Description	EARTH	Earth mode	FLASH	Flashing mode	LOOP	Code number mode	Display	Description	ON	Performs loop current detection before dialing.	OFF	Does not perform loop current detection before dialing.
Display	Description																				
ON	Detects busy tone.																				
OFF	Does not detect busy tone.																				
Display	Description																				
EARTH	Earth mode																				
FLASH	Flashing mode																				
LOOP	Code number mode																				
Display	Description																				
ON	Performs loop current detection before dialing.																				
OFF	Does not perform loop current detection before dialing.																				

Item No.	Description																				
U670	<p data-bbox="290 241 491 275">Outputting lists</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 877 374">Outputs a list of data regarding fax transmissions.</p> <p data-bbox="290 378 1385 445">Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p data-bbox="290 450 400 479">Purpose</p> <p data-bbox="290 483 1189 512">To check conditions of use, settings and transmission procedures of the fax.</p> <p data-bbox="290 553 387 582">Method</p> <ol data-bbox="308 586 879 685" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output. 3. Press the start key. The selected list is output. <table data-bbox="336 698 1401 1283"> <tr> <th data-bbox="344 707 636 745">Display</th><th data-bbox="636 707 1393 745">Description</th></tr> <tr> <td data-bbox="344 752 636 790">SETTING LIST</td><td data-bbox="636 752 1393 819">Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.</td></tr> <tr> <td data-bbox="344 835 636 873">ACTION LIST</td><td data-bbox="636 835 1393 902">Outputs a list of error history, transmission line details and other information.</td></tr> <tr> <td data-bbox="344 918 636 956">SELF ST REPORT</td><td data-bbox="636 918 1393 985">Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.</td></tr> <tr> <td data-bbox="344 1001 636 1039">PROTOCOL LIST</td><td data-bbox="636 1001 1393 1039">Outputs a list of transmission procedures.</td></tr> <tr> <td data-bbox="344 1055 636 1093">ERROR LIST</td><td data-bbox="636 1055 1393 1093">Outputs a list of error.</td></tr> <tr> <td data-bbox="344 1108 636 1146">ADDR BOOK(No.)</td><td data-bbox="636 1108 1393 1146">Outputs address book in order IDs were added</td></tr> <tr> <td data-bbox="344 1153 636 1191">ADDR BOOK(Name)</td><td data-bbox="636 1153 1393 1191">Outputs address book in order of names</td></tr> <tr> <td data-bbox="344 1198 636 1236">ONE-TOUCH LIST</td><td data-bbox="636 1198 1393 1236">Outputs a list of one-touch.</td></tr> <tr> <td data-bbox="344 1243 636 1281">GROUP LIST</td><td data-bbox="636 1243 1393 1281">Outputs a list of group.</td></tr> </table> <p data-bbox="290 1330 440 1359">Completion</p> <p data-bbox="290 1364 1254 1393">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SETTING LIST	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.	ACTION LIST	Outputs a list of error history, transmission line details and other information.	SELF ST REPORT	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.	PROTOCOL LIST	Outputs a list of transmission procedures.	ERROR LIST	Outputs a list of error.	ADDR BOOK(No.)	Outputs address book in order IDs were added	ADDR BOOK(Name)	Outputs address book in order of names	ONE-TOUCH LIST	Outputs a list of one-touch.	GROUP LIST	Outputs a list of group.
Display	Description																				
SETTING LIST	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.																				
ACTION LIST	Outputs a list of error history, transmission line details and other information.																				
SELF ST REPORT	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.																				
PROTOCOL LIST	Outputs a list of transmission procedures.																				
ERROR LIST	Outputs a list of error.																				
ADDR BOOK(No.)	Outputs address book in order IDs were added																				
ADDR BOOK(Name)	Outputs address book in order of names																				
ONE-TOUCH LIST	Outputs a list of one-touch.																				
GROUP LIST	Outputs a list of group.																				

Item No.	Description																		
U695	<p>FAX function customize</p> <p>Description Sets fax batch transmission ON/OFF. Also changes the print size priority at the time of small size reception.</p> <p>Purpose To be executed as required.</p> <p>Setting 1. Select the setting.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FAX BULK TX</td><td>fax batch transmission ON/OFF</td></tr> <tr> <td>A5 PT PRI CHG</td><td>Change of print size priority at the time of small size reception</td></tr> </tbody> </table> <p>Setting: [FAX BULK TX] 1. Select [ON] or [OFF].</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Fax batch transmission is enabled.</td></tr> <tr> <td>OFF</td><td>Fax batch transmission is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p>Setting: [A5 PT PRI CHG] 1. Select [ON] or [OFF].</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>At the time of A5 size reception: A5→B5→A4</td></tr> <tr> <td>OFF</td><td>At the time of A5 size reception: A5→A4→B5</td></tr> </tbody> </table> <p>* : Initial setting: OFF</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FAX BULK TX	fax batch transmission ON/OFF	A5 PT PRI CHG	Change of print size priority at the time of small size reception	Display	Description	ON	Fax batch transmission is enabled.	OFF	Fax batch transmission is disabled.	Display	Description	ON	At the time of A5 size reception: A5→B5→A4	OFF	At the time of A5 size reception: A5→A4→B5
Display	Description																		
FAX BULK TX	fax batch transmission ON/OFF																		
A5 PT PRI CHG	Change of print size priority at the time of small size reception																		
Display	Description																		
ON	Fax batch transmission is enabled.																		
OFF	Fax batch transmission is disabled.																		
Display	Description																		
ON	At the time of A5 size reception: A5→B5→A4																		
OFF	At the time of A5 size reception: A5→A4→B5																		

Item No.	Description																																														
U699	<p>Setting the software switches</p> <p>Description Sets the software switches on the FAX control PWB individually.</p> <p>Purpose To change the setting when a problem such as split output of received originals occurs. Since the communication performance is largely affected, normally this setting need not be changed.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Press [SW No.].3. Enter the desired software switch number (3 digits) using the numeric keys and press the enter key.4. Use numeric keys 7 to 0 to switch each bit between 0 and 1.5. Press the start key to set the value. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p>List of Software Switches of Which the Setting Can Be Changed</p> <p><Communication control procedure></p> <table><tr><th>No.</th><th>Bit</th><th>Item</th></tr><tr><td rowspan="2">36</td><td>7654</td><td>Coding format in transmission</td></tr><tr><td>3210</td><td>Coding format in reception</td></tr><tr><td rowspan="6">37</td><td>5</td><td>33600 bps/V34</td></tr><tr><td>4</td><td>31200 bps/V34</td></tr><tr><td>3</td><td>28800 bps/V34</td></tr><tr><td>2</td><td>26400 bps/V34</td></tr><tr><td>1</td><td>24000 bps/V34</td></tr><tr><td>0</td><td>21600 bps/V34</td></tr><tr><td rowspan="8">38</td><td>7</td><td>19200 bps/V34</td></tr><tr><td>6</td><td>16800 bps/V34</td></tr><tr><td>5</td><td>14400 bps/V34</td></tr><tr><td>4</td><td>12000 bps/V34</td></tr><tr><td>3</td><td>9600 bps/V34</td></tr><tr><td>2</td><td>7200 bps/V34</td></tr><tr><td>1</td><td>4800 bps/V34</td></tr><tr><td>0</td><td>2400 bps/V34</td></tr><tr><td>41</td><td>3</td><td>FSK detection in V.8</td></tr><tr><td rowspan="2">42</td><td>4</td><td>4800 bps when low-speed setting is active</td></tr><tr><td>2</td><td>FIF length in transmission of more than 4 times of DIS/DTC signal</td></tr></table>	No.	Bit	Item	36	7654	Coding format in transmission	3210	Coding format in reception	37	5	33600 bps/V34	4	31200 bps/V34	3	28800 bps/V34	2	26400 bps/V34	1	24000 bps/V34	0	21600 bps/V34	38	7	19200 bps/V34	6	16800 bps/V34	5	14400 bps/V34	4	12000 bps/V34	3	9600 bps/V34	2	7200 bps/V34	1	4800 bps/V34	0	2400 bps/V34	41	3	FSK detection in V.8	42	4	4800 bps when low-speed setting is active	2	FIF length in transmission of more than 4 times of DIS/DTC signal
No.	Bit	Item																																													
36	7654	Coding format in transmission																																													
	3210	Coding format in reception																																													
37	5	33600 bps/V34																																													
	4	31200 bps/V34																																													
	3	28800 bps/V34																																													
	2	26400 bps/V34																																													
	1	24000 bps/V34																																													
	0	21600 bps/V34																																													
38	7	19200 bps/V34																																													
	6	16800 bps/V34																																													
	5	14400 bps/V34																																													
	4	12000 bps/V34																																													
	3	9600 bps/V34																																													
	2	7200 bps/V34																																													
	1	4800 bps/V34																																													
	0	2400 bps/V34																																													
41	3	FSK detection in V.8																																													
42	4	4800 bps when low-speed setting is active																																													
	2	FIF length in transmission of more than 4 times of DIS/DTC signal																																													

Item No.	Description		
U699	<Communication time setting>		
	No.	Bit	Item
	53	76543210	T3 timeout setting
	54	76543210	T4 timeout setting (automatic equipment)
	55	76543210	T5 timeout setting
	60	76543210	Time before transmission of CNG (1100 Hz) signal
	63	76543210	T0 timeout setting (manual equipment)
	64	7	Phase C timeout in ECM reception
	66	76543210	Timeout 1 in countermeasures against echo
	68	76543210	Timeout for FSK detection start in V.8
	<Modem setting>		
	No.	Bit	Item
	89	76543	RX gain adjust
	<NCU setting>		
	No.	Bit	Item
	121	7654	Dial tone/busy tone detection pattern
	122	7654	Busy tone detection pattern
		1	Busy tone detection in automatic FAX/TEL switching
	125	76543210	Access code registration for connection to PSTN
	126	7654	FAX/TEL automatic switching ringback tone ON/OFF cycle
	<Calling time setting>		
	No.	Bit	Item
	133	76543210	DTMF signal transmission time
	134	76543210	DTMF signal pause time
	141	76543210	Ringer detection cycle (minimum)
	142	76543210	Ringer detection cycle (maximum)
	143	76543210	Ringer ON time detection
	144	76543210	Ringer OFF time detection
	145	76543210	Ringer OFF non-detection time
	147	76543210	Dial tone detection time (continuous tone)
	148	76543210	Allowable dial tone interruption time
	149	76543210	Time for transmitting selection signal after closing the DC circuit
	151	76543210	Ringer frequency detection invalid time

Item No.	Description
U910	<p data-bbox="290 241 651 275">Clearing the black ratio data</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 919 374">Clears the accumulated black ratio data for A4 sheet.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1126 443">To clear data as required at times such as during maintenance service.</p> <p data-bbox="290 486 387 515">Method</p> <ol data-bbox="308 519 1094 618" style="list-style-type: none">1. Press the start key.2. Select [ALL CLEAR].3. Press the start key. The accumulated black ratio data is cleared. <p data-bbox="290 658 440 687">Completion</p> <p data-bbox="290 692 1254 721">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																								
U917	<p>Setting backup data reading/writing</p> <p>Description Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p>Purpose To store and write data when replacing the control PWB.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch.2. Insert USB memory in USB memory slot.3. Turn the main power switch on. Wait for 10 seconds to allow the machine to recognize the USB memory.4. Enter the maintenance item.5. Press the start key.6. Select [Export] or [Import] and press the start key. <table><tr><th>Display</th><th>Description</th></tr><tr><td>IMPORT</td><td>Writing data from the USB memory to the machine</td></tr><tr><td>EXPORT</td><td>Retrieving from the machine to a USB memory</td></tr></table> <p>7. Select the item.</p> <table><tr><th>Display</th><th>Description</th><th>Depending data</th></tr><tr><td>ADDRESS BOOK</td><td>Address book</td><td>-</td></tr><tr><td>JOB ACCNT.</td><td>Job accounting</td><td>-</td></tr><tr><td>ONE TOUCH USER PROGRAM</td><td>Information on one-touch key User managements Program information</td><td>Address book Job accounting Job accountings and user managements</td></tr><tr><td>DOCUMENT BOX</td><td>Document box information</td><td>Job accountings and user managements</td></tr><tr><td>FAX FORWARD</td><td>FAX transfer information</td><td>Job accountings, user managements and document box information</td></tr></table> <p>* : Since data are dependent with each other, data other than those assigned are also retrieved or written in.</p> <ol style="list-style-type: none">8. Select [ON].9. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed.10. When normally completed, [FIN] is displayed.11. Turn the main power switch off and on after completing writing when selecting [IMPORT].	Display	Description	IMPORT	Writing data from the USB memory to the machine	EXPORT	Retrieving from the machine to a USB memory	Display	Description	Depending data	ADDRESS BOOK	Address book	-	JOB ACCNT.	Job accounting	-	ONE TOUCH USER PROGRAM	Information on one-touch key User managements Program information	Address book Job accounting Job accountings and user managements	DOCUMENT BOX	Document box information	Job accountings and user managements	FAX FORWARD	FAX transfer information	Job accountings, user managements and document box information
Display	Description																								
IMPORT	Writing data from the USB memory to the machine																								
EXPORT	Retrieving from the machine to a USB memory																								
Display	Description	Depending data																							
ADDRESS BOOK	Address book	-																							
JOB ACCNT.	Job accounting	-																							
ONE TOUCH USER PROGRAM	Information on one-touch key User managements Program information	Address book Job accounting Job accountings and user managements																							
DOCUMENT BOX	Document box information	Job accountings and user managements																							
FAX FORWARD	FAX transfer information	Job accountings, user managements and document box information																							

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	e002	Parameter error	e31e	User managements error
	e003	File write error	e31f	User managements open error
	e004	File initialization error	e320	User managements error
	e005	File error	e410	Box file open error
	e006	Processing error	e411	Box error in writing
	e010	Address book clear error (contact)	e412	Box error in reading
	e011	Address book open error (contact)	e413	Box list error
	e012	Address book list error (contact)	e414	Box list error
	e013	Address book list error (contact)	e415	Box error
	e014	Address book clear error (group)	e416	Box error
	e015	Address book open error (group)	e417	Box open error
	e016	Address book list error (group)	e418	Box close error
	e017	Address book list error (group)	e419	Box creation error
	e110	Job accounting clear error	e41a	Box creation error
	e111	Job accounting open error	e41b	Box deletion error
	e112	Job accounting open error	e41c	Box movement error
	e113	Job accounting error in writing	e510	Program error in writing
	e114	Job accounting list error	e511	Program error in reading
	e115	Job accounting list error	e710	Fax memory open error
	e210	One-touch open error	e711	Fax memory initialization error
	e211	One-touch list error	e712	Fax memory list error
	e212	One-touch list error	e713	Fax memory error
	e310	User managements backup error	e714	Fax memory error
	e311	User managements clear error	e715	Fax memory mode error
	e312	User managements open error	e716	Fax memory error
	e313	User managements open error	e717	Fax memory error
	e314	User managements open error	e718	Fax memory mode error
	e315	User managements error in writing	e910	File reading error
	e316	User managements list error	e911	File writing error
	e317	User managements list error	e912	Data mismatch
	e318	User managements list error	e913	Log file open error
	e319	User managements list error	e914	Log file error in writing
	e31a	User managements open error	e915	Directory open error
	e31b	User managements error	e916	Directory error in reading
	e31c	User managements error	e917	Synchronization error
	e31d	User managements open error	e918	Synchronization error


Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	d000	Unspecified error	d00b	File reading error
	d001	HDD unavailable	d00c	File writing error
	d002	USB memory is not inserted	d00d	File copy error
	d003	File for writing is not found in the USB	d00e	File compressed error
	d004	File for reading is not found in the HDD	d00f	File decompressed error
	d005	USB error in writing	d010	Directory open error
	d006	USB error in reading	d011	Directory creation error
	d007	USB unmount error	d012	File writing error
	d008	File rename error	d013	File reading error
	d009	File open error	d014	File deletion error
	d00a	File close error	d015	File copy error to the USB
	Supplement The following restrictions apply to the data which were imported from 4 in 1 model (with FAX) to 3 in 1 model (without FAX). Personal address book: FAX-related data are not imported. Group address book: Group addresses including FAX addresses are not imported. Job accounting data: Initial values are added for FAX-related data. One-touch data: Groups assigned with FAX addresses or those including FAX are not imported. User management data: Initial values are added for out-going FAXes of authentication. Program data: Not imported. (The same applies when data are imported from 3 in 1 to 4 in 1 model.)			
	Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.			
U927	Clearing the all copy counts and machine life counts (one time only)			
	Description Resets all of the counts back to zero.			
	Supplement The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.			
	Method 1. Press the start key. 2. Press [EXECUTE]. 3. Press the start key. All copy counts and machine life counts are cleared. [CAN NOT EXECUTE] is displayed if the count cannot be cleared.			
	Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.			

Item No.	Description
U977	<p data-bbox="290 241 533 271">Data capture mode</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 983 374">Store the print data sent to the machine into USB memory.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1211 443">In case to occur the error at printing, check the print data sent to the machine.</p> <p data-bbox="290 483 387 512">Method</p> <ol data-bbox="308 517 823 757" style="list-style-type: none">1. Insert USB memory in USB memory slot.2. Turn the main power switch on.3. Enter the maintenance item.4. Press the start key.5. Select [EXECUTE].6. Press the start key.7. Send the print data to the machine. <p data-bbox="336 761 1150 790">Once the print data is stored into USB memory, OK will be displayed.</p> <p data-bbox="290 831 440 860">Completion</p> <p data-bbox="290 864 1254 893">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

1-3-2 Service mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a service mode



(2) Description of service mode

Service items	Description
Service Status	<p data-bbox="389 293 927 322">Printing a status page for service purpose</p> <p data-bbox="389 360 539 389">Description</p> <p data-bbox="389 394 1422 456">Prints a status page for service purpose. The status page includes various settings and service cumulative.</p> <p data-bbox="389 463 499 492">Purpose</p> <p data-bbox="389 497 1398 526">To acquire the current printing environmental parameters and cumulative information.</p> <p data-bbox="389 566 486 595">Method</p> <ol data-bbox="405 600 743 701" style="list-style-type: none">1. Select [Service status].2. Select [YES]. Two pages will be printed. <p data-bbox="389 741 539 770">Completion</p> <p data-bbox="389 775 831 804">Press the System Menu/Counter key.</p>

Service items	Description
	<div><div>Service status page (1)</div><div><div>Service Status Page</div><div>MFP</div><div>(2)08/03/2011 12:00</div><div>(1)Firmware version 2MD_2F00.001.020 2011.02.24</div><div>(3)[XXXXXXXX] (4)[XXXXXXXX] (5)[XXXXXXXX]</div><div>Controller Information</div><div><div>Memory status</div><div>(7)Standard Size128.0 KB</div><div>(8)Option Slot128.0 KB</div><div>(9)Total Size256.0 KB</div><div>Time</div><div>(10)Local Time Zone+01:00 Tokio</div><div>(11)Date and Time06/04/2010 12:00</div><div>(12)Time Server10.183.53.13</div><div>Installed Options</div><div>(13)Paper FeederCassette</div><div>(14)Memory CardNot Installed</div><div>(15)Card Authentication Kit (B)Not Installed</div><div>(16)USB KeyboardConnected</div><div>(17)USB Keyboard TypeUS-English</div><div>Print Coverage</div><div>(18)Average(%) / Usage Page(A4/Letter Conversion)</div><div>(19)Total</div><div>K: 1.10 / 1111111.11</div><div>(20)Copy</div><div>K: 1.10 / 1111111.11</div><div>(21)Printer</div><div>K: 1.10 / 1111111.11</div><div>(22)FAX</div><div>K: 1.10 / 1111111.11</div><div>(23)Period(27/10/2009 - 03/11/2009 08:40)</div><div>(24)Last Page (%)1.00</div><div>PDF modeY500</div><div>FAX Information</div><div>(25)Rings (Normal)3</div><div>(26)Rings (FAX/TEL)3</div><div>(27)Rings (TAD)3</div></div></div></div> <div>1</div> <div>(6)[XXXXXXXXXXXXXXXXXXXX]</div>

Figure 1-3-4

Figure 1-3-4

Service items	Description
	Service status page (2)

Service Status Page

MFP

Firmware version 2MD_2F00.001.020 2011.02.24

08/03/2011 12:00

[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]

Engine Information

(29) NVRAM Version _1F31255_1F31255

(30) Scanner Version 2MD_1200.001.089

(31) FAX Slot1

 FAX BOOT Version 2KX_5000.001.001

 FAX APL Version 2KX_5100.001.001

 FAX IPL Version 2KX_5200.001.001

(32) MAC Address 00:C0:EE:D0:01:0D

(33) DP Counters

 Total 1234

Send Information

(34) Date and Time 10/06/30 15:30

(35) Address

1/2 (36) (37)

(38) 100/100

(39) 0/0/0/0/0/0/

(40) 0/0/0/0/0/0/

(41) 0/0/0/0/0/0/0/

(42) 0000000/0000000/0000000/0000000/0000000/0000000/0000000/0000000/

 0000000/

 F00/U00/0/0/0/30/30/70/70/00/abcde/1/0 (43) (44) (45) (46) (47) (48) (49) (50) (51) (52) (53) (54) (55)

(56) 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/

 0000/0000/0000/0000/0000/0000/0000/0000/0000/

(57) 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07

 2MD_D100.001.005/t/(58) (59)

(60) [ABCDEFGHJIJ/] [ABCDEFGHJIJ/] [ABCDEFGHJIJ/]

(61) [ABCDEFGHJIJ/]

(62) 0000000000/F80C001A37/302A183C00/000100013D/8791BEC305/0000003100/000F5D0000/01FD000000/

 0000000FB7/0000000000/0000260000/0000000000/0000000000/0000008400/0000000000/011E000F51/00000073

 ABCD/ABCDEFGHJIJ (63) (64)

2

[XXXXXXXXXXXXXXXXXXXX]

Figure 1-3-5

Service items	Description	
	Detail of service status page	
	No.	Description
		Supplement
	(1)	Firmware version -
	(2)	System date -
	(3)	Engine soft version -
	(4)	Engine boot version -
	(5)	Operation panel mask version -
	(6)	Machine serial number -
	(7)	Standard memory size -
	(8)	Optional memory size -
	(9)	Total memory size -
	(10)	Local time zone -
	(11)	Report output date -
	(12)	NTP server name -
	(13)	Presence or absence of the optional paper feeder Paper feeder 2/Paper feeder 3/Paper feeder 4
	(14)	Presence or absence of the optional memory card -
	(15)	Presence or absence of the card authentication kit (B) -
	(16)	Presence or absence of the USB Keyboard Connected/Not Connected
	(17)	Type of the USB Keyboard US-English/US-English with Euro
	(18)	Page of relation to the A4/Letter -
	(19)	Average coverage for total -
	(20)	Average coverage for copy -
	(21)	Average coverage for printer -
	(22)	Average coverage for fax -
	(23)	Cleared date and output date -
	(24)	Coverage on the final output page -
	(25)	Number of rings 0 to 15
	(26)	Number of rings before auto-automatic switching 0 to 15
	(27)	Number of rings before connecting to answering machine 0 to 15
	(28)	FRPO setting -

Service items	Description	
	No.	Description
	Description	Supplement
	(29)	NV RAM version
		_ 1F3 1225 _ 1F3 1225 (a) (b) (c) (d) (e) (f) (a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME database version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).
	(30)	Scanner firmware version
	(31)	Fax firmware version
	(32)	Mac address
	(33)	Number of original feed from DP
	(34)	The last sent date and time
	(35)	Transmission address
	(36)	Destination information
	(37)	Area information
	(38)	Margin settings
	(39)	Top offset setting
	(40)	Left offset setting
	(41)	Margin/Page length/Page width settings
	(42)	Life counter (The first line)
		Life counter (The second line)
	(43)	Panel lock information
	(44)	USB information
	(45)	Paper handling information

Service items	Description																													
	No.	Description	Supplement																											
	(46)	Black and white printing double count mode	0: All single counts 3: Folio, Single count, Less than 330 mm (length)																											
	(47)	Billing counting timing	-																											
	(48)	Temperature (machine inside)	-																											
	(49)	Temperature (machine outside)	-																											
	(50)	Relative temperature (machine outside)	-																											
	(51)	Absolute temperature (machineoutside)	-																											
	(52)	LXI calibration information	-																											
	(53)	Fixed assets number	-																											
	(54)	Job end judgment time-out time	-																											
	(55)	Job end detection mode	-																											
	(56)	Media type attributes 1 to 28 (Not used: 18, 19, 20)	Weight settings 0: Light/1: Normal 1 / 2: Normal 2 / 3: Normal 3/ 4: Heavy 1 / 5: Heavy 2 / 6: Heavy 3 / 7: Extra Heavy Fuser settings 0: High / 1: Middle / 2: Low / 3: Vellum Duplex settings 0: Disable / 1: Enable																											
	(57)	RFID information	-																											
	(58)	RFID reader/writer version information	-																											
	(59)	Toner installation mode information	-																											
	(60)	Soft version of the optional paper feeder	-																											
	(61)	Version of the optional message	-																											
	(62)	Maintenance information	-																											
	(63)	Durm ID	-																											
	(64)	Drum serial number	-																											
	Code conversion																													
	<table><tr><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td><td>I</td><td>J</td></tr><tr><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr></table>										A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J																					
0	1	2	3	4	5	6	7	8	9																					

Service items	Description
Network Status	<p>Printing a status page for network</p> <p>Description Prints a status page for network.</p> <p>Purpose To acquire the detailed network setting information.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Network Status]. 3. Press the start key. 4. Press [Yes] (the Left Select key). Network status page will be printed. <p>Completion Press the stop key.</p>
New Developer	<p>Performing toner install</p> <p>Description Replenishes toner rapidly from the toner container into the developing unit.</p> <p>Purpose Perform the developer refreshing when the destiny is light or the faint of dark part occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [New Developer]. 3. Press the start key. 4. Press [Yes] (the Left Select key). Toner install mode is performed. <p>Completion Press the stop key.</p>

Service items	Description								
Auto DrumRefresh	<p>Automatic drum refreshing</p> <p>Description Sets the specify the duration of automatic drum refreshing.</p> <p>Purpose To prevent bleeding of the output image when operating environment is one of high humidity.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Auto DrumRefresh]. 3. Press the start key. 4. Select the setting. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>OFF</td><td>Disables automatic drum refreshing</td></tr> <tr> <td>Standard</td><td>Sets the standard duration for automatic drum refreshing (maximum 140 s)</td></tr> <tr> <td>Long</td><td>Sets a longer time for automatic drum refreshing (maximum 180 s)</td></tr> </tbody> </table> <ol style="list-style-type: none"> 5. Press the start key. The setting is set. <p>Completion Press the stop key.</p>	Display	Description	OFF	Disables automatic drum refreshing	Standard	Sets the standard duration for automatic drum refreshing (maximum 140 s)	Long	Sets a longer time for automatic drum refreshing (maximum 180 s)
Display	Description								
OFF	Disables automatic drum refreshing								
Standard	Sets the standard duration for automatic drum refreshing (maximum 140 s)								
Long	Sets a longer time for automatic drum refreshing (maximum 180 s)								
Drum Refresh	<p>Performing drum refreshing</p> <p>Description To perform drum refreshing.</p> <p>Purpose To clean the drum surface when image failure occurs due to the drum. This mode is effective when dew condensation on the drum occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Drum Refresh]. 3. Press the start key. 4. Press [Yes] (the Left Select key). Drum refresh is performed. <p>Completion Press the stop key.</p>								

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfeed in the machine, pull out the paper cassette, pull out the rear unit, remove the developing unit or open the duplex cover.

(2) Paper misfeed detection condition




Figure 1-4-1

Section	Code	Conditions	Jam location
Machine	0010	Paper does not arrive at the registration sensor (RS) within specified time from start of paper feed (paper feed from MP tray).	A
		Paper does not arrive at the registration sensor (RS) within specified time from start of paper feed (paper feed from cassette).	B
		Paper does not arrive at the registration sensor (RS) within specified time of PF paper feed sensor turning on (paper feed from paper feeder).	B
		Paper does not arrive at the registration sensor (RS) within specified time from start of paper switchback (duplex refeeding).	G
	0011	Paper does not pass the registration sensor (RS) within specified time from start of secondary paper feed.	F
	0012	Paper remains at the registration sensor (RS) when power is turned on.	F
	0020	Paper does not arrive at the eject sensor (ES) within specified time from start of secondary paper feed.	F
	0021	Paper does not pass the eject sensor (ES) within specified time of the registration sensor (RS) turning off.	H
	0022	Paper remains at the eject sensor (ES) when power is turned on.	H
	00A1	Paper does not arrive at the duplex sensor (DUS) within specified time from start of paper switchback.	H
	00A2	Paper does not pass the duplex sensor (DUS) within specified time of the duplex sensor (DUS) turning on.	H
	00A3	Paper does not arrive at the duplex jam sensor (DUJS) within specified time of the duplex sensor (DUS) turning on.	G
	00A4	Paper does not pass the duplex jam sensor (DUJS) within specified time from start of secondary paper feed (duplex refeeding).	G
	00A5	Paper remains at the duplex sensor (DUS) or the duplex jam sensor (DUJS) when power is turned on.	G
	00E0	Paper misfeed occurs due to forced stop when an error occurs during printing.	-
	00F0	Paper does not arrive at the paper full sensor (PFS) within specified time of the eject sensor (ES) turning on.	H
	00F1	Paper misfeed by system error.	-
	00F2	Paper misfeed by system error.	-

*: Refer to figure 1-4-2 for paper jam location (see page 1-4-1)

Section	Code	Conditions	Jam location
Paper feeder	0030	Paper does not arrive at the PF paper feed sensor 1 within specified time from start of paper feed (paper feed from paper feeder 1).	C
		Paper does not arrive at the PF paper feed sensor 1 within specified time of the PF paper feed sensor 2 turning on (paper feed from paper feeder 2).	C
		Paper does not arrive at the PF paper feed sensor 1 within specified time of the PF paper feed sensor 3 turning on (paper feed from paper feeder 3).	C
	0031	Paper does not pass the PF paper feed sensor 1 within specified time of the PF paper feed sensor 1 turning on.	C
	0032	Paper remains at the PF paper feed sensor 1 when power is turned on.	C
	0040	Paper does not arrive at the PF paper feed sensor 2 within specified time from start of paper feed (paper feed from paper feeder 2).	D
		Paper does not arrive at the PF paper feed sensor 2 within specified time of the PF paper feed sensor 3 turning on (paper feed from paper feeder 3).	D
	0041	Paper does not pass the PF paper feed sensor 2 within specified time of the PF paper feed sensor 2 turning on.	D
	0042	Paper remains at the PF paper feed sensor 2 when power is turned on.	D
	0050	Paper does not arrive at the PF paper feed sensor 3 within specified time from start of paper feed (paper feed from paper feeder 3).	E
	0051	Paper does not pass the PF paper feed sensor 3 within specified time of the PF paper feed sensor 3 turning on.	E
	0052	Paper remains at the PF paper feed sensor 3 when power is turned on.	E
Document processor	9000	The DP timing sensor (DPTS) does not turn on within specified time during the first sheet feeding (Retry 5 times).	I
	9001	DP timing sensor (DPTS) turns off within the specified time since the sensor turns on.	I
	9003	During duplex switchback scanning, the DP timing sensor (DPTS) does not turn off within specified time.	I
	9004	During duplex switchback scanning, the DP timing sensor (DPTS) does not turn on within specified time since original switchback operation starts.	I
	9011	The DP or DP top cover is opened during original feeding.	I
	9401	The DP timing sensor (DPTS) does not turn off within specified time of the DP timing sensor (DPTS) turning on.	I

*: Refer to figure 1-4-2 for paper jam location (see page 1-4-1)

1-4-2 Self-diagnostic function

(1) Self-diagnostic function

This machine is equipped with self-diagnostic function. When a problem is detected, the machine stops printing and display an error message on the operation panel. An error message consists of a message prompting a contact to service personnel, total print count, and a four-digit error code indicating the type of the error.

(The display varies depending on the type of the error.)




Figure 1-4-2

(2) Self diagnostic codes


Code	Contents	Causes	Check procedures/ corrective measures
0030	FAX control PWB system error Processing with the fax software was disabled due to a hardware problem.	Defective FAX control PWB.	Replace the fax control PWB and check for correct operation. (see page 1-5-43).
0070	FAX control PWB incompatible detection error Abnormal detection of FAX control PWB incompatibility In the initial communication with the FAX control PWB, any normal communication command is not transmitted.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the fax control PWB and check for correct operation. (see page 1-5-43).
0100	Backup memory device error	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-35).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
0120	MAC address data error For data in which the MAC address is invalid.	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-35).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
0130	Backup memory read/write error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-35).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
0140	Backup memory data error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-35).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
0150	Engine PWB EEPROM error Detecting engine PWB EEPROM communication error.	Improper installation engine PWB EEPROM.	Check the installation of the EEPROM and remedy if necessary.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
		Device damage of EEPROM.	Contact the Service Administrative Division.
0170	Billing counting error A checksum error is detected in the main and engine backup memories for the billing counters.	Data damage of EEPROM.	Contact the Service Administrative Division.
		Defective PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-35).

Code	Contents	Causes	Check procedures/ corrective measures
0180	Machine number mismatch Machine number of main and engine does not match.	Data damage of EEPROM.	Contact the Service Administrative Division.
0420	Paper feeder communication error Communication error between engine PWB and optional paper feeder.	Improper installation paper feeder.	Follow installation instruction carefully again.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Paper feeder interface and connect-L PWB (YC2) Connect-L PWB (YC6) and engine PWB (YC504)
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
0830	FAX control PWB flash program area checksum error A checksum error occurred with the program of the FAX control PWB.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the FAX control PWB (see page 1-5-43).
0840	Faults of RTC The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed.	The battery is disconnected from the main PWB.	Check visually and remedy if necessary
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
0870	FAX control PWB to main PWB high capacity data transfer error High-capacity data transfer between the FAX control PWB and the main PWB of the machine was not normally performed even if the data transfer was retried the specified times.	Improper installation FAX control PWB.	Reinstall the FAX control PWB (see page 1-5-43).
		Defective FAX control PWB or main PWB.	Replace the FAX control PWB or main PWB and check for correct operation (see page 1-5-43 or 1-5-35).
0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the FAX control PWB.	Defective FAX control PWB.	Replace the FAX control PWB and check for correct operation (see page 1-5-43).

Code	Contents	Causes	Check procedures/ corrective measures
1010	Lift motor error During driving the lift motor, a motor overcurrent signal is detected for 5 s. This error is detected five times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair it if any problem is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Lift motor and connect-R PWB (YC8) Connect-R PWB (YC2) and engine PWB (YC502)
		Defective drive transmission system of the lift motor.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective lift motor.	Replace the lift motor
		Defective engine PWB or connect-R PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
2000	Main motor steady-state error The main motor ready input is not given for 2 s during the main motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Main motor and engine PWB (YC501)
		Defective drive transmission system of the main motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective main motor.	Replace the main motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
2200	Drum motor steady-state error The drum motor ready input is not given for 2 s during the drum motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Drum motor and engine PWB (YC11)
		Defective drive transmission system of the drum motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective drum motor.	Replace the drum motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).

Code	Contents	Causes	Check procedures/ corrective measures
3100	ISU home position error The home position is not correct when the power is turned on or at the start of copying using the table.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Home position sensor and CCD PWB (YC3) CCD PWB (YC2) and main PWB (YC8) ISU motor and main PWB (YC1004)
		Defective home position sensor.	Replace the home position sensor.
		Defective ISU motor.	Replace the ISU motor.
		Defective CCD PWB.	Replace the scanner unit (see page 1-5-26).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
3200	Exposure lamp error When input value at the time of exposure lamp illumination does not exceed the threshold value between 5 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. LED PWB (YC1) and LED drive PWB (YC2) LED drive PWB (YC1) and CCD PWB (YC3) CCD PWB (YC2) and main PWB (YC8)
		Defective exposure lamp or LED drive PWB.	Replace the scanner unit (see page 1-5-19).
		Defective CCD PWB.	Replace the scanner unit (see page 1-5-19).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-34).
3500	Communication error between scanner and ASIC An error code is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. CCD PWB (YC2) and main PWB (YC8)
		Defective CCD PWB.	Replace the scanner unit (see page 1-5-26).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
4000	Polygon motor synchronization error The polygon motor ready input is not given for 10 s during the polygon motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Laser scanner unit and main PWB (YC14)
		Defective polygon motor.	Replace the laser scanner unit (see page 1-5-16).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).

Code	Contents	Causes	Check procedures/ corrective measures
4200	BD steady-state error	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Laser scanner unit and main PWB (YC16)
		Defective laser scanner unit.	Replace the laser scanner unit (see page 1-5-16).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
4700	VIDEO ASIC device error Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Main PWB (YC13) and engine PWB (YC12)
		Defective main PWB or engine PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-35, 1-5-31).
5100	Main charger high-voltage error Five pages have been printed with the main charger output short-circuited.	Drum unit installed incorrectly.	Verify harness is not pinched.
		Engine PWB installed incorrectly.	Verify harness is not pinched.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
6000	Broken fuser heater wire The temperature does not reach 100°C/212°F after the fuser heater has been turned on continuously for 30 s. The temperature does not rise by 1°C/1.8°F after the fuser heater lamp has been turned on continuously for 15 s during warm-up or at standby.(Only when the detection temperature is less than 200°C.)	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Fuser heater and power source PWB (YC102) Fuser unit and engine PWB (YC506)
		Deformed connector pin.	See page 1-4-10.
		Defective triac.	See page 1-4-10.
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-30).
		Broken fuser heater wire.	Replace the fuser unit (see page 1-5-30).
6020	Abnormally high fuser thermistor 2 temperature The temperature of the fuser thermistor 2 detects 250°C/482°F or more continuously for 3 s.	Shorted fuser thermistor 2.	Replace the fuser unit (see page 1-5-30).
		Deformed connector pin.	See page 1-4-10.
		Defective triac.	See page 1-4-10.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).

Code	Contents	Causes	Check procedures/ corrective measures
6030	Broken fuser thermistor 2 wire average AD value input from fuser thermistor 2 for 1.8 seconds is less than one. (Only when the detection temperature is 50°C or more.)	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Fuser unit and engine PWB (YC506)
		Deformed connector pin.	See page 1-4-10.
		Defective triac.	See page 1-4-10.
		Broken fuser thermistor 2 wire.	Replace the fuser unit (see page 1-5-30).
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-30).
		Broken fuser heater wire.	Replace the fuser unit (see page 1-5-30).
6000/ 6020/ 6030 Com- bined	Broken fuser heater wire Abnormally high fuser thermistor temperature Broken fuser thermistor wire	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective triac.	Remove the power cord and check that the resistance between terminals T1 and T2 of the triac TRA51 is of several Mega-Ohms and not shorted (see figure 1-4-4). If failed, replace the power source PWB (see page 1-5-38).
		<div></div> <p>Figure 1-4-3</p>	
6220	Abnormally high fuser thermistor 1 temperature The temperature of the fuser thermistor 1 detects 255°C/491°F or more continuously for 3 s.	Shorted fuser thermistor 1.	Replace the fuser unit (see page 1-5-30).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).

Code	Contents	Causes	Check procedures/ corrective measures
6230	Broken fuser thermistor 1 wire average AD value input from fuser thermistor 1 for 1.8 seconds is less than one.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Fuser unit and engine PWB (YC506)
		Broken fuser thermistor 1 wire.	Replace the fuser unit (see page 1-5-30).
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-30).
		Broken fuser heater wire.	Replace the fuser unit (see page 1-5-30).
6400	Zero-cross signal error The zero-cross signal does not reach the engine PWB for more than 2 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Power source PWB (YC103) and connect-L PWB (YC1) Connect-L PWB (YC8) and engine PWB (YC503)
		Defective power source PWB.	Replace the power source PWB and check for correct operation (see page 1-5-38).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
7000	Toner motor lock error During driving the toner motor, a motor overcurrent signal is detected for 5 s.	Lump of toner inside toner container.	Replace the toner container.
		Defective drive transmission system of the toner motor.	Replace the developing unit (see page 1-5-26).
		Defective toner motor.	Replace the developing unit (see page 1-5-26).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
7410	Drum unit non- installing error The drum unit is not installed or not installed properly. The drum PWB EEPROM does not communicate normally.	The drum unit is not installed.	Install the drum unit (see page 1-5-27).
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Drum PWB (YC1) and connect-L PWB (YC3)
		Defective drum PWB EEPROM.	Replace the drum unit (see page 1-5-27).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).

Code	Contents	Causes	Check procedures/ corrective measures
9500	BRU communication error	IPU PWB error	Contact the Service Administrative Division.
9510	BRU PWB error		
9520	BRU PWB data error		
F000	Main PWB - operation panel PWB communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB.
		Defective operation panel PWB.	Replace the operation panel PWB.
F010	Main PWB checksum error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-30).
F020	Main PWB RAM checksum error	Defective main memory (RAM) on the main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB.
		Defective expanded memory (DIMM).	Replace the expanded memory (DIMM).
F040	Main PWB - engine PWB communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB.
		Defective engine PWB.	Replace the engine PWB.
F041	Main PWB - scanner communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB.
F050	Engine ROM checksum error	Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
F051	Scan engine ROM checksum error	Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).

1-4-3 Image formation problems

(1) Completely blank printout.




see page 1-4-14

(2) All-black print-out.




see page 1-4-15

(3) Dropouts.




see page 1-4-16

(4) Black dots.




see page 1-4-16

(5) Black horizontal streaks.




see page 1-4-16

(6) Black vertical streaks.




see page 1-4-17

(7) Unsharpness.




see page 1-4-17

(8) Gray background.




see page 1-4-17

(9) Dirt on the top edge or back of the paper.






see page 1-4-18

(10) Undulated printing at the right edge (scanning start position).





see page 1-4-18


(1) Completely blank printout.

Print example	Causes		Check procedures/corrective measures
	Defective transfer bias output.	Poor contact of engine PWB's transfer bias output terminal and machine's contact (spring).	Check the installation position of the engine PWB. Refer to figure 1-4-4 below.
		 <p style="text-align: center;">Figure 1-4-4</p>	
	Defective developing bias output.	Defective engine PWB.	Replace the engine PWB (See page 1-5-31).
		Poor contact of engine PWB's developing bias output terminal and machine's contact (spring).	Check the installation position of the engine PWB. Refer to figure 1-4-4 above.
		Poor contact of machine's developing bias output terminal and developing unit's contact.	Check the installation of the developing unit. Refer to figure 1-4-5 below.
	No LSU laser is output.	 <p style="text-align: center;">Figure 1-4-5</p>	
		Defective engine PWB.	Replace the engine PWB (See page 1-5-31).
		Defective laser scanner unit.	Replace the laser scanner unit (See page 1-5-16).
		Defective main PWB.	Replace the main PWB (See page 1-5-35).


(2) All-black printout.

Print example		Causes	Check procedures/corrective measures
	No main charging.	Defective main charger unit.	Replace the main charger unit (See page 1-5-27).
		Poor contact of engine PWB's main charger output terminal and machine's contact (spring).	Check the installation position of the engine PWB. See page 1-4-14, refer to figure 1-4-4.
		Poor contact of machine's main charger output terminal and main charger unit's contact (spring).	Check the installation of the drum (main charger) unit. Refer to figure 1-4-6 below.
		 <p style="text-align: center;">Figure 1-4-6</p>	
		Defective engine PWB.	Replace the engine PWB (See page 1-5-31).


(3) Dropouts.

Print example	Causes	Check procedures/corrective measures
	Defective developing roller (developing unit).	If the defects occur at regular intervals of 39 mm/1 9/16" (see page 2-4-4), the problem may be the damaged developing roller (in the developing unit). Replace the developing unit (see page 1-5-26).
	Defective drum unit.	If the defects occur at regular intervals of 94 mm/3 11/16" (see page 2-4-4), the problem may be the damaged drum (in the drum unit). Replace the drum unit (see page 1-5-27).
	Defective fuser unit (heat roller or press roller).	If the defects occur at regular intervals of 82 mm/3 1/4", or 93 mm/3 11/16" (see page 2-4-4), the problem may be the damaged heat roller or press roller (in the fuser unit). Replace fuser unit (see page 1-5-30).
	Defective paper specifications.	Paper with rugged surface or dump tends to cause dropouts. Replace paper with the one that satisfies the paper specifications.
	Defective transfer roller installation.	The transfer roller must be supported by the bushes at the both ends. Clean the bush to remove oil and debris. Replace the transfer roller if necessary (see page 1-5-28).
	Defective transfer bias output.	Replace the engine PWB (see page 1-5-31).


(4) Black dots.

Print example	Causes	Check procedures/corrective measures
	Defective drum unit or developing unit.	If the defects occur at regular intervals of 94 mm/3 11/16" (see page 2-4-4), the problem may be the damaged drum (in the drum unit). Replace drum unit (see page 1-5-26). If the defects occur at random intervals, the toner may be leaking from the developing unit or drum unit. Replace the developing unit or drum unit (see page 1-5-26 or 1-5-27).


(5) Black horizontal streaks.

Print example	Causes	Check procedures/corrective measures
	Defective drum unit's ground.	Defective drum unit's ground. The contact (spring) in the drum unit and its counter part, the drum grounding terminal in the printer, must be in a good contact. See page 1-4-14, refer to figure 1-4-4
	Defective drum unit.	Replace the drum unit (see page 1-5-27).


(6) Black vertical streaks.

Print example	Causes	Check procedures/corrective measures
	Flawed main charger roller	Replace the main charger unit (see page 1-5-27).
	Defective drum unit.	A streak of toner remaining on drum after printing means that the cleaning blade (in the drum unit) is not working properly. Replace the drum unit (see page 1-5-27).
	Defective developing roller (developing unit).	Replace the developing unit (see page 1-5-26).


(7) Unsharpness.

Print example	Causes	Check procedures/corrective measures
	Defective paper specifications.	Replace paper with the one that satisfies the paper specification.
	Defective transfer roller installation.	The transfer roller must be supported by the bushes at the both ends. Clean the bush to remove oil and debris. Replace the transfer roller if necessary (see page 1-5-28).
	Poor contact of engine PWB's transfer bias output terminal and machine's contact (spring).	Check the installation position of the engine PWB. See page 1-4-14, refer to figure 1-4-4.
	EcoPrint mode setting.	The EcoPrint mode can provides faint, unsharp printing because it acts to conserve toner for draft printing purpose. For normal printing, turn the EcoPrint mode off by using the operator panel. For details, refer to the operation guide.


(8) Gray background.

Print example	Causes	Check procedures/corrective measures
	Print density setting.	The print density may be set too high. Try adjusting the print density. For details, refer to the operation guide.
	Defective potential on the drum surface.	Replace the drum unit (see page 1-5-27).
	Defective main charger unit.	Replace the main charger unit (see page 1-5-27).
	Defective developing roller (developing unit).	Replace the developing unit (see page 1-5-26).

(9) Dirt on the top edge or back of the paper.

Print example	Causes	Check procedures/corrective measures
	Toner contamination in various parts.	Dirty edges and back of the paper can be caused by toner accumulated on such parts as the paper chute guide, paper conveying paths, the bottom of the drum and developing unit, and the fuser unit inlet. Clean these areas and parts to remove toner.
	Defective transfer roller.	If the transfer roller is contaminated with toner, clean the transfer roller using a vacuum cleaner or by continuously printing a low density page until the symptom has faded away.

(10) Undulated printing at the right edge (scanning start position).

Print example	Causes	Check procedures/corrective measures
	Defective polygon motor (laser scanner unit).	Replace the laser scanner unit (see page 1-5-16).
	Defective main PWB.	Replace the main PWB (see page 1-5-35).

1-4-4 Electric problems

Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the main power switch is turned on.	1. No electricity at the power outlet.	Measure the input voltage.
	2. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	3. The top cover is not closed completely.	Check the top cover.
	4. Broken power cord.	Check for continuity. If none, replace the cord.
	5. Defective main power switch.	Check for continuity across the contacts. If none, replace the power source PWB (see page 1-5-38).
	6. Defective interlock switch.	Check for continuity across the contacts of interlock switch. If none, replace the power source PWB (see page 1-5-38).
	7. Defective power source PWB.	Replace the power source PWB (see page 1-5-38).
(2) Switchback motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Switchback motor and connect-R PWB (YC3) Connect-R PWB (YC1) and engine PWB (YC9)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the switchback motor.
	4. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(3) Toner motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Toner motor and developing PWB (YC2) Developing PWB (YC1) and connect-L PWB (YC9) Connect-L PWB (YC8) and engine PWB (YC503)
	2. Defective motor.	Replace the toner motor.
	3. Defective PWB.	Replace the engine PWB or connect-L PWB and check for correct operation (see page 1-5-31).

Problem	Causes	Check procedures/corrective measures
(4) Right fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Right fan motor and connect-R PWB (YC11) Connect-R PWB (YC1) and engine PWB (YC9)
	2. Defective motor.	Replace the right fan motor.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(5) Left fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Left fan motor and connect-L PWB (YC4) Connect-L PWB (YC6) and engine PWB (YC504)
	2. Defective motor.	Replace the left fan motor.
	3. Defective PWB.	Replace the engine PWB or connect-L PWB and check for correct operation (see page 1-5-31).
(6) Power source fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Power source fan motor and connect-L PWB (YC11) Connect-L PWB (YC8) and engine PWB (YC503)
	2. Defective motor.	Replace the power source fan motor.
	3. Defective PWB.	Replace the engine PWB or connect-L PWB and check for correct operation (see page 1-5-31).
(7) Feed fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Feed fan motor and engine PWB (YC15)
	2. Defective motor.	Replace the feed fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
(8) Eject fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Eject fan motor and connect-R PWB (YC13) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective motor.	Replace the eject fan motor.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(9) Controller fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Controller fan motor and main PWB (YC41)
	2. Defective motor.	Replace the controller fan motor.
	3. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).

Problem	Causes	Check procedures/corrective measures
(10) ISU motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. ISU motor and main PWB (YC1004)
	2. Defective drive transmission system.	Check if the gears rotate smoothly. If not, grease the gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the ISU motor.
	4. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-35).
(11) Paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Paper feed clutch and connect-R PWB (YC5) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective clutch.	Replace the paper feed clutch.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(12) Registration clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Registration clutch and connect-R PWB (YC6) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective clutch.	Replace the registration clutch.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(13) Middle clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Middle clutch and connect-R PWB (YC7) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective clutch.	Replace the middle clutch.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(14) Duplex clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Duplex clutch and connect-R PWB (YC9) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective clutch.	Replace the duplex clutch.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(15) MP solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. MP solenoid and connect-R PWB (YC10) Connect-R PWB (YC1) and engine PWB (YC9)
	2. Defective solenoid.	Replace the MP solenoid.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).

Problem	Causes	Check procedures/corrective measures
(16) Developing solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Developing solenoid and connect-R PWB (YC4) Connect-R PWB (YC2) and engine PWB (YC502)
	2. Defective solenoid.	Replace the developing solenoid.
	3. Defective PWB.	Replace the engine PWB or connect-R PWB and check for correct operation (see page 1-5-31).
(17) Feedshift solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Feedshift solenoid and engine PWB (YC506)
	2. Defective solenoid.	Replace the feedshift solenoid.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
(18) Cleaning lamp does not turn on.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Cleaning lamp and drum PWB (YC2) Drum PWB (YC1) and connect-L PWB (YC3) Connect-L PWB (YC6) and engine PWB (YC504)
	2. Defective cleaning lamp.	Replace the cleaning lamp.
	3. Defective PWB.	Replace the engine PWB or connect-L PWB and check for correct operation (see page 1-5-31).
(19) The message requesting paper to be loaded is shown when paper is present on the cassette.	1. Deformed actuator of the paper sensor.	Check visually and remedy or replace if necessary.
	2. Defective paper sensor.	Replace the engine PWB and check for correct operation (see page 1-5-31).
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-31).
(20) The message requesting paper to be loaded is shown when paper is present on the MP tray.	1. Deformed actuator of the MP paper sensor.	Check visually and remedy or replace if necessary.
	2. Defective MP paper sensor.	Replace the power source PWB and check for correct operation (see page 1-5-38).
	3. Defective PWB.	Replace the power source PWB and check for correct operation (see page 1-5-38).

Problem	Causes	Check procedures/corrective measures
(21) The size of paper on the cassette is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. Cassette size switch and connect-L PWB (YC10) Connect-L PWB (YC8) and engine PWB (YC503)
	2. Defective cassette size switch.	Replace the cassette size switch.
	3. Defective PWB.	Replace the engine PWB or connect-L PWB and check for correct operation (see page 1-5-31).
(22) A paper jam in the paper feed, paper conveying, eject or duplex section is indicated when the main power switch is turned on.	1. A piece of paper torn from paper is caught around registration sensor, eject sensor, duplex sensor or duplex jam sensor.	Check visually and remove it, if any.
	2. Defective eject sensor.	Replace the eject sensor.
	3. Defective duplex sensor.	Replace the duplex sensor.
	4. Defective registration sensor or duplex jam sensor.	Replace the engine PWB and check for correct operation (see page 1-5-31).
(23) A message indicating cover open is displayed when the top cover is closed.	1. Deformed actuator of the interlock switch.	Check visually and remedy or replace if necessary.
	2. Defective interlock switch.	Replace the power source PWB and check for correct operation (see page 1-5-38).
(24) DP paper feed motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. DP paper feed motor and DP drive PWB (YC3) DP drive PWB (YC1) and main PWB (YC1008)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the DP paper feed motor.
	4. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-49).
(25) DP paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. DP paper feed clutch and DP drive PWB (YC6) DP drive PWB (YC8) and main PWB (YC1005)
	2. Defective clutch.	Replace the DP paper feed clutch.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-49).

Problem	Causes	Check procedures/corrective measures
(26) DP pressure solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. DP pressure solenoid and DP drive PWB (YC4) DP drive PWB (YC8) and main PWB (YC1005)
	2. Defective solenoid.	Replace the DP pressure solenoid.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-49).
(27) DP switchback solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. DP switchback solenoid and DP drive PWB (YC5) DP drive PWB (YC8) and main PWB (YC1005)
	2. Defective solenoid.	Replace the DP switchback solenoid.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-49).
(28) An original jams when the main power switch is turned on.	1. A piece of paper torn from an original is caught around the DP timing sensor.	Check visually and remove it, if any.
	2. Defective DP timing sensor.	Replace the DP timing sensor.
(29) A message indicating cover open is displayed when the DP top cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. DP open/close sensor and DP drive PWB (YC2) DP drive PWB (YC8) and main PWB (YC1005)
	2. Defective DP open/close sensor.	Replace the DP open/close sensor.

1-4-5 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Pickup roller Paper feed roller MP paper feed roller	Clean with isopropyl alcohol.
	Check if the following rollers is deformed. Pickup roller Paper feed roller MP paper feed roller	Check visually and replace any deformed (see page 1-5-6).
	Defective paper feed clutch installation.	Check visually and remedy if necessary.
(2) No secondary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Upper registration roller Lower registration roller	Clean with isopropyl alcohol.
	Defective registration clutch installation.	Check visually and remedy if necessary.
(3) Skewed paper feed.	Paper width guide in a cassette installed incorrectly.	Check the paper width guide visually and remedy or replace if necessary.
(4) Multiple sheets of paper are fed.	Check if the paper is excessively curled.	Change the paper.
	Paper is loaded incorrectly.	Load the paper correctly.
	Check if the retard roller is worn.	Replace the retard roller if it is worn (see page 1-5-7).
(5) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Check if the contact between the upper and lower registration rollers is correct.	Check visually and remedy if necessary.
	Check if the heat roller or press roller is extremely dirty or deformed.	Check visually and replace the fuser unit (see page 1-5-30).
(6) Toner drops on the paper conveying path.	Check if the drum unit or developing unit is extremely dirty.	Clean the drum unit or developing unit.
(7) Abnormal noise is heard.	Check if the rollers, pulleys and gears operate smoothly.	Grease the bushes and gears.
	Check if the following clutches are installed correctly. Paper feed clutch Registration clutch Middle clutch Duplex clutch	Check visually and remedy if necessary.

Problem	Causes/check procedures	Corrective measures
(8) No primary original feed.	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP feed pulley	Clean with isopropyl alcohol.
	Check if the following pulleys is deformed. DP forwarding pulley DP feed pulley	Check visually and replace any deformed (see page 1-5-50).
(9) Multiple sheets of original are fed.	Original is not correctly set.	Set the original correctly.
	Check if the DP separation pad is worn.	Replace the DP separation pad if it is worn (see page 1-5-50).
(10) Originals jam.	Originals outside the specifications are used.	Use only originals conforming to the specifications.
	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP feed pulley	Clean with isopropyl alcohol.
	Check if the contact between the conveying roller and conveying pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the eject roller and eject pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the switchback roller and switchback pulley is correct.	Check visually and remedy if necessary.

1-4-6 Send error code

This section describes the scanning errors and descriptions, preventive actions, as well as corrective actions. Error codes not described here could fall within software errors.

If such an error is encountered, turn power off then on, and advise the service representative.

(1) Scan to SMB error codes

Code	Contents	Check procedures/corrective measures
1101	Host destined does not exist on the network.	<ol style="list-style-type: none"> 1. Confirm the destined host. 2. Confirm the device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Confirm the parameters of the network to which the device is connected are correct. 3. Check the host if the folder is properly shared.
1103	Destined host, folder, and/or file names are invalid.	<ol style="list-style-type: none"> 1. Check illegal characters are not contained within these names. 2. Check the name of the folder and files conform with the naming syntax. 3. Confirm destined host and folder.
1105	SMB protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMB protocols.
2101	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm the destined host. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMB port number. 4. Confirm the device's network parameters. 5. Confirm the parameters of the network to which the device is connected are correct.
2201	Writing scanned data has failed.	<ol style="list-style-type: none"> 1. Check the file name to save the scanned data. 2. Confirm the device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.

(2) Scan to FTP error codes

Code	Contents	Check procedures/corrective measures
1101	FTP server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the FTP server name.
1103	Destined folder is invalid.	<ol style="list-style-type: none"> 1. Check that the illegal characters are not contained within these names. 2. Check the FTP server name.
1105	FTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's FTP protocols.
1131	Initializing TLS has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters.
1132	TLS negotiation has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters. 2. Check the FTP server name.
2101	Access to the FTP server has failed.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the FTP port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the FTP server name.
2102	Access to the FTP server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the FTP server name.
2201	Connection with the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Confirm destined folder. 4. Check the FTP server name.
2202	Connection with the FTP server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2231	Connection with the FTP server has failed. (FTPS communication)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
3101	FTP server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the FTP server.

(3) Scan to E-mail error codes

Code	Contents	Check procedures/corrective measures
1101	SMTP/POP3 server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the SMTP/POP3 server.
1104	The domain the destined address belongs is prohibited by scanning restriction.	<ol style="list-style-type: none"> 1. Confirm device's SMTP parameters.
1105	SMTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
1106	Sender's address is not specified.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
2101	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMTP/POP3 port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the SMTP/POP3 server.
2102	Connection to the SMTP/POP3 server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the SMTP/POP3 server.
2201	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2202	Connection to the SMTP/POP3 server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2204	The size of scanning exceeded its limit.	<ol style="list-style-type: none"> 1. Confirm device's network parameters.
3101	SMTP/POP3 server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the SMTP/POP3 server.
3201	No SMTP authentication is found.	<ol style="list-style-type: none"> 1. Check the SMTP server. 2. The device supports SMTP authentication services including CRAM-MD5, DIGEST-MD5, PLAIN and LOGIN.

(2) Table of general classification

Error code	Description
U00000	No response or busy after the set number of redials.
U00100	Transmission was interrupted by a press of the stop/clear key.
U00200	Reception was interrupted by a press of the stop/clear key.
U00300	Recording paper on the destination unit has run out during transmission.
U004XX	A connection was made but interrupted during handshake with the receiver unit (refer to 1-4-33 U004XX error code table).
U006XX	Communication was interrupted because of a machine problem (refer to 1-4-33 U006XX error code table).
U00700	Communication was interrupted because of a problem in the destination unit.
U008XX	A page transmission error occurred in G3 mode (refer to 1-4-33 U008XX error code table).
U009XX	A page reception error occurred in G3 mode (refer to 1-4-33 U009XX error code table).
U010XX	Transmission in G3 mode was interrupted by a signal error (refer to 1-4-34 U010XX error code table).
U011XX	Reception in G3 mode was interrupted by a signal error (refer to 1-4-35 U011XX error code table).
U01400	An invalid one-touch key was specified during communication.
U01500	A communication error occurred when calling in V.8 mode.
U01600	A communication error occurred when called in V.8 mode.
U017XX	A communication error occurred before starting T.30 protocol during transmission in V.34 mode (refer to 1-4-36 U017XX error code table).
U018XX	A communication error occurred before starting T.30 protocol during reception in V.34 mode (refer to 1-4-36 U018XX error code table).
U03000	No document was present in the destination unit when polling reception started.
U03200	In interoffice subaddress-based bulletin board reception, data was not stored in the box specified by the destination unit.
U03300	In polling reception from a unit of our make, operation was interrupted due to a mismatch in permit ID or telephone number. Or, in interoffice subaddress-based bulletin board reception, operation was interrupted due to a mismatch in permit ID or telephone number.
U03400	Polling reception was interrupted because of a mismatch in individual numbers (destination unit is either of our make or by another manufacturer).
U03500	In interoffice subaddress-based bulletin board reception, the specified Subaddress confidential box number was not registered in the destination unit.
U03600	An interoffice subaddress-based bulletin board reception was interrupted because of a mismatch in the specified subaddress confidential box number.
U03700	Interoffice subaddress-based bulletin board reception failed because the destination unit had no subaddress-based bulletin board transmission capability, or data was not stored in any subaddress confidential box in the destination unit.
U04000	In interoffice subaddress-based transmission mode, the specified subaddress box number was not registered in the destination unit.

Error code	Description
U04100	Subaddress-based transmission failed because the destination unit had no subaddress-based reception capability.
U04200	In encrypted transmission, the specified encryption box was not registered in the destination unit.
U04300	Encrypted transmission failed because the destination unit had no encrypted communication capability.
U044XX	Communication was interrupted because of an encryption key error during encrypted transmission (refer to 1-4-36 U044XX error code table).
U04500	Encrypted reception was interrupted because of a mismatch in encryption keys.
U05100	Password check transmission or restricted transmission was interrupted because the permit ID's did not agree with.
U05200	Password check reception or restricted reception was interrupted because the permit ID's did not match, the rejected FAX number's did match, or the destination receiver did not return its phone number.
U05300	The password check reception or the restricted reception was interrupted because the permitted numbers did not match, the rejected numbers did match, or the machine in question did not acknowledge its phone number.
U14000	Memory overflowed during confidential reception. Or, in subaddress-based confidential reception, memory overflowed.
U14100	In interoffice subaddress-based transmission, memory overflowed in the destination unit.
U19000	Memory overflowed during memory reception.
U19100	Memory overflowed in the destination unit during transmission.
U19300	Transmission failed because an error occurred during JBIG encoding.

(2-1) U004XX error code table: Interrupted phase B

Error code	Description
U00430	Polling request was received but interrupted because of a mismatch in permit number. Or, subaddress-based bulletin board transmission request was received but interrupted because of a mismatch in permit ID in the transmitting unit.
U00431	An subaddress-based bulletin board transmission was interrupted because the specified subaddress confidential box was not registered.
U00432	An subaddress-based bulletin board transmission was interrupted because of a mismatch in Subaddress confidential box numbers.
U00433	Subaddress-based bulletin board transmission request was received but data was not present in the subaddress confidential box.
U00440	Subaddress-based confidential reception was interrupted because the specified subaddress box was not registered.
U00450	The destination transmitter disconnected because the permit ID's did not agree with while the destination transmitter is in password-check transmission or restricted transmission.
U00460	Encrypted reception was interrupted because the specified encryption box number was not registered.
U00462	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.

(2-2) U006XX error code table: Problems with the unit

Error code	Description
U00601	Document jam or the document length exceeds the maximum.
U00613	Image writing section problem
U00656	Data was not transmitted to a modem error.
U00690	System error.

(2-3) U008XX error code table: Page transmission error

Error code	Description
U00800	A page transmission error occurred because of reception of a RTN or PIN signal.
U00811	A page transmission error reoccurred after retry of transmission in the ECM mode.

(2-4) U009XX error code table: Page reception error

Error code	Description
U00900	An RTN or PIN signal was transmitted because of a page reception error.
U00910	A page reception error remained after retry of transmission in the ECM mode.

(2-5) U010XX error code table: G3 transmission

Error code	Description
U01000	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.
U01001	Function of the unit differs from that indicated by a DIS signal.
U01016	An MCF signal was received but no DIS signal was received after transmission of an EOM signal, and T1 timeout was detected.
U01019	No relevant signal was received after transmission of a CNC signal, and the preset number of command retransfers was exceeded (between units of our make).
U01020	No relevant signal was received after transmission of a CTC signal, and the preset number of command retransfers was exceeded (ECM).
U01021	No relevant signal was received after transmission of an EOR.Q signal, and the preset number of command retransfers was exceeded (ECM).
U01022	No relevant signal was received after transmission of an RR signal, and the preset number of command retransfers was exceeded (ECM).
U01028	T5 time-out was detected during ECM transmission (ECM).
U01052	A DCN signal was received after transmission of an RR signal (ECM).
U01080	A PIP signal was received after transmission of a PPS.NULL signal.
U01092	During transmission in V.34 mode, communication was interrupted because of an impossible combination of the symbol speed and communication speed.
U01093	A DCN or other inappropriate signal was received during phase B of transmission.
U01094	The preset number of command retransfers for DCS/NSS signals was exceeded during phase B of transmission.
U01095	No relevant signal was received after transmission of a PPS (Q) signal during phase D of transmission, and the preset number of command transfers was exceeded.
U01096	A DCN signal or invalid command was received during phase D of transmission.
U01097	The preset number of command retransfers was exceeded after transmission of an RR signal or no response.

(2-6) U011XX error code table: G3 reception

Error code	Description
U01100	Function of the unit differs from that indicated by a DCS signal.
U01101	Function of the unit (excl. communication mode select) differs from that indicated by an NSS signal.
U01102	A DTC (NSC) signal was received when no transmission data was in the unit.
U01110	No response after transmission of a DIS signal.
U01111	No response after transmission of a DTC (NSC) signal.
U01113	No response after transmission of an FTT signal.
U01125	No response after transmission of a CNS signal (between units of our make).
U01129	No response after transmission of an SPA signal (short protocol).
U01141	A DCN signal was received after transmission of a DTC signal.
U01143	A DCN signal was received after transmission of an FTT signal.
U01155	A DCN signal was received after transmission of an SPA signal (short protocol).
U01160	During message reception, transmission time exceeded the maximum transmission time per line.
U01162	Reception was aborted due to a modem malfunction during message reception.
U01191	Communication was interrupted because an error occurred during an image data reception sequence in the V.34 mode.
U01193	There was no response, or a DCN signal or invalid command was received, during phase C/D of reception.
U01194	A DCN signal was received during phase B of reception.
U01195	No message was received during phase C of reception.
U01196	Error line control was exceeded and a decoding error occurred for the message being received.

(2-7) U017XX error code table: V.34 transmission

Error code	Description
U01700	A communication error occurred in phase 2 (line probing).
U01720	A communication error occurred in phase 4 (modem parameter exchange).
U01721	Operation was interrupted due to the absence of a common communication speed between units.

U01700: A communication error that occurs at the transmitting unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/A/Abar (B/Bbar, for polling transmission)/INFOh was not detected.

U01720: A communication error that occurs at the transmitting unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01721: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange; 1) a DCN signal was received from the destination unit, and the line was cut; or 2) a DIS (NSF, CSI) signal was received from the destination unit and, in response to the signal, the unit transmitted a DCN signal, and the line was cut.

(2-8) U018XX error code table: V.34 reception

Error code	Description
U01800	A communication error occurred in phase 2 (line probing).
U01810	A communication error occurred in phase 3 (primary channel equivalent device training).
U01820	A communication error occurred in phase 4 (modem parameter exchange).
U01821	Operation was interrupted due to the absence of a common communication speed between units.

U01800: A communication error that occurs at the receiver unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/B/Bbar (A/Abar, for polling reception)/probing tone was not detected.

U01810: A communication error that occurs at the receiver unit in phase 3 (primary channel equivalent device training). For example, S/Sbar/PP/TRN was not detected.

U01820: A communication error that occurs at the receiver unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01821: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange, a DCN signal was transmitted to the destination unit and the line was cut.

(2-9) U044XX error code table: Encrypted transmission

Error code	Description
U04400	Encrypted transmission was interrupted because encryption keys did not agree.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the main power switch. And then unplug the power cable from the wall outlet.

When the fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 90% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.

(4) How to tell a genuine Kyocera Mita toner container

As a means of brand protection, the Kyocera Mita toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window (●)

A shiny or gold-colored band when seen through the right side window (☀)

The above will reveal that the toner container is a genuine Kyocera Mita branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Outer covers

(1) Detaching and refitting the right cover and left cover

Procedure

1. Remove the cassette. (See page 1-5-6)
2. Open the front cover.
3. Remove the one screw.
4. Unhook six hooks and then remove the right cover.





Figure 1-5-3

5. Remove two fulcrum of the front cover.
6. Unhook the hook of the front cover rack and then remove the front cover.

**Figure 1-5-4**

7. Open the left side cover and then remove the waste toner box.
(See page 1-5-27)
8. Remove the one screw and then remove the rear upper cover.
9. Unhook four hooks and then remove the rear upper cover.




Figure 1-5-5

10. Draw the rear unit.
11. Open the rear middle cover.
12. Unhook seven hooks and then remove the left cover.




Figure 1-5-6

1-5-3 Paper feed section

(1) Detaching and refitting the paper feed assembly (paper feed roller and pickup roller)

Procedure

1. Remove the cassette.
2. While pushing the lock and then slide the paper feed roller pin.
3. While pressing the lever and then remove the paper feed assembly.
4. Check or replace the paper feed assembly and refit all the removed parts.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-7

(2) Detaching and refitting the retard roller assembly

Procedure

1. Remove the cassette.
2. Unhook two hooks and then remove the retard guide.




Figure 1-5-8

3. Remove the retard holder (roller) from the retard guide.
4. Check or replace the retard roller and refit all the removed parts.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-9

(3) Detaching and refitting the upper registration and lower roller

Procedure

1. Remove the developing unit.
(See page 1-5-26)
2. Remove the spring.
3. Pull the upper registration roller.




Figure 1-5-10

4. Remove the upper registration roller from the bush.
5. Remove the gear and bush from the upper registration roller.




Figure 1-5-11

6. Remove the lower registration roller.
7. Remove the stopper, gear and three bushes from the lower registration roller.
8. Check or replace the upper registration and lower roller and refit all the removed parts.




Figure 1-5-12

(4) Detaching and refitting the MP paper feed roller

Procedure

1. Open the front cover.
2. Remove the developing unit.
(See page 1-5-26)
3. Remove the front cover.
(See page 1-5-3)
4. Pull the MP paper feed tray upwards until it is removed from the machine.




Figure 1-5-13

5. Pull the MP paper feed roller holder. (1)
6. Slide the MP paper feed roller holder. (2)
7. Remove the MP paper feed roller.
8. Check or replace the MP paper feed roller and refit all the removed parts.





Figure 1-5-14

1-5-4 Optical section

(1) Detaching and refitting the Document processor

Procedure

1. Remove the right cover.
(See page 1-5-3)
2. Remove two connectors from the main PWB.




Figure 1-5-15

3. Remove the ferrite core.
4. Remove the screw and grounding terminal.
5. Release the clamp and then remove the electrical wires.




Figure 1-5-16

6. Pull the Document processor out.




Figure 1-5-17

(2) Detaching and refitting the scanner unit

Procedure

1. Remove the right cover and left cover.
(See page 1-5-3)
2. Remove the document processor.
(See page 1-5-11)
3. Remove the FFC and three connectors and the USB from the main PWB.




Figure 1-5-18

4. Release clamps and then remove the wires.




Figure 1-5-19

5. Remove two screws.




Figure 1-5-20

6. Unhook four hooks and then remove the scanner unit.




Figure 1-5-21

(3) Detaching and refitting the laser scanner unit

Procedure

1. Remove the right cover and left cover.
(See page 1-5-3)
2. Remove the document processor.
(See page 1-5-11)
3. Remove the scanner unit.
(See page 1-5-13)
4. Remove the connector from the main PWB.
5. Remove the screw and grounding terminal.
6. Unhook the hook and then remove the right front upper cover.




Figure 1-5-22

7. Unhook the hook and then remove the left front upper cover.
8. Remove the one screw on upper cover rack.




Figure 1-5-23

9. Remove two fulcrum of the upper cover.




Figure 1-5-24

10. Remove six screws on the inner tray.

11. Remove the inner tray.




Figure 1-5-25

12. Remove two connectors from the main PWB.




Figure 1-5-26

13. Remove four screws and then remove the laser scanner unit.
 14. Check or replace the laser scanner unit and refit all the removed parts.




Figure 1-5-27

(4) Replacing the image scanner unit (ISU)

Procedure

Removing the image scanner unit (ISU)

1. Remove the scanner unit.
(See page 1-5-13)
2. Remove the card reader cover.




Figure 1-5-28

3. Remove the upper cover by using a pen.
4. Remove the LCD cover.




Figure 1-5-29

5. Remove the left operation panel cover.
6. Remove the right operation panel cover.






Figure 1-5-30


7. Remove the left language sheet.
8. Remove the right language sheet.

**Figure 1-5-31**

9. Remove two screws.

**Figure 1-5-32**

10. Remove three connectors and then remove the operation panel.

**Figure 1-5-33**

11. Remove two screws.
12. Unhook three hooks and then remove the ISU upper frame.




Figure 1-5-34

13. Move the image scanner unit (ISU) in the middle of the ISU shaft.
14. Detach the ISU shaft from the holder by lifting it.
15. Pull the ISU shaft out from the ISU.




Figure 1-5-35

16. Remove the ISU belt from the tension pulley and ISU gear 63/32.
17. Remove the ISU belt from the hooks of the ISU.




Figure 1-5-36

18. Remove the FFC from the FFC tape D.
19. Remove the ferrite core from the pit.
20. Remove the FFC from the FFC tape A.




Figure 1-5-37

21. Fold the end of the FFC and then pull the FFC out from the ISU lower frame.
22. Remove the FFC tape D and A from the ISU lower frame.
23. Clean the adhesive residue of the FFC tape D and A.




Figure 1-5-38

24. Remove the ferrite core from the FFC.






Figure 1-5-39

Installing the image scanner unit (ISU)

25. Peel off the protective seal on one side from the FFC tape D.
26. Stick the FFC tape D on the ISU lower frame, aligned with the marking of the frame.
(Sticking standards: See right figure)
27. Peel off the protective seal on the other side of the FFC tape A.
28. Stick the FFC tape A on the ISU lower frame.
(At the right for how to correctly stick the tape in position, see the figure.)

**Figure 1-5-40**

29. Fix the ferrite core onto the FFC.

**Figure 1-5-41**

30. Peel off the protective seal from the FFC tape D.
31. Align the line marking on the FFC with the rib on the ISU lower frame, then fix the FFC to the FFC tape D.
32. Install the ferrite core in the pit.
33. Peel off the released paper from the FFC tape A.
34. Stick the FFC on the FFC tape A.




Figure 1-5-42

35. Thread an end of the FFC through the ISU lower frame.
36. Refer to the step 11 to 1 and refit all the removed parts.

NOTE:

When the replacing the image scanner unit (ISU), perform following maintenance modes.

1. U425 Setting the target (see page 1-3-20)
2. U411 Adjusting the scanner automatically (see page 1-3-18)




Figure 1-5-43

1-5-5 Developing section

(1) Detaching and refitting the developing unit

Procedure

1. Open the front cover.
2. Remove the developing unit.
3. Check or replace the developing unit and refit all the removed parts.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-44

1-5-6 Drum section

(1) Detaching and refitting the drum unit

Procedure

1. Remove the developing unit.
(See page 1-5-26)
2. Open the left side cover and then remove the waste toner box.
3. Remove the drum stopper.
4. Unlock the drum unit lock and then remove the drum unit.
5. Check or replace the drum unit and refit all the removed parts.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-45

(2) Detaching and refitting the main charger unit

Procedure

1. Remove the drum unit.
(See page 1-5-27)
2. Unlock the lock lever and then remove the main charger unit.
3. Check or replace the main charger unit and refit all the removed parts.




Figure 1-5-46

1-5-7 Transfer/separation section

(1) Detaching and refitting the transfer roller and separation brush unit

Procedure

1. Remove the developing unit.
(See page 1-5-26)
2. Remove the drum unit.
(See page 1-5-27)
3. Slide the paper chute guide and unhook the hooks.
4. Remove the paper chute guide.




Figure 1-5-47

5. Remove the transfer roller's shaft from the both bushes.




Figure 1-5-48

6. Release four hooks and then remove the separation brush unit.
7. Check or replace the transfer roller and separation brush unit and refit all the removed parts.

CAUTION: Note the following, when refitting the transfer roller and separation brush unit.

A: Transferroller

To avoid damaging the bush, place the transfer roller so that its gear does not hit the U-shaped bush.

B: Separation brush unit

While inserting the separation holder in place, align the ends of the holder with the guides until they click in.

(a) The separation brush unit is inserted into the two projections of the frame and does not run on to the projections.

(b) The separation brush unit is firmly in contact with the separation plate of the frame.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-49

1-5-8 Fuser section

(1) Detaching and refitting the fuser unit

Procedure

1. Draw the rear unit.
2. Insert a flat-blade screwdriver to push the fuser lock (gray colored) on the rear unit and the fuser unit is separated from the rear unit (rails).
Do it both ends of the rear unit.
3. Check or replace the fuser unit and refit all the removed parts.
Place the fuser unit on the rear unit (rails) and push the fuser lock so that the fuser lock catches the fuser unit.
Do it for the both ends of the fuser unit.

NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-5), perform maintenance mode.:

U251 Clearing the maintenance count (see page 1-3-17)




Figure 1-5-50

1-5-9 PWBs

(1) Detaching and refitting the engine PWB

Procedure

1. Remove the developing unit.
(See page 1-5-26)
2. Remove the drum unit.
(See page 1-5-27)
3. Remove the right cover and left cover.(See page 1-5-3)
4. Remove the PSU fan motor.
(See page 1-5-38)
5. Stand the main body front side up.
6. Remove five screws and then remove the bottom plate1.
7. Remove two screws and then remove the bottom plate 2.




Figure 1-5-51

8. Remove two wires from the hooks and notches.
9. Open the DU guide (duplex cover).




Figure 1-5-52

10. Remove the cord cover.
11. Remove the connector.
12. Detach the joint.
13. Remove the six screws and then remove the DU base.




Figure 1-5-53

14. Release four snaps.
15. Remove one tab.
16. Remove five connectors.




Figure 1-5-54

17. Remove four screws.




Figure 1-5-55

- 18. Detach the engine PWB assembly.
- 19. Remove four connectors.
- 20. Remove the engine PWB assembly.





Figure 1-5-56

21. Remove one connector.
22. Remove two screws-A and then remove the HV plate.
23. Remove two screws-B and then remove the engine R grounding plate, engine L grounding plate and shield plate.
24. Check or replace the engine PWB and refit all the removed parts.
To replace the engine PWB, remove the EEPROM from the old engine PWB and mount it to the new engine PWB.

**Figure 1-5-57**

(2) Detaching and refitting the main PWB

Procedure

1. Remove the right cover.
(See page 1-5-3)
2. Remove the screw.
3. Remove the connector of the controller fan motor and then remove the memory slot cover.




Figure 1-5-58

4. Remove the electrical wires from the three wire saddles.




Figure 1-5-59

5. Draw the rear unit.
6. Remove seven screws and then remove the controller box.




Figure 1-5-60

7. Remove fourteen connectors from the main PWB.
8. Remove six screws and then remove the main PWB.
9. Check or replace the main PWB and refit all the removed parts.




Figure 1-5-61

(3) Detaching and refitting the power source PWB

Procedure

1. Remove the right cover and left cover.
(See page 1-5-3)
2. Remove the drum unit.
(See page 1-5-27)
3. Remove three connectors from the relay PWB.
4. Release three clamps and then remove the wires.




Figure 1-5-62

5. Unhook five hooks and then remove the rack cover.
6. Remove the one screw and then remove upper cover rack.
7. Remove the gear and front cover rack each.
8. Unhook two hooks and then remove the gear holder by pulling upwards.





Figure 1-5-63

9. Remove one connector (YC11) from the connect-L PWB.
10. Remove the wire from the drum grounding plate and clamp.
11. Release two hooks and then remove the power source fan motor.

**Figure 1-5-64**

12. Remove seven screws-A and drum grounding plate and two grounding terminals.
13. Remove the AC inlet.




Figure 1-5-65

14. Remove two screws and three grounding terminals.
15. Remove one connector.
16. Remove the PWB connector between connect-L PWB and power source unit.
17. Remove the power source unit.




Figure 1-5-66

18. Remove one connector.
19. Remove seven screws and then remove the power source PWB.
20. Check or replace the power source PWB and refit all the removed parts.

Note:

While assembling the rack component, align the guiding holes on either the upper cover rack and the front cover rack with each other.




Figure 1-5-67




Figure 1-5-68

(4) Detaching and refitting the FAX control PWB

Procedure

1. Remove two screws and then remove the FAX control PWB.
2. Check or replace the FAX control PWB and refit all the removed parts.




Figure 1-5-69

1-5-10 Others

(1) Detaching and refitting the paper feed drive unit

Procedure

1. Remove the cassette.
(See page 1-5-6)
2. Remove the developing unit.
(See page 1-5-26)
3. Remove the right cover.
(See page 1-5-3)
4. Remove five connectors from the connect-R PWB.
5. While opening the one hook and then remove the wire.
6. While opening three hooks and then remove the right fan motor.




Figure 1-5-70

7. Remove two hooks and then remove the duct.
8. Remove wire from the clamp.





Figure 1-5-71

9. Remove three screws and then remove the paper feed drive unit.
10. Check or replace the paper feed drive unit and refit all the removed parts.
To refit the paper feed drive unit, make sure mesh of gears.

**Figure 1-5-72**

(2) Detaching and refitting the main drive unit

Procedure

1. Remove the right cover.
(See page 1-5-3)
2. Remove the controller box.
(See page 1-5-35)
3. Remove two connectors.
4. Remove five screws and then remove the main drive unit.
5. Check or replace the main drive unit and refit all the removed parts.




Figure 1-5-73

(3) Direction of installing the principal fan motors

When detaching or refitting the left fan motor or right fan motor or controller fan motor, be careful of the airflow direction (intake or exhaust).




Figure 1-5-74

1-5-11 Document processor

(1) Detaching and refitting the DP rear cover and DP front cover

Procedure

1. Open the DP top cover.
2. Remove two screws.
3. Unhook the hook and then remove the DP rear cover.




Figure 1-5-75

4. Unhook two hooks and then remove the DP front cover.




Figure 1-5-76

(2) Detaching and refitting the DP drive PWB

Follow the procedure below to check or replace the DP drive PWB.

Procedure

1. Remove the DP rear cover.
(See page 1-5-48).
2. Remove seven connectors from the DP drive PWB.
3. Remove the screw and then remove the DP drive PWB.
4. Check or replace the DP drive PWB.
Refit all the removed parts.




Figure 1-5-77

(3) Detaching and refitting the DP forwarding pulley assembly and DP separation pad assembly.

Procedure

1. Open the DP top cover.
2. Unlatch the lock lever and slide the shaft.




Figure 1-5-78

3. Remove the DP forwarding pulley assembly.




Figure 1-5-79

4. Unhook two hooks and remove the DP separation pad assembly.
 5. Check or replace the DP forwarding pulley assembly and DP separation pad assembly.
- Refit all the removed parts.




Figure 1-5-80

This page is intentionally left blank.

1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of main PWB (main controller and scanner) and engine PWB and FAC control PWB and Option language.

Preparation

Extract the file that has the download firmware and put them in the USB Memory.

Procedure

1. Turn ON the main power switch and confirm if the screen shows "Ready to print" then, turn OFF the main power switch.
2. Insert USB memory that has the firm-ware in the USB memory slot.
3. Turn ON the main power switch.
4. About 40 seconds later, "FW-Update" will be displayed and blinking the data LED (this shows to start the download).
5. Display the software that now upgrad-
ing.

"FW-Update [CTRL]"

"FW-Update [ENGIN]"

"FW-Update [SCAN]"

"FW-Update [FAX]"

"FW-Update [OPT]"

6. Display the completion of the upgrade (Data LED is ON condition).
7. ROM version is confirmed by the con-
tent of the display.
8. Turn OFF the main power switch and
remove the USB memory.





Figure 1-6-1

1-6-2 Remarks on engine PWB replacement

When replacing the engine PWB, remove the EEPROM (U7) from the engine PWB that has been removed and then reattach it to the new engine PWB.



2-1-1 Paper feed/conveying section

Paper feed/conveying section consists of the paper feed unit that feeds paper from the cassette and the MP tray paper feed unit that feeds paper from the MP tray, and the paper conveying section that conveys the fed paper to the transfer/separation section.

(1) Cassette paper feed section

Paper cassette is the universal type that is applicable to various paper sizes by adjusting the side guides and paper stopper and approximate 500 pages can be put in. Mechanism in the paper cassette consists of the bottom plate that lifts the paper in order to let it touch the pickup roller and the retard roller that prevents papers from multiple feeding. Paper that is drawn out by the rotation of pickup roller of the cassette paper feed section is then sent in between the feed roller and the retard roller. Function of the built-in torque limiter in the retard roller gives weak resistance force against the rotation. Normally, when only a page is drawn out by the rotation of pickup roller, the paper is conveyed to the machine by the rotation of feed roller on its own. If the pickup roller drew out two lapped pages somehow, the upper paper is conveyed by the feed roller and the lower paper stays due to the rotation resistant force of the retard roller because the friction force between papers is smaller than the rotation resistance force of the retard roller and then the multiple paper feed can be prevented.




Figure 2-1-1 Cassette paper feed section

- | | |
|----------------------|------------------|
| 1. Pickup roller | 5. Retard holder |
| 2. Paper feed roller | 6. Bottom plate |
| 3. Feed holder | 7. Retard guide |
| 4. Retard roller | 8. Cassette base |




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

The MP tray can contain about 100 pages. Feeding is performed by the rotation of the MP tray feed roller from the MP tray. Function of the MP tray friction pad prevents papers from multiple feeding.




Figure 2-1-3 MP tray paper feed section

1. MP paper feed roller
2. Bottom plate
3. MP tray frame
4. MPF base
5. MP tray cover




Figure 2-1-4 MP tray paper feed section block diagram

(3) Paper conveying section

Paper conveying section consists of the parts shown in the following illustration and conveys papers from the paper cassette or the MP tray to the transfer/separation section when papers are fed. Paper by feeding or refeeding is conveyed by the middle roller to the position where the registration sensor (RS) is turned on, and then sent to the transfer/separation section by the upper registration roller and lower registration roller.




Figure 2-1-5 Paper conveying section

- | | |
|-----------------------------|-----------------------------------|
| 1. Middle roller | 5. Registration sensor (RS) |
| 2. Feed DU pulley | 6. Actuator (registration sensor) |
| 3. Feed frame | 7. Lower registration roller |
| 4. Registration upper guide | 8. Upper registration roller |




Figure 2-1-6 Paper conveying section block diagram

2-1-2 Drum section

The drum unit includes a photoconductive drum, eraser lamp, cleaning blade and, a main charger unit. The drum unit is removable with the main charger unit.




Figure 2-1-7 Drum section

1. Drum
2. Main charger case
3. Charger cleaning roller
4. Main charger roller




Figure 2-1-8 Drum section block diagram

2-1-3 Optical section

(1) Scanner unit




Figure 2-1-9 Scanner unit

- | | |
|-------------------------|------------------------------|
| 1. ISU top frame | 6. ISU belt |
| 2. ISU bottom frame | 7. ISU shaft |
| 3. Contact glass | 8. ISU gear 63/32 |
| 4. DP contact glass | 9. ISU motor |
| 5. Size indicator plate | 10. Image scanner unit (ISU) |

(2) Image scanner unit (ISU)

The original image is illuminated by the LED and scanned by the CCD image sensor in the CCD PWB (CCD-PWB) via the four mirrors and ISU lens, the reflected light being converted to an electrical signal.

If a document processor (DP) is used, the image scanner unit stops at the position of the DP contact glass and scans sequentially one row of the image on the original in synchronization with the moving timing of the original in the sub scan direction by driving the DP.




Figure 2-1-10 Image scanner unit (ISU)

- | | |
|-------------------------|--------------------------------|
| 1. Lamp mount | 8. Mirror D |
| 2. ISU housing | 9. ISU lens |
| 3. ISU reflector | 10. CCD PWB (CCDPWB) |
| 4. Transparent material | 11. Inverter PWB (INPWB) |
| 5. Mirror A | 12. Home position sensor (HPS) |
| 6. Mirror B | 13. ISU shaft |
| 7. Mirror C | |




Figure 2-1-11 Scanner unit block diagram

(3) Laser scanner unit

The charged surface of the drum is then scanned by the laser beam from the laser scanner unit. The laser beam is dispersed as the polygon motor (PM) revolves to reflect the laser beam over the drum. Various lenses and mirror are housed in the laser scanner unit, adjust the diameter of the laser beam, and focalize it at the drum surface.




Figure 2-1-12 Laser scanner unit

1. Polygon motor (PM)
2. f-θ sub lens
3. f-θ main lens
4. Direction change mirror
5. Protective glass




Figure 2-1-13 Laser scanner unit block diagram

2-1-4 Developing section

The latent image constituted on the drum is developed into a visible image. The developing roller contains a 3-pole (S-NS) magnet roller and an aluminum cylinder rotating around the magnet roller. Toner attracts to the magnet sleeve since it is powdery ink made of black resin bound to iron particles. Developing blade, magnetized by magnet, is positioned approximately 0.3 mm above the magnet sleeve to constitute a smooth layer of toner in accordance with the magnet sleeve revolution.

The developing roller is applied with the AC-weighted, positive DC power source. Toner on the magnet sleeve is given a positive charge. The positively charged toner is then attracted to the areas of the drum which was exposed to the laser light. (The gap between the drum and the magnet sleeve is approximately 0.32 mm.) The non-exposed areas of the drum repel the positively charged toner as these areas maintain the positive charge.

The developing roller is also AC-biased to ensure contrast in yielding by compensating the toner's attraction and repelling action during development.




Figure 2-1-14 Developing section

- | | |
|----------------------|--------------------|
| 1. Developing blade | 6. DLP screw B |
| 2. Blade magnet | 7. Toner container |
| 3. Developing roller | 8. Sleeve cover |
| 4. Developer case | 9. Developer lid |
| 5. DLP screw A | |




Figure 2-1-15 Developing section block diagram

2-1-5 Transfer/Separation section

The image developed by toner on the drum is transferred onto the paper because of the electrical attraction between the toner itself and the transfer roller. The transfer roller is negatively biased so that the positively charged toner is attracted onto the paper while it is pinched by the drum and the transfer roller.




Figure 2-1-16 Transfer/Separation section

1. Transfer roller
2. Paper chute guide
3. Separation brush




Figure 2-1-17 Transfer/Separation section block diagram

2-1-6 Cleaning section

After the transferring process, the drum needs to be physically cleaned of toner which is residual after the development process. The cleaning blade is constantly pressed against the drum and scrapes the residual toner off to the cleaning roller. The waste toner is collected at the output end of the sweep roller and sent to the waste toner box.

After the drum is physically cleaned, it then must be cleaned to the electrically neutral state. This is necessary to erase any residual positive charge, ready to accept the uniform charge for the next print process. The residual charge is canceled by exposing the drum to the light emitted from the cleaning lamp (CL). This lowers the electrical conductivity of the drum surface making the residual charge on the drum surface escape to the ground.




Figure 2-1-18 Cleaning section

1. Cleaning blade
2. Cleaning roller
3. Sweep roller
4. Drum frame
5. Cleaning lamp (CL)




Figure 2-1-19 Cleaning section block diagram

2-1-7 Fuser section

The toner on the paper is molten and pressed into the paper as it passes between the heat roller and the press roller in the fuser unit.

The heat roller has a fuser heater (FH) inside which continuously turns on and off by the fuser thermistor (FTH) to maintain the constant temperature onto the heat roller surface.

Should the temperature of the heat roller exceed the predetermined value, the fuser thermostat (FTS) is activated to effectively disconnect the fuser heater (FH) from power.

Fuser temperature is optimized to the paper type. The heat roller is resin coated by fluorine to prevent toner from accumulating on the roller after a long run. Care must be taken while handling the heat roller not to scratch the roller surface as doing so may result in print problems. The heat roller has four separators (claws) which are continuously in contact with its surface. These separators (claws) prevent the paper on which toner has been fused from being wound around the heat roller causing paper jam.

The press roller is made of the heat-resistant silicone rubber. This roller is used to strongly press the paper towards the heat roller by means of press springs.




Figure 2-1-20 Fuser section

- | | |
|----------------------|-------------------------------|
| 1. Fuser heater (FH) | 8. Eject roller |
| 2. Heat roller | 9. Feed guide |
| 3. Press roller | 10. Actuator (eject sensor) |
| 4. Fuser upper frame | 11. Fuser thermostat (FTS) |
| 5. Fuser lower frame | 12. Fuser thermistor 1 (FTH1) |
| 6. Separators | 13. Fuser thermistor 2 (FTH2) |
| 7. Eject pulley | |




Figure 2-1-21 Fuser section block diagram

2-1-8 Eject/Rear unit section

Eject/Rear unit section transports the paper which passed the fuser unit towards the top tray, face up tray or duplex conveying section.




Figure 2-1-22 Eject/Rear unit section

- | | |
|---------------------------------|------------------------------|
| 1. Face down upper roller | 9. Face up roller |
| 2. Eject FD pulley | 10. Eject FU pulley |
| 3. Actuator (paper full sensor) | 11. Face up guide |
| 4. FD cover | 12. Actuator (duplex sensor) |
| 5. Feed FD pulley | 13. Vertical guide |
| 6. Face down lower roller | 14. Paper eject guide |
| 7. DU guide | 15. Rear cover |
| 8. Feed DU pulley | |




Figure 2-1-23 Eject/rear unit section block diagram

2-1-9 Duplex conveying section

Duplex conveying section consists of conveying path which sends the paper sent from the eject/rear unit section to the paper feed/conveying section when duplex printing.




Figure 2-1-24 Duplex conveying section

- 1. DU roller
- 2. DU feed pulley
- 3. DU base
- 4. DU lower guide
- 5. Actuator (duplex jam sensor)
- 6. Feed upper guide




Figure 2-1-25 Duplex conveying section block diagram

2-1-10 Document processor

(1) Original feed section

The original feed section consists of the parts shown in figure. An original placed on the original table is conveyed to the original conveying section. Original is fed by the rotation of the DP forwarding pulley and DP feed pulley.




Figure 2-1-26 Original feed section

- | | |
|-------------------------|-----------------------------------|
| 1. DP forwarding pulley | 8. Separation mount |
| 2. DP feed pulley | 9. Upper guide |
| 3. LF holder | 10. Switchback guide |
| 4. PF stopper | 11. DP original sensor (DPOS) |
| 5. Front separation pad | 12. Actuator (DP original sensor) |
| 6. LF friction plate | 13. Original table |
| 7. DP separation pad | |

]




Figure 2-1-27 Original feed section block diagram

(2) Original conveying section

The original conveying section consists of the parts shown in figure. A conveyed original is scanned by the optical section (CCD) of main machine when it passes through the DP contact glass of main machine.




Figure 2-1-28 Original conveying section

- | | |
|-----------------------|--------------------------------|
| 1. Conveying roller A | 5. DP timing sensor (DPTS) |
| 2. Conveying pulley | 6. Actuator (DP timing sensor) |
| 3. Conveying bottom | 7. DP contact glass |
| 4. Reading guide | |




Figure 2-1-29 Original conveying section block diagram

(3) Original switchback/eject sections

The original switchback/eject sections consists of the parts shown in figure. An original of which scanning is complete is ejected to the original eject table by the eject roller. In the case of duplex switchback scanning, an original is conveyed temporarily to the switchback tray and conveyed again to the original conveying section by the switchback roller.




Figure 2-1-30 Original switchback/eject sections

- | | |
|-----------------------|-----------------------------|
| 1. Conveying roller B | 7. Original eject table |
| 2. Conveying pulley | 8. Switchback guide |
| 3. DP base | 9. Switchback roller |
| 4. Eject roller | 10. Switchback pulley |
| 5. Eject pulley | 11. Switchback pulley mount |
| 6. PF housing | 12. Switchback tray |




Figure 2-1-31 Original switchback/eject sections block diagram

This page is intentionally left blank.

2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs

- | | |
|--------------------------------------|---|
| 1. Main PWB (MPWB) | Controls the software such as the print data processing and provides the interface with computers. |
| 2. Engine PWB (EPWB)..... | Controls printer hardware such as high voltage/bias output control, paper conveying system control, and fuser temperature control, etc. |
| 3. Power source PWB (PSPWB) | After full-wave rectification of AC power source input, switching for converting to 24 V DC for output. Controls the fuser heater. |
| 4. Operation panel PWB (OPPWB) | Consists the LCD, LED indicators and key switches. |
| 5. Connect-R PWB (CPWB-R)..... | Interconnects the engine PWB and the electrical parts. |
| 6. Connect-L PWB (CPWB-L)..... | Interconnects the engine PWB and the electrical parts. |
| 7. Relay PWB (RYPWB) | Interconnects the power source PWB and the fuser heater. |
| 8. Drum PWB (DRPWB) | Relays wirings from electrical components on the drum unit. Drum individual information in EEPROM storage. |
| 9. Developing PWB (DEVPWB)..... | Relays wirings from electrical components on the developing unit. |
| 10. APC PWB (APCPWB) | Generates and controls the laser beam. |

11. PD PWB (PDPWB) Controls horizontal synchronizing timing of laser beam.
 12. LED drive PWB (LEDDRPWB) Controls the LED.
 13. LED PWB (LEDPWB) Controls the LED.
 14. CCD PWB (CCDPWB)..... Reads the image of originals.
 15. FAX control PWB (FCPWB)* Modulates, demodulates, compresses, decompresses and
 smoothes out image data, and converts resolution of image data.

*: Only 4in1 model (with FAX)

List of correspondences of PWB names

No.	Name used in service manual	Name used in parts list
1	Main PWB (MPWB)	PARTS MAIN PWB ASSY EU SP
2	Engine PWB (EPWB)	PARTS ENGINE PWB ASSY SP
3	Power source PWB (PSPWB)	PARTS SWITCHING REGULATOR (U) SP *1
3	Power source PWB (PSPWB)	PARTS SWITCHING REGULATOR (E) SP *2,*3
4	Operation panel PWB (OPPWB)	-
5	Connect-R PWB (CPWB-R)	P.W.BOARD ASSY CONNECT-R
6	Connect-L PWB (CPWB-L)	P.W.BOARD ASSY CONNECT-L
7	Relay PWB (RYPWB)	P.W.BOARD ASSY RELAY
8	Drum PWB (DRPWB)	-
9	Developer PWB (DEVPWB)	-
10	APC PWB (APCPWB)	-
11	PD PWB (PDPWB)	-
12	LED drive PWB (LEDDRPWB)	-
13	LED PWB (LEDPWB)	-
14	CCD PWB (CCDPWB)	-
15	FAX control PWB (FCPWB)	PARTS FAX UNIT(U) SP *1
15	FAX control PWB (FCPWB)	PARTS FAX UNIT(E) SP *2
15	FAX control PWB (FCPWB)	PARTS FAX UNIT(AS) SP *3

*1: 120V

*2: 220V

*3: 240V

(2) Switches and sensors




Figure 2-2-2 Switches and sensors

- | | |
|---|--|
| 1. Main power switch (MSW) | Turns ON/OFF the AC power source. |
| 2. Interlock switch (ILSW) | Shuts off 24 V DC power line when the front cover is opened. |
| 3. Cassette size switch (CSSW) | Detects the paper size dial setting of the paper setting dial. |
| 4. Paper sensor 1 (PS1) | Detects the paper remaining amount level. |
| 5. Paper sensor 2 (PS2) | Detects the paper remaining amount level. |
| 6. Lift sensor (LS)..... | Detects activation of upper limit of the bottom plate in the paper cassette. |
| 7. Registration sensor (RS)..... | Detects the timing of primary feeding. |
| 8. MP paper sensor (MPPS) | Detects the presence of paper on the MP tray. |
| 9. Eject sensor (ES)..... | Detects paper jam in the fuser unit. |
| 10. Paper full sensor (PFS)..... | Detects whether the face down tray is full. |
| 11. Duplex jam sensor (DUJS) | Detects paper jam in the duplex conveying section. |
| 12. Duplex sensor (DUS) | Detects paper jam in the rear unit. |
| 13. Toner sensor (TS) | Detects the toner in the toner container. |
| 14. Waste toner sensor (WTS)..... | Detects the waste toner box being full. |
| 15. Envelope switch-R (EVSU-R) | Detects the position of the envelope switch (right). |
| 16. Envelope switch-L (EVSU-L)..... | Detects the position of the envelope switch (left). |
| 17. Envelope feeder switch (EVFSW)..... | Detects optional envelope feeder. |

- 18. Fuser unit switch (FUSW) Detects open/close rear unit (fuser unit).
- 19. Temperature sensor (TEMS)..... Detects the ambient temperature and absolute humidity.
- 20. Fuser thermistor 1 (FTH1) Measures the heat roller temperature.
- 21. Fuser thermistor 2 (FTH2) Measures the heat roller (center) temperature.
- 22. Home position sensor (HPS) Detects the ISU in the home position.

(3) Motors




Figure 2-2-3 Motors

- | | |
|--|--|
| 1. Main motor (MM)..... | Drives the paper feed/conveying section and fuser unit. |
| 2. Lift motor (LM)..... | Operates the bottom plate in the paper cassette. |
| 3. Drum motor (DRM) | Drives the drum unit and developing unit. |
| 4. Toner motor (TM) | Replenishes the developing unit with toner. |
| 5. Switchback motor (SBM) | Drives paper eject (switchback) section. |
| 6. Polygon motor (PM)..... | Drives the polygon mirror. |
| 7. Right fan motor (RFM) | Cools the interior of machine. |
| 8. Left fan motor (LFM) | Cools the interior of machine. |
| 9. Power source fan motor (PSFM) | Cools the power source unit. |
| 10. Feed fan motor (FFM)..... | Cools the paper feed conveying section and duplex conveying section. |
| 11. Eject fan motor (EFM)..... | Disperses steam. |
| 12. ISU motor (ISUM) | Drives the ISU. |
| 13. Controller fan motor (CONFM)..... | Cools the controller section. |

(4) Other electrical components





Figure 2-2-4 Other electrical components

- | | |
|---------------------------------------|--|
| 1. Paper feed clutch (PFCL) | Controls the paper cassette paper feed. |
| 2. Registration clutch (RCL) | Controls the secondary paper feed. |
| 3. Middle feed clutch (MCL) | Controls the paper conveying at the conveying section. |
| 4. Duplex clutch (DUCL) | Controls the paper conveying at the duplex conveying section. |
| 5. MP solenoid (MPSOL) | Controls the primary paper feed from the MP tray. |
| 6. Developing solenoid (DEVSOL) | Controls the developing unit drive. |
| 7. Feedshift solenoid (FSSOL) | Switches the output stack between face up and face down. |
| 8. Cleaning lamp (CL) | Eliminates the residual electrostatic charge on the drum. |
| 9. Fuser heater (FH) | Heats the heat roller. |
| 10. Fuser thermostat (FTS) | Shuts off the power source to the fuser heater lamp when the heat roller reaches extremely high temperature. |

(5) Document processor**Figure 2-2-5 Document processor**

1. DP drive PWB (DPDPWB)..... Consists the solenoids and clutch driver circuit and wiring relay circuit.
2. DP original sensor (DPOS)..... Detects the presence of an original.
3. DP timing sensor (DPTS)..... Detects the original scanning timing.
4. DP open/close sensor (DPOCS)..... Detects the opening/closing of the DP.
5. DP paper feed motor (DPPFM)..... Drives the original feed section.
6. DP paper feed clutch (DPPFCL)..... Controls the drive of the forwarding pulley and feed pulley.
7. DP switchback solenoid (DPSBSOL).... Operates the switchback guide.
8. DP pressure solenoid (DPPRSOL)..... Operates the switchback pulley.

This page is intentionally left blank.

2-3-1 Power source PWB




Figure 2-3-1 Power source PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC101	1	LIVE	I	120 V AC 220-240 V AC	AC power input
	2	NEUTRAL	I	120 V AC 220-240 V AC	AC power input
Connected to AC inlet and main power switch					
YC102	1	COMMON1	O	120 V AC/0V 220-240 V AC/0V	FH: On/Off
Connected to relay PWB	2	N.C	-	-	Not used
	3	LIVE	O	120 V AC220-240 V AC	AC power to RYPWB
YC103	1	+5V1	O	5 V DC	5 V DC power to CPWB-L
Connected to connect-L PWB	2	+5V1	O	5 V DC	5 V DC power to CPWB-L
	3	+5V1	O	5 V DC	5 V DC power to CPWB-L
	4	+24V1	O	24 V DC	24 V DC power to CPWB-L
	5	HUNITN	O	0/5 V DC	EVFSW: On/Off
	6	HANDSN	O	0/5 V DC	MPPS: On/Off
	7	N.C.	-	-	Not used
	8	HEATONN1	I	0/5 V DC	FH: On/Off
	9	ZCROSS	O	0/5 V DC (pulse)	Zero-cross signal
	10	SWSLEEPN	I	0/5 V DC	Sleep mode signal: On/Off
	11	+24V2	O	24 V DC	24 V DC power to CPWB-L (via ILSW)
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	GND	-	-	Ground
	16	+24V2	O	24 V DC	24 V DC power to CPWB-L (via ILSW)
	17	+24V2	O	24 V DC	24 V DC power to CPWB-L (via ILSW)

2-3-2 Engine PWB




Figure 2-3-2 Engine PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC5	1	OPSDO	O	0/5 V DC (pulse)	Serial communication data signal output
Connected to connect-L PWB	2	+24V2	I	24 V DC	24 V DC power from CPWB-L (via ILSW)
	3	+24V2	I	24 V DC	24 V DC power from CPWB-L (via ILSW)
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	+24V1	I	24 V DC	24 V DC power from CPWB-L
	10	+5V1	I	5 V DC	5 V DC power from CPWB-L
	11	+5V1	I	5 V DC	5 V DC power from CPWB-L
	12	+5V1	I	5 V DC	5 V DC power from CPWB-L
	13	+5V2	O	5 V DC	5 V DC power to CPWB-L
YC7	1	GND	-	-	Ground
Connected to lift sensor	2	LIFTSEN	I	0/5 V DC	LS: On/Off
	3	+5V2	O	5 V DC	5 V DC power to LS
YC9	1	WETCLK2	O	0/5 V DC (pulse)	TEMS clock signal
Connected to connect-R PWB			I	Analog	TEMS detection voltage (humidity)
	2	WETCLK1	O	0/5 V DC (pulse)	TEMS clock signal
	3	+5V1	O	5 V DC	5 V DC power to CPWB-R
	4	AIRTEMP	I	Analog	TEMS detection voltage (temperature)
	5	RFANDRN	O	0/12/24 V DC	RFM: Full speed/Half speed/Off
	6	+24V1	O	24 V DC	24 V DC power to CPWB-R
	7	MPFDRN	O	0/24 V DC	MPSOL: On/Off
	8	OUTB2	O	0/24 V DC (pulse)	SBM drive control signal
	9	OUTB1	O	0/24 V DC (pulse)	SBM drive control signal
	10	OUTA2	O	0/24 V DC (pulse)	SBM drive control signal
	11	OUTA1	O	0/24 V DC (pulse)	SBM drive control signal
	12	GND	-	-	Ground
YC11	1	+24V4	O	24 V DC	24 V DC power to DRM
Connected to drum motor	2	GND	-	-	Ground
	3	DMOTRDYN	I	0/5 V DC	DRM ready signal
	4	DMOTCLK	O	0/5 V DC (pulse)	DRM clock signal
	5	DMOTONN	O	0/5 V DC	DRM: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC12	1	POLRDYN	I	0/5 V DC	PM ready signal
Connected to main PWB	2	POLONN	O	0/5 V DC	PM: On/Off
	3	OUTPEN	O	0/5 V DC	Laser output enable signal
	4	PDMASKN	O	0/5 V DC	Horizontal synchronizing signal
	5	SBSY	O	0/5 V DC	Serial busy signal
	6	SDIR	O	0/5 V DC	Serial communication direction change signal
	7	EGIRN	O	0/5 V DC	Engine interruption signal
	8	EGSI	I	0/5 V DC (pulse)	Serial communication data signal input
	9	EGSO	O	0/5 V DC (pulse)	Serial communication data signal output
	10	SCKN	I	0/5 V DC (pulse)	Serial communication clock signal
	11	EECLK			
	12	EEDIO			
	13	POLCLK			
	14	+24V5	O	24 V DC	24 V DC power to MPWB
	15	+5V1	O	5 V DC	5 V DC power to MPWB
	16	+5V1	O	5 V DC	5 V DC power to MPWB
	17	+5V1	O	5 V DC	5 V DC power to MPWB
	18	GND	-	-	Ground
	19	GND	-	-	Ground
	20	GND	-	-	Ground
	21	+24V4	O	24 V DC	24 V DC power to MPWB
	22	GND	-	-	Ground
YC15	1	+5V1	O	5 V DC	5 V DC power to FFM
Connected to feed fan motor	2	FFANDRN	O	0/2.5/5 V DC	FFM: Full speed/Half speed/Off
YC501	1	+24V4	O	24 V DC	24 V DC power to MM
Connected to main motor	2	GND	-	-	Ground
	3	MMOTONN	O	0/5 V DC	MM ready signal
	4	MMOTRDYN	I	0/5 V DC	MM clock signal
	5	MMOTCLK	O	0/5 V DC (pulse)	MM: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC502 Connected to connect-R PWB	1	LMOTON	O	0/24 V DC	LM: On/Off
	2	DUDRN	O	0/24 V DC	DUCL: On/Off
	3	DLPDRN	O	0/24 V DC	DEVSOL: On/Off
	4	MIDDRN	O	0/24 V DC	MCL: On/Off
	5	+24V2	O	24 V DC	24 V DC power to CPWB-R
	6	+24V2	O	24 V DC	24 V DC power to CPWB-R
	7	REGDRN	O	0/24 V DC	RCL: On/Off
	8	FEEDDRN	O	0/24 V DC	PFCL: On/Off
	9	EXITFAN	O	0/24 V DC	EFM: On/Off
YC503	1	NC	-	-	Not used
Connected to connect-L PWB	2	HEATONN1	O	0/5 V DC	FH: On/Off
	3	ZCROSS	I	0/5 V DC (pulse)	Zero-cross signal
	4	SWSLEEPN	O	0/5 V DC	Sleep mode signal: On/Off
	5	HANDSN	I	0/5 V DC	MPPS: On/Off
	6	HPAP	I	0/5 V DC	EVFSW: On/Off
	7	SWFAN	O	0/24 V DC	PSFM: On/Off
	8	CASET	I	Analog	CSSW detection voltage
	9	TNMOT	O	0/24 V DC	TM: On/Off
	10	TNLEVEL	I	Analog	TS detection voltage
YC504	1	OPSDI	I	0/5 V DC (pulse)	Serial communication data signal input
Connected to connect-L PWB	2	OPSEL2	O	0/5 V DC	Paper feeder select signal (2)
	3	OPSEL1	O	0/5 V DC	Paper feeder select signal (1)
	4	OPSEL0	O	0/5 V DC	Paper feeder select signal (0)
	5	OPRDYN	I	0/5 V DC	Paper feeder ready signal
	6	OPSCCLK	O	0/5 V DC (pulse)	Serial communication clock signal
	7	WTNLEDN	O	0/5 V DC (pulse)	WTS (light emission) control signal
	8	ERASER	O	24/0 V DC	CL: On/Off
	9	EEDIO	I/O	0/5 V DC (pulse)	DRPWB EEPROM data signal
	10	EECLK	O	0/5 V DC (pulse)	DRPWB clock signal
	11	LFANDRN	O	0/12/24 V DC	LFM: Full speed/Half speed/Off
	12	WTNFUL	I	0/5 V DC (pulse)	WTS detection signal

Connector	Pin	Signal	I/O	Voltage	Description
YC506 Connected to fuser unit	1	FUSER-L	I	2 to 5 V DC	EVSW-L detection voltage
	2	FUSER-R	I	2 to 5 V DC	EVSW-R detection voltage
	3	+5V1	O	5 V DC	5 V DC power to fuser unit
	4	THERM3	-	-	Not used
	5	+5V2	O	5 V DC	5 V DC power to ES
	6	EXITPAP	I	0/5 V DC	ES: On/Off
	7	GND	-	-	Ground
	8	THERM1	I	Analog	FTH1 detection voltage
	9	+5V1	O	5 V DC	5 V DC power to FTH1
	10	FDDRNR	O	0/24 V DC	FSSOL: On/Off
	11	+24V2	O	24 V DC	24 V DC power to FSSOL
	12	FUDRN	O	0/24 V DC	FSSOL: On/Off
	13	+5V2	O	5 V DC	5 V DC power to DUS
	14	DUPAP	I	0/5 V DC	DUS: On/Off
	15	GND	-	-	Ground
	16	+5V1	O	5 V DC	5 V DC power to FTH2
	17	THERM2	I	Analog	FTH2 detection voltage

2-3-3 Main PWB




Figure 2-3-3 Main PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC8	1	LAMP	O	0/24 V DC	EL drive signal
Connected to CCD PWB	2	NC	-	-	Not used
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	HPSW	I	0/3.3 V DC	HPS: On/Off
	6	+3.3V	O	3.3 V DC	3.3 V DC power to CCDPWB
	7	GND	-	-	Ground
	8	CCDRSN	O	LVDS	CCD reset signal
	9	CCDRSP	O	LVDS	CCD reset signal
	10	GND	-	-	Ground
	11	CCDCLPP	O	LVDS	CCD clamp signal
	12	CCDCLPN	O	LVDS	CCD clamp signal
	13	GND	-	-	Ground
	14	CCDPH1N	O	LVDS	CCD shift register clock signal
	15	CCDPH1P	O	LVDS	CCD shift register clock signal
	16	GND	-	-	Ground
	17	CCDPH2P	O	LVDS	CCD shift register clock signal
	18	CCDPH2N	O	LVDS	CCD shift register clock signal
	19	GND	-	-	Ground
	20	CCDSH	O	0/3.3 V DC	CCD shift gate signal
	21	CCDSW	O	0/3.3 V DC	CCD color/BW change signal
	22	GND	-	-	Ground
	23	CCDDATAR	I	Analog	CCD image output signal (R)
	24	GND	-	-	Ground
	25	CCDDATAG	I	Analog	CCD image output signal (G)
	26	GND	-	-	Ground
	27	CCDDATAB	I	Analog	CCD image output signal (B)
	28	GND	-	-	Ground
	29	+12V	O	DC12V	12 V DC power to CCDPWB
	30	NC	-	-	Not used
	31	+5V1	O	5 V DC	5 V DC power to CCDPWB
	32	+5V1	O	5 V DC	5 V DC power to CCDPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC13	1	POLRDYN	O	0/5 V DC	PM ready signal
Connected to engine PWB	2	POLONN	I	0/5 V DC	PM: On/Off
	3	OUTPEN	I	0/5 V DC	Laser output enable signal
	4	PDMASKN	I	0/3.3 V DC	Horizontal synchronizing signal
	5	SBSY	I	0/3.3 V DC	Serial busy signal
	6	SDIR	I	0/3.3 V DC	Serial communication direction change signal
	7	EGIRN	I	0/3.3 V DC	Engine interruption signal
	8	EGSI	O	0/3.3 V DC (pulse)	Serial communication data signal input
	9	EGSO	I	0/3.3 V DC (pulse)	Serial communication data signal output
	10	SCKN	O	0/3.3 V DC (pulse)	Serial communication clock signal
	11	EECLK			
	12	EEDIO			
	13	POLCLK			
YC14	1	+24V5	O	24 V DC	24 V DC power to PM
Connected to laser scanner unit	2	GND	-	-	Ground
	3	POLONN	O	0/5 V DC	PM: On/Off
	4	POLRDYN	I	0/5 V DC	PM ready signal
	5	POLCLK	O	0/5 V DC (pulse)	Serial communication clock signal
	6	GND	-	-	Ground
	7	VATAN1	O		Video data signal (-)
	8	VDATAP1	O		Video data signal (+)
	9	OUTPEN	O	0/5 V DC	Laser output enable signal
	10	SAMPLEN1	O	0/3.3 V DC	Sample/hold signal
	11	+5V3		5 V DC	5 V DC power to APCPWB
	12	NC	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC16 Connected to FAX control PWB	A1	NC	-	-	Not used
	B1	NC	-	-	Not used
	A2	NC	-	-	Not used
	B2	TXDREQ	I	0/3.3 V DC	Transmission DMA request signal
	A3	AUDIO	I	0/3.3 V DC	Audio signal
	B3	3.3V	O	3.3 V DC	3.3 V DC power output
	A4	3.3V	O	3.3 V DC	3.3 V DC power output
	B4	A15	O	0/3.3 V DC (pulse)	Address bus signal
	A5	GND	-	-	Ground
	B5	A14	O	0/3.3 V DC (pulse)	Address bus signal
	A6	A13	O	0/3.3 V DC (pulse)	Address bus signal
	B6	A12	O	0/3.3 V DC (pulse)	Address bus signal
	A7	A11	O	0/3.3 V DC (pulse)	Address bus signal
	B7	A10	O	0/3.3 V DC (pulse)	Address bus signal
	A8	A9	O	0/3.3 V DC (pulse)	Address bus signal
	B8	A8	O	0/3.3 V DC (pulse)	Address bus signal
	A9	GND	-	-	Ground
	B9	A7	O	0/3.3 V DC (pulse)	Address bus signal
	A10	A6	O	0/3.3 V DC (pulse)	Address bus signal
	B10	A5	O	0/3.3 V DC (pulse)	Address bus signal
	A11	A4	O	0/3.3 V DC (pulse)	Address bus signal
	B11	A3	O	0/3.3 V DC (pulse)	Address bus signal
	A12	A2	O	0/3.3 V DC (pulse)	Address bus signal
	B12	A1	O	0/3.3 V DC (pulse)	Address bus signal
	A13	GND	-	-	Ground
	B13	3.3V	-	3.3 V DC	3.3 V DC power output
	A14	OP2IFN	O	0/3.3 V DC	Select signal
	B14	OP2ACKN	I	0/3.3 V DC (pulse)	OP2ACKN signal
	A15	OP2IRN	I	0/3.3 V DC	Interruption signal
	B15	5V	-	5 V DC	5 V DC power output
	A16	RDY	O	0/3.3 V DC	Ready signal
	B16	RXDREQ	I	0/3.3 V DC	Reception DMA request signal
	A17	GND	-	-	Ground
	B17	RXDMACKN	O	0/3.3 V DC (pulse)	Reception DMAACK signal
	A18	IORN	O	0/3.3 V DC	Read enable signal
	B18	IOWN	O	0/3.3 V DC	Write enable signal
	A19	RESETN	O	0/3.3 V DC	Reset signal

Connector	Pin	Signal	I/O	Voltage	Description
YC16	B19	TXDMAACKN	I	0/3.3 V DC	Transmission DMAACK signal
Connected to FAX control PWB	A20	D15	I/O	0/3.3 V DC (pulse)	Data bus signal
	B20	D14	I/O	0/3.3 V DC (pulse)	Data bus signal
	A21	GND	-	-	Ground
	B21	D13	I/O	0/3.3 V DC (pulse)	Data bus signal
	A22	D12	I/O	0/3.3 V DC (pulse)	Data bus signal
	B22	D11	I/O	0/3.3 V DC (pulse)	Data bus signal
	A23	D10	I/O	0/3.3 V DC (pulse)	Data bus signal
	B23	D9	I/O	0/3.3 V DC (pulse)	Data bus signal
	A24	D8	I/O	0/3.3 V DC (pulse)	Data bus signal
	B24	D7	I/O	0/3.3 V DC (pulse)	Data bus signal
	A25	GND	-	-	Ground
	B25	D6	I/O	0/3.3 V DC (pulse)	Data bus signal
	A26	D5	I/O	0/3.3 V DC (pulse)	Data bus signal
	B26	D4	I/O	0/3.3 V DC (pulse)	Data bus signal
	A27	D3	I/O	0/3.3 V DC (pulse)	Data bus signal
	B27	D2	I/O	0/3.3 V DC (pulse)	Data bus signal
	A28	D1	I/O	0/3.3 V DC (pulse)	Data bus signal
	B28	D0	I/O	0/3.3 V DC (pulse)	Data bus signal
	A29	GND	-	-	Ground
	B29	NC	-	-	Not used
	A30	NC	-	-	Not used
	B30	NC	-	-	Not used
YC41	1	+24V6	0	DC24V	24 V DC power output to CONFM
Connected to controller fan motor	2	CONTFANDRN	0	DC0V/24V (pulse)	CONFM driving control signal
YC100	1	VBUS	O	5 V DC	5 V DC power output
Connected to operation panel PWB	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC101	1	GND	-	-	Ground
Connected to operation panel PWB	2	PANEL_STAT US	O	DC0V/3.3V	Operation panel status signal
	3	INT_POWER KEY_N	O	DC0V/3.3V	Power key?On/Off
	4	PANEL_RESE T	O	DC0V/3.3V	Reset signal
	5	AUDIO	O	Analog	Audio output signal
	6	LIGHTOFF_P OWERON	O	DC0V/3.3V	Sleep return signal
	7	SHUTDOWN	O	DC0V/3.3V	24V down signal
	8	LED_PROCE SSIING_N	O	DC0V/3.3V	Processing LED control signal
	9	LED_ATTENS ION_N	O	DC0V/3.3V	Attention LED control signal
	10	LED_MEMOR Y_N	O	DC0V/3.3V	Memory LED control signal
	11	SUSPEND_P OWER	O	DC3.3V	3.3 V DC power output to OPPWB
	12	ENERGY_SA VE	O	DC0V/3.3V	Energy save signal
	13	BEEP_POWE RON	O	DC0V/3.3V	Sleep return signal
YC102	1	+5V2	O	DC5V	5 V DC power output to OPPWB
Connected to operation panel PWB	2	+5V2	O	DC5V	5 V DC power output to OPPWB
	3	+5V2	O	DC5V	5 V DC power output to OPPWB
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	NC	-	-	Not used
YC107	1	VBUS	O	5 V DC	5 V DC power output
Connected to USB	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC108 Connected to IC card reader	1	VBUS	O	DC5V	5 V DC power output
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	NC	-	-	Not used
	5	GND	-	-	Ground
YC110 Connected to ethernet	1	TCT	O	3.3 V DC	3.3 V DC power output
	2	TD+	O	0/3.3 V DC (pulse)	Transmission data
	3	TD-	O	0/3.3 V DC (pulse)	Transmission data
	4	RD+	I	0/3.3 V DC (pulse)	Received data
	5	RD-	I	0/3.3 V DC (pulse)	Received data
	6	RCT	O	3.3 V DC	3.3 V DC power output
	7	100B_LED_K	-	-	100 Base/10 Base display
	8	100B_LED_A	-	-	100 Base/10 Base display
	9	LINK_LED_K	-	-	LINK LED
	10	LINK_LED_A	-	-	LINK LED
YC119 Connected to USB	U1	VBUS	O	5 V DC	5 V DC power output
	U2	DATA-	I/O	-	USB data signal
	U3	DATA+	I/O	-	USB data signal
	U4	GND	-	-	Ground
YC215 Connected to engine PWB	1	+24V5	I	24 V DC	24 V DC power from EPWB
	2	+5V1	I	5 V DC	5 V DC power from EPWB
	3	+5V1	I	5 V DC	5 V DC power from EPWB
	4	GND	-	-	Ground
	5	+5V1	I	5 V DC	5 V DC power from EPWB
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	+24V4	I	24 V DC	24 V DC power from EPWB
YC216 Connected to PD PWB	1	+3.3V	-	3.3 V DC	3.3 V DC power to PDPWB
	2	PDN	I	0/5 V DC (pulse)	Horizontal synchronizing signal
	3	GND	-	-	Ground
YC1001 Connected to connect-L PWB	1	+24V1	I	24 V DC	24 V DC power from CPWB-L
	2	NC	-	-	Not used
	3	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC1004 Connected to ISU motor	1	SCMOT1A	O	0/24 V DC (pulse)	ISUM drive control signal
	2	SCMOT2B	O	0/24 V DC (pulse)	ISUM drive control signal
	3	SCMOT1B	O	0/24 V DC (pulse)	ISUM drive control signal
	4	SCMOT2A	O	0/24 V DC (pulse)	ISUM drive control signal
YC1008 Connected to DP drive PWB	1	MOT1A	O	0/24 V DC (pulse)	DPPFM drive control signal
	2	MOT2A	O	0/24 V DC (pulse)	DPPFM drive control signal
	3	MOT1B	O	0/24 V DC (pulse)	DPPFM drive control signal
	4	MOT2B	O	0/24 V DC (pulse)	DPPFM drive control signal
	5	+24V6	O	24 V DC	24 V DC power to PDPWB
	6	GND	-	-	Ground
YC1009 Connected to DP drive PWB	1	FEEDCL	O	0/24 V DC	DPPFCL: On/Off
	2	REVSOL	O	0/24 V DC	DPSBSOL: On/Off
	3	PRESOLN	O	0/24 V DC	DPPRSOL: On (Press)/Off
	4	RELSOLN	O	0/24 V DC	DPPRSOL: On (Release)/Off
	5	DPDET N	I	0/3.3 V DC	DP set signal
	6	OPSWN	I	0/3.3 V DC	DPOCS: On/Off
	7	ORGSWN	I	0/3.3 V DC	DPOS: On/Off
	8	TIMSWN	I	0/3.3 V DC	DPTS: On/Off
	9	GND	-	-	Ground
	10	+3.3V	O	3.3 V DC	3.3 V DC power to DPDPWB

2-3-4 Connect-L PWB




Figure 2-3-4 Connect-L PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	+24V2	I	24 V DC	24 V DC power from PSPWB (via ILSW)
Connected to power source PWB	2	+24V2	I	24 V DC	24 V DC power from PSPWB (via ILSW)
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	+24V2	I	24 V DC	24 V DC power from PSPWB (via ILSW)
	8	SWSLEEPN	O	0/5 V DC	Sleep mode signal: On/Off
	9	ZCROSS	I	0/5 V DC (pulse)	Zero-cross signal
	10	HEATONN1	O	0/5 V DC	FH: On/Off
	11	N.C.	-	-	Not used
	12	HANDSN	I	0/5 V DC	MPPS: On/Off
	13	HUNITN	I	0/5 V DC	EVFSW: On/Off
	14	+24V1	I	24 V DC	24 V DC power from PSPWB
	15	+5V1	I	5 V DC	5 V DC power from PSPWB
	16	+5V1	I	5 V DC	5 V DC power from PSPWB
	17	+5V1	I	5 V DC	5 V DC power from PSPWB
YC2	1	+24V1	O	24 V DC	24 V DC power to paper feeder
Connected to paper feeder	2	OPCLK	O	0/5 V DC (pulse)	Serial communication clock signal
	3	+5V1	O	5 V DC	5 V DC power to paper feeder
	4	OPRDYN	I	0/5 V DC	Paper feeder ready signal
	5	OPSEL0	O	0/5 V DC	Paper feeder select signal (0)
	6	OPSEL1	O	0/5 V DC	Paper feeder select signal (1)
	7	OPSEL2	O	0/5 V DC	Paper feeder select signal (2)
	8	OPSDI	I	0/5 V DC (pulse)	Serial communication data signal input
	9	OPSDO	O	0/5 V DC (pulse)	Serial communication data signal output
	10	GND	-	-	Ground
YC3	1	GND	-	-	Ground
Connected to drum PWB	2	ERASER	O	0/24 V DC	CL: On/Off
	3	GND	-	-	Ground
	4	WTNLEDN	O	0/5 V DC (pulse)	WTS (light emission) control signal
	5	EECLK	O	0/5 V DC (pulse)	DRPWB clock signal
	6	WTNFUL	I	0/5 V DC (pulse)	WTS detection signal
	7	EEDIO	I/O	0/5 V DC (pulse)	DRPWB EEPROM data signal
	8	+5V2	O	5 V DC	5 V DC power to DRPWB
	9	GND	-	-	Ground
	10	+5V2	O	5 V DC	5 V DC power to DRPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC4 Connected to left fan motor	1	+24V1	O	24 V DC	24 V DC power to LFM
	2	LFANDRN	O	0/12/24 V DC	LFM: Full speed/Half speed/Off
YC5 Connected to paper full sensor	1	GND	-	-	Ground
	2	FDPFULN	I	0/5 V DC	PFS: On/Off
	3	+5V2	O	5 V DC	5 V DC power to PFS
YC6 Connected to engine PWB	1	WTNFUL	O	0/5 V DC (pulse)	WTS detection signal
	2	LFANDRN	I	0/12/24 V DC	LFM: Full speed/Half speed/Off
	3	EECLK	I	0/5 V DC (pulse)	DRPWB clock signal
	4	EEDIO	I/O	0/5 V DC (pulse)	DRPWB EEPROM data signal
	5	ERASER	I	24/0 V DC	CL: On/Off
	6	WTNLEDN	I	0/5 V DC (pulse)	WTS (light emission) control signal
	7	OPSCLK	I	0/5 V DC (pulse)	Serial communication clock signal
	8	OPRDYN	O	0/5 V DC	Paper feeder ready signal
	9	OPSEL0	I	0/5 V DC	Paper feeder select signal (0)
	10	OPSEL1	I	0/5 V DC	Paper feeder select signal (1)
	11	OPSEL2	I	0/5 V DC	Paper feeder select signal (2)
	12	OPSDI	O	0/5 V DC (pulse)	Serial communication data signal output
YC7 Connected to engine PWB	1	OPSDO	I	0/5 V DC (pulse)	Serial communication data signal output
	2	+24V2	O	24 V DC	24 V DC power to EPWB (via ILSW)
	3	+24V2	O	24 V DC	24 V DC power to EPWB (via ILSW)
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	+24V1	O	24 V DC	24 V DC power to EPWB
	10	+5V1	O	5 V DC	5 V DC power to EPWB
	11	+5V1	O	5 V DC	5 V DC power to EPWB
	12	+5V1	O	5 V DC	5 V DC power to EPWB
	13	+5V2	I	5 V DC	5 V DC power from EPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC8	1	TNLEVEL	O	Analog	TS detection voltage
Connected to engine PWB	2	TNMOT	I	0/24 V DC	TM: On/Off
	3	CASET	O	Analog	CSSW detection voltage
	4	SWFAN	I	0/24 V DC	PSFM: On/Off
	5	HPAP	O	0/5 V DC	EVFSW: On/Off
	6	HANDSN	O	0/5 V DC	MPPS: On/Off
	7	SWSLEEPN	I	0/5 V DC	Sleep mode signal: On/Off
	8	ZCROSS	O	0/5 V DC (pulse)	Zero-cross signal
	9	HEATONN1	I	0/5 V DC	FH: On/Off
	10	NC	-	-	Not used
YC9	1	RFDATA	I/O	0/5 V DC (pulse)	RFID data signal
Connected to developing PWB	2	TNMOT	O	0/24 V DC	TM: On/Off
	3	TNLEVEL	I	Analog	TS detection voltage
	4	+5V2	O	5 V DC	5 V DC power to DEVPWB
	5	GND	-	-	Ground
	6	RFCLK	O	0/5 V DC (pulse)	RFID clock signal
YC10	1	CAS2	I	0/5 V DC	CSSW: On/Off
Connected to cassette size switch	2	CAS1	I	0/5 V DC	CSSW: On/Off
	3	CASET	I	Analog	CSSW detection voltage
	4	CAS0	I	0/5 V DC	CSSW: On/Off
YC11	1	+24V1	O	24 V DC	24 V DC power to PSFM
Connected to power source fan motor	2	SWFAN	O	0/24 V DC	PSFM: On/Off
YC12	1	+24V1	O	24 V DC	24 V DC power to MPWB
Connected to main PWB	2	GND	-	-	Ground
YC13	1	RELAY	O	0/5 V DC	Relay mode signal: On/Off
Connected to relay PWB	2	GND	-	-	Ground

2-3-5 Connect-R PWB




Figure 2-3-5 Connect-R PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1	1	GND	-	-	Ground
Connected to engine PWB	2	OUTA1	I	0/24 V DC (pulse)	SBM drive control signal
	3	OUTA2	I	0/24 V DC (pulse)	SBM drive control signal
	4	OUTB1	I	0/24 V DC (pulse)	SBM drive control signal
	5	OUTB2	I	0/24 V DC (pulse)	SBM drive control signal
	6	MPFDRN	I	0/24 V DC	MPSOL: On/Off
	7	+24V1	I	24 V DC	24 V DC power from EPWB
	8	RFANDRN	I	0/12/24 V DC	RFM: Full speed/Half speed/Off
	9	AIRTEMP	O	Analog	TEMS detection voltage (temperature)
	10	+5V1	I	5 V DC	5 V DC power from EPWB
	11	WETCLK1	I	0/5 V DC (pulse)	TEMS clock signal
	12	WETCLK2	I	0/5 V DC (pulse)	TEMS clock signal
			O	Analog	TEMS detection voltage (humidity)
YC2	1	LMOTON	I	0/24 V DC	LM: On/Off
Connected to engine PWB	2	DUDRN	I	0/24 V DC	DUCL: On/Off
	3	DLPDRN	I	0/24 V DC	DEVSOL: On/Off
	4	MIDDRN	I	0/24 V DC	MCL: On/Off
	5	+24V2	I	24 V DC	24 V DC power from EPWB
	6	+24V2	I	24 V DC	24 V DC power from EPWB
	7	REGDRN	I	0/24 V DC	RCL: On/Off
	8	FEEDDRN	I	0/24 V DC	PFCL: On/Off
	9	EXITFAN	I	0/24 V DC	EFM: On/Off
YC3	1	OUTA1	O	0/24 V DC (pulse)	SBM drive control signal
Connected to switchback motor	2	OUTA2	O	0/24 V DC (pulse)	SBM drive control signal
	3	OUTB1	O	0/24 V DC (pulse)	SBM drive control signal
	4	OUTB2	O	0/24 V DC (pulse)	SBM drive control signal
YC4	1	+24V2	O	24 V DC	24 V DC power to DEVSOL
Connected to developing solenoid	2	DLPDRN	O	0/24 V DC	DEVSOL: On/Off
YC5	1	+24V2	O	24 V DC	24 V DC power to PFCL
Connected to paper feed clutch	2	FEEDDRN	O	0/24 V DC	PFCL: On/Off
YC6	1	+24V2	O	24 V DC	24 V DC power to RCL
Connected to registration clutch	2	REGDRN	O	0/24 V DC	RCL: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC7	1	+24V2	O	24 V DC	24 V DC power to MCL
Connected to middle clutch	2	MIDDRN	O	0/24 V DC	MCL: On/Off
YC8	1	LMOTON	O	0/24 V DC	LM: On/Off
Connected to lift motor	2	GND	-	-	Ground
YC9	1	+24V2	O	24 V DC	24 V DC power to DUCL
Connected to duplex clutch	2	DUDRN	O	0/24 V DC	DUCL: On/Off
YC10	1	+24V2	O	24 V DC	24 V DC power to MPSOL
Connected to MP solenoid	2	MPFDRN	O	0/24 V DC	MPSOL: On/Off
YC11	1	+24V1	O	24 V DC	24 V DC power to RFM
Connected to right fan motor	2	RFANDRN	O	0/12/24 V DC	RFM: Full speed/Half speed/Off
YC12	1	ATRTEMP	O	5 V DC	5 V DC power to FUSW
Connected to fuser unit switch	2	ATRTEMP2	I	0/5 V DC	FUSW: On/Off
YC13	1	+24V1	O	24 V DC	24 V DC power to EFM
Connected to eject fan motor	2	EXITFAN	O	0/24 V DC	EFM: On/Off

2-3-6 DP drive PWB




Figure 2-3-6 DP drive PWB silk-screen diagram


Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to main PWB	1	MOT1A	I	0/24 V DC (pulse)	DPPFM drive control signal
	2	MOT2A	I	0/24 V DC (pulse)	DPPFM drive control signal
	3	MOT1B	I	0/24 V DC (pulse)	DPPFM drive control signal
	4	MOT2B	I	0/24 V DC (pulse)	DPPFM drive control signal
	5	+24V6	I	24 V DC	24 V DC power from MPWB
	6	GND	-	-	Ground
YC2 Connected to DP open/close sensor, DP original sensor and DP timing sensor	1	PILED	O	3.3 V DC	3.3 V DC power to DPOCS
	2	GND	-	-	Ground
	3	OPSWN	I	0/3.3 V DC	DPOCS: On/Off
	4	PILED	O	3.3 V DC	3.3 V DC power to DPOS
	5	GND	-	-	Ground
	6	ORGSWN	I	0/3.3 V DC	DPOS: On/Off
	7	PILED	O	3.3 V DC	3.3 V DC power to DPTS
	8	GND	-	-	Ground
	9	TIMSWN	I	0/3.3 V DC	DPTS: On/Off
YC3 Connected to DP paper feed motor	1	DPMOT1A	O	0/24 V DC (pulse)	DPPFM drive control signal
	2	DPMOT2A	O	0/24 V DC (pulse)	DPPFM drive control signal
	3	DPMOT1B	O	0/24 V DC (pulse)	DPPFM drive control signal
	4	DPMOT2B	O	0/24 V DC (pulse)	DPPFM drive control signal
YC4 Connected to DP pressure solenoid	1	+24V6	O	24 V DC	24 V DC power to DPPRSOL
	2	PRESOLN	O	0/24 V DC	DPPRSOL: ON (Press)/Off
	3	RELSOLN	O	0/24 V DC	DPPRSOL: On (Release)/Off
YC5 Connected to DP switch-back solenoid	1	+24V6	O	24 V DC	24 V DC power to DPSBSOL
	2	REVSOL	O	0/24 V DC	DPSBSOL: On/Off
YC6 Connected to DP paper feed clutch	1	+24V6	O	24 V DC	24 V DC power to DPPFCL
	2	FEEDCL	O	0/24 V DC	DPPFCL: On/Off


Connector	Pin	Signal	I/O	Voltage	Description
YC8	1	+3.3V	I	3.3 V DC	3.3 V DC power from MPWB
Connected to main PWB	2	GND	-	-	Ground
	3	TIMSWN	O	0/3.3 V DC	DPTS: On/Off
	4	ORGSWN	O	0/3.3 V DC	DPOS: On/Off
	5	OPSWN	O	0/3.3 V DC	DPOCS: On/Off
	6	DPDETN	O	0/3.3 V DC	DP set signal
	7	RELSOLN	I	0/24 V DC	DPPRSOL: On (Release)/Off
	8	PRESOLN	I	0/24 V DC	DPPRSOL: ON (Press)/Off
	9	REVSOL	I	0/24 V DC	DPSBSOL: On/Off
	10	FEEDCL	I	0/24 V DC	DPPFCL: On/Off


This page is intentionally left blank.


2-4-1 Appendixes

(1) Wiring diagram







(2) Repetitive defects gauge

(3) Maintenance kits

Maintenance part name		Parts No.	Alternative part No.
Name used in service	Name used in parts list		
Maintenance kit (300,000 pages)	MK-350 B/MAINTENANCE KIT (OPTION)	1702LX7US0 1702LX8AS0 1702LX8NL0	072LX7US 072LX8AS 072LX8NL
Drum unit	DK-320	-	-
Developing unit	DV-350(E) B DV-352(U) B DV-354(AO) B	- - -	- - -
Fuser unit	FK-350(E) FK-350(U)	- -	- -
Retard roller assembly	RETARD ROLLER ASSY	-	-
Paper feed assembly	FEED HOLDER ASSY	-	-
Separation brush unit	DC BRUSH ASSY	-	-
Transfer roller	ROLLER TRANSFER ASSY	-	-
Maintenance kit (150,000 pages)	MK-370/MAINTENANCE KIT (OPTION)	1702LX0UN0	072LX0UN
DP forwarding pulley assembly	-	-	-
DP separation pad assembly	-	-	-

(4) Firmware Environment Commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO Commands for Reprogramming Firmware

The current settings of the FRPO parameters are listed as optional values on the service status page.

Note: Before changing any FRPO parameter, print out a service status page, so you will know the parameter values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command.(!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 11; EXIT;

FRPO Parameters

Environment	Parameter	Values	Factory setting
Top margin	A1	Integer value in inches	0
	A2	Fraction value in 1/100 inches	0
Left margin	A3	Integer value in inches	0
	A4	Fraction value in 1/100 inches	0
Page length	A5	Integer value in inches	16
	A6	Fraction value in 1/100 inches	61
Page width	A7	Integer value in inches	16
	A8	Fraction value in 1/100 inches	61
Default pattern resolution	B8	0: 300 dpi 1: 600 dpi	0
Page orientation	C1	0: Portrait 1: Landscape	0
Default font No. *	C2	Middle two digits of power-up font	0
	C3	Last two digits of power-up font	0
	C5	First two digits of power-up font	0
PCL font switch	C8	0:HP compatibility mode (Characters higher than 127 are not printed.) 32:Conventional mode (Characters higher than 127 are printed. Supported symbol sets: ISO-60 Norway [00D], ISO-15 Italian [00I], ISO-11 Sweden [00S], ISO-6 ASCII [00U], ISO-4 U.K. [01E], ISO-69 France [01F], ISO-21 Germany [01G], ISO-17 Spain [02S], Symbol [19M] ^a)	0
Print density	D4	Number from 1 (Light) to 5 (Dark)	3
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (0 to 99).	1

Environment	Parameter	Values	Factory setting
Setting of AGFA	I6	Place of 0: Setting of memory of rasterizer of AGFA Place of ten: Font cache mode of FM	0
KIR mode	N0	0: Off 2: On	2
Duplex binding	N4	0: Off 1: Long edge 2: Short edge	0
Sleep timer time-out time	N5	1 to 240 minutes [0: Off]	1
Ecoprint level	N6	0: Off 2: On	0
Function switch in Duplex mode	N7	0: It skips to next page 1: Disregard	0
Default emulation mode	P1	0: Line Printer 1: IBM Proprinter X24E 2: Diablo 630 5: Epson LQ-850 6: PCL 6 9: KPDL	6
Carriage-return action *	P2	0: Ignores 0x0d 1: Carriage-return 2: Carriage-return + linefeed	1
Linefeed action *	P3	0: Ignores 0x0d 1: Linefeed 2: Linefeed + carriage-return	1
Automatic emulation sensing (For KPDL3)	P4	0: AES disabled 1: AES enabled	0
Alternative emulation (For KPDL3)	P5	Same as the P1 values except that 9 is ignored.	6
Automatic emulation switching trigger (For KPDL3)	P7	0: Page eject commands 1: None 2: Page eject and Prescribe EXIT 3: Prescribe EXIT 4: Formfeed (^L) 6: Page eject, Prescribe EXIT and formfeed 10: Page eject commands; if AES fails, resolves to KPDL	10
Command recognition character	P9	ASCII code of 33 to 126	82 (R)

Environment	Parameter	Values	Factory setting
Default paper size	R2	0: Size of the default paper cassette (See R4.) 1: Monarch (3-7/8 × 7-1/2 inches) 2: Business (4-1/8 × 9-1/2 inches) 3: International DL (11 × 22 cm) 4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: JIS B5 (18.2 × 25.7 cm) 13: ISO A5 14: A6 (10.5 × 14.8 cm) 15: JIS B6 (12.8 × 18.2 cm) 16: Commercial #9 (3-7/8 × 8-7/8 inches) 17: Commercial #6 (3-5/8 × 6-1/2 inches) 18: ISO B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches)f 20: B4 → A4 reduces 21: A3 → A4 reduces 22: A4 → A4 98% reduces 23: Stock form → A4 reduces 31: Hagaki (10 × 14.8 cm)f 32: Ofuku-Hagaki (14.8 × 20 cm)f 33: Officio II 40: 16K 50: Statement 51: Folio 52: Youkei 2 53: Youkei 4	0
Margin setting of emulation	R3	0: Interchangeable to HP 1: All PCL print area	0
Default cassette	R4	0: Multi-purpose tray 1 1: Cassette 1 2: Cassette 2 3: Cassette 3 4: Cassette 4	1
MP tray paper size	R7	Same as the R2 values except: 0	8 (A4)
A4/letter equation	S4	0: Off 1: On	0
Host buffer size	S5	0: 10kB (x H8) 1: 100kB (x H8) 2: 1024kB (x H8)	1
RAM disk size	S6	1 to 1024 MB	400
RAM disk mode	S7	0: Off 1: On	0

Environment	Parameter	Values	Factory setting
Wide A4	T6	0:Off 1:On	0
Line spacing *	U0	Lines per inch (integer value)	6
Line spacing *	U1	Lines per inch (fraction value)	0
Character spacing *	U2	Characters per inch (integer value)	10
Character spacing *	U3	Characters per inch (fraction value)	0
KPDL interpreter mode according to I/F	U4	0: ASCII (text mode) 1: Binary (binary mode)	1
Country code	U6	0: US-ASCII 1: France 2: Germany 3: UK 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US Legal 10: IBM PC-850 (Multilingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 21: US ASCII (U7=50 SET) 77: HP Roman-8 (U7=52 SET)	41
Code set at power up in daisywheel emulation	U7	0: Same as the default emulation mode (P1) 1: IBM 6: IBM PC-8 50: US ASCII (U6=21 SET) 52: HP Roman-8 (U6=77 SET)	53
Font pitch for fixed pitch scalable font	U8	Integer value in cpi: 0 – 99	10
	U9	Fraction value in 1/100 cpi: 0 – 99	0
Font height for the default scalable font *	V0	Integer value in 100 points: 0–9	0
	V1	Integer value in points: 0–99	12
	V2	Fraction value in 1/100 points: 0, 25, 50, 75	0
Default scalable font *	V3	Name of typeface of up to 32 characters, enclosed with single or double quotation marks	Courier

Environment	Parameter	Values	Factory setting
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular letter Gothic = regular	5
Paper type for the MP tray	X0	1: Plain 1 2: Transparency 3: Preprinted 4: Label 5: Bond 6: Recycle 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 16: Thick 17: High Quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
Paper type for paper cassettes 1	X1	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High Quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1

Environment	Parameter	Values	Factory setting
Paper type for paper cassettes 2 to 4	X2 X3 X4	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High Quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
PCL paper source	X9	0: Performs paper selection depending on media type. 1: Performs paper selection depending on paper sources.	0
Automatic continue for 'Press GO'	Y0	0:Off 1:On	0
Automatic continue timer	Y1	number from 0 to 99 in increments of 5 seconds	6 (30seconds)
Error message for device error	Y3	0:Not Detect 1:Detect	127
Duplex operation for specified paper type (Prepunched, Preprintedand Letter-head)	Y4	0:Off 1:On	0
Default operation for PDF direct printing	Y5	0: Enlarges or reduces the image to fit in the current paper size. Loads paper from the current paper cassette. 1: Through the image. Loads paper which is the same size as the image. 2: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. 3: Through the image. Loads Letter, A4 size paper depending on the image size. 8: Through the image. Loads paper from the current paper cassette. 9: Through the image. Loads Letter, A4 size paper depending on the image size. 10: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the imagesize.	0

- a. Characters higher than 127 are printed regardless of the C8 value. However, setting C8 to 0 does not print character code 160.

*. Ignored in some emulation modes.

(5) Maintenance Commands

This section provides information on how to use the maintenance command and its parameters using examples.

Adjusting the print start timing (alternative command for the maintenance mode U034)

Description

Adjusts the leading edge registration or left edge.

Purpose


Make the adjustment if there is a regular error between the leading edges of the copy image and original.


Make the adjustment if there is a regular error between the left edges of the copy image and original.

Format	!R! KCFG“PFRC”,#1 ,#2 ,#3;	
Parameter	#1	Paper source number 0: MP tray 2-6 : Cassette2-6 100: Duplex (e.g. landscape images short-edge bind) 200: Rotated duplex (e.g. portrait images long-edge bind)
	#2	Edge to adjust 1: Leading edge 2: Left edge
	#3	Adjustable range (-128 to +127) number of dot in 600dpi

Example: Set the leading edge of MP tray to +30 dots

!R! KCFG “PFRC”,0,1,30;EXIT;





Adjusting the scanner magnification (alternative command for the maintenance mode U065)**Description**

Adjusts the magnification of the original scanning.

Purpose


Make the adjustment if the magnification in the main scanning direction is incorrect.

Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.



Format	!R! KCFG "SCAN",8, #1,#2;EXIT;	
Parameter	#1	1: Y SCAN ZOOM Scanner magnification in the main scanning direction 2: X SCAN ZOOM Scanner magnification in the auxiliary scanning direction
	#2	#1=1: Adjustable range: -32 to 127 (in 0.1% increment) (0: default) #2=2 : Adjustable range: -25 to 25 (in 0.1% increment) (0: default)

Example: Y SCAN ZOOM set to 55, X SCAN ZOOM set to 10


!R! KCFG "SCAN",8,1,55; KCFG "SCAN",8,2,10;EXIT;





Original

Copy
example 1Copy
example 2

Magnified in the main
scanning direction



Original

Copy
example 1Copy
example 2

Magnified in the auxiliary
scanning direction

Adjusting the scanner leading edge registration (alternative command for the maintenance U066)

Description

Adjusts the scanner leading edge registration of the original scanning.


Purpose

Make the adjustment if there is a regular error between the leading edges of the copy image and original.

Format	!R! KCFG "SCAN",5,#1,#2;EXIT;	
Parameter	#1	1: Scanner leading edge registration 2: Scanner leading edge registration of rotated scan
	#2	Adjustable range: -45 to 45 (in 0.086mm increment) (0: default)

Example: Scanner leading edge registration set to 10 to increase 0.86mm

!R! KCFG "SCAN",5,1,"10";EXIT;



Adjusting the scanner center line (alternative command for the maintenance mode U067)

Description

Adjusts the scanner center line of the original scanning.

Purpose


Make the adjustment if there is a regular error between the center lines of the copy image and original.

Format	!R! KCFG "SCAN",6, #1;#2;EXIT;	
Parameter	#1	1: Scanner center line 2: Scanner center line of rotated scan
	#2	#1=1: Adjustable range: -70 to 70 (in 0.086mm increment) (0: default) #1=2: Adjustable range: -40 to 40 (in 0.086mm increment) (0: default)

Example: Scanner leading edge registration set to 20 to increase 1.72mm

!R! KCFG "SCAN",6,1,20;EXIT;

Scanner center line (within ± 2.0 mm)



Adjusting the scanning position for originals from the DP (alternative command for the maintenance mode U068)

Description

Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.

Purpose

Used when the image fogging occurs because the scanning position is not proper when the DP is used. Execute KCFG "EESS",4, 107, 1, "#1"; command to adjust the timing of DP leading edge when the scanning position is changed.

Format	!R! KCFG "SCAN",9, #1,#2;EXIT;	
Parameter	#1	1: DP READ Starting position adjustment for scanning originals 2: BLACK LINE Scanning position for the test copy originals
	#2	#1=1: Adjustable range: -33 to 33 (in 0.086mm increment) (0: default) #1=2: Adjustable range: 0 to 3 (in 0.22mm increment) (0: default)

Example: DP READ set to 15, BLACK LINE set to 3

!R! KCFG "SCAN",9,1,15; KCFG "SCAN",9,2,3;EXIT;

Adjusting the DP magnification (alternative command for the maintenance mode U070)

Description

Adjusts the DP original scanning speed.

Purpose


Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.

Format	!R! KCFG "SCAN",4, #1;#2;EXIT;	
Parameter	#1	2: CONVEYING SPEED Magnification in the auxiliary scanning direction
	#2	Adjustable range: --25 to 25 (in 0.1% increment) (0: default)


Example: DP scanning magnification set to 20 to increase 2%

!R! KCFG "SCAN",4,2,20;EXIT;


Leading edge registration



Original



Copy
example 1



Copy
example 2

Adjusting the DP scanning timing (alternative command for the maintenance mode U071)

Description

Adjusts the DP original scanning timing.

Purpose


Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.

Format	!R! KCFG "SCAN",2,#1,#2;EXIT;	
Parameter	#1	1: FRONT HEAD Leading edge registration (first page) 2: FRONT TAIL Trailing edge registration (first page) 3: BACK HEAD Leading edge registration (second page) 4: BACK TAIL Trailing edge registration (second page) 5: ROTATE Leading edge registration (rotate scan)
	#2	#1=1: Adjustable range: -32 to 32 (in 0.196mm increment) (0: default) #1=2: Adjustable range: -32 to 32 (in 0.196mm increment) (0: default) #1=3: Adjustable range: -45 to 45 (in 0.196mm increment) (0: default) #1=4: Adjustable range: -45 to 45 (in 0.196mm increment) (0: default) #1=5: Adjustable range: -128 to 128 (in 0.196mm increment) (0: default)


Example: FRONT HEAD set to 10, FRONT TAIL set to 15, BACK HEAD set to 10, BACK TAIL 15

!R! KCFG "SCAN",2,1,10; KCFG "SCAN",2,2,15; KCFG "SCAN",2,3,10; KCFG "SCAN",2,4,15;EXIT;


Leading edge registration



Original




Copy
example 1



Copy
example 2

Trailing edge registration



Original



Copy
example 1



Copy
example 2

Adjusting the DP center line (alternative command for the maintenance mode U072)

Description

Adjusts the scanning center line for the DP original.

Purpose


Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.

Format	!R! KCFG "SCAN",3, #1,#2;EXIT;	
Parameter	#1	1: FRONT Center line (first page) 2: BACK Center line (second page) 3: ROTATE Center line (rotated scan)
	#2	Setting range: -39 to 39 (in 0.086mm increment) (initial: 0)


Example: FRONT set to 15, BACK set to 3

!R! KCFG "SCAN",3,1,15; KCFG "SCAN",3,2,3;EXIT;


DP center line



Original








Copy
example 1




Copy
example 2

INSTALLATION GUIDE FOR Card Authentication Kit(C)


CARD READER HOLDER (C)



6



7



8

- (ENG) Refer to the Card Authentication Kit (B) Operation Guide on the bundled Product Library DVD for descriptions of the Card Authentication Kit options and the procedures for using them.
- (ES) Consulte la Card Authentication Kit (B) Operation Guide, disponible en el Product Library DVD suministrado, para obtener descripciones de las opciones de Card Authentication Kit y los procedimientos de uso.
- (FR) Se reporter au Card Authentication Kit (B) Operation Guide sur le Product Library DVD fourni pour les descriptions des options de Card Authentication Kit et leurs procédures d'utilisation.
- (DE) Siehe auch in Card Authentication Kit (B) Operation Guide auf der Product Library DVD für Erklärungen der Card Authentication Kit Optionen und den Gebrauch.
- (IT) Vedere Card Authentication Kit (B) Operation Guide sul Product Library DVD fornito per la descrizione delle opzioni Card Authentication Kit e le procedure di utilizzo del kit.
- (CN) 有关 Card Authentication Kit 选项的说明以及使用该选项的步骤，请参阅附带的 Product Library DVD 上的 Card Authentication Kit (B) 操作手册。
- (TW) 有關 Card Authentication Kit 選項和使用它們的步驟的說明，請參閱附帶的 Product Library DVD 上的 Card Authentication Kit (B) 操作手冊。
- (KO) Card Authentication Kit 옵션과 사용 과정에 관한 설명은 함께 제공된 Product Library DVD 에 있는 Card Authentication Kit (B) 조작 설 명서를 참조하시기 바랍니다 .
- (JP) ICカード認証キットで設定できる内容や操作方法については、付属のProduct Library DVD に収録されているICカード認証キット（B）使用説明書を参照してください。

KYOCERA MITA EUROPE B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 0BS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Sint-Martinusweg 199-201, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Espace Technologique de St Aubin
Route de l' Orme
91195 Gif-sur-Yvette CEDEX, France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.44.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvet 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351.21.843.6780

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
49 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA Asia Limited

16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories, Hong Kong
Phone: (852)-2610-2181

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

©2011 KYOCERA MITA Corporation

 is a trademark of Kyocera Corporation

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

30-30 47th Avenue
Long Island City, NY 11101
TEL : (718) 289-2500
FAX : (718) 289-2501

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

3100 Breckinridge Blvd. NW Building 100,
Suite 105 Duluth, Georgia 30096
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804

KYOCERA MITA Brazil Ltda.

Av. Tambore, 1180 Mob.B-09 CEP 06460-000
Tambore-Barveri-SP,
Brazil
TEL : (55) 11-4195-8496
FAX : (55) 11-4195-6167

KYOCERA MITA Asia Limited

16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories, Hong Kong
Phone: (852)-2610-2181

KYOCERA MITA (Thailand) Corp., Ltd.
335 Ratchadapisek Road, Bangsue,
Bangkok, 10800, Thailand
Phone: (66)-2-586-0333

KYOCERA MITA Singapore Pte Ltd.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: (65)-6741-8733

KYOCERA MITA Hong Kong Limited
16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: (852)-2429-7422

KYOCERA MITA Taiwan Corporation
6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: (886)-2-2507-6709

KYOCERA MITA Korea Co., Ltd.
18F, Kangnam bldg, 1321-1,
Seocho-Dong, Seocho-Gu, Seoul, Korea
Phone: (822)-6933-4050

KYOCERA MITA India Private Limited
First Floor, ORCHID CENTRE
Sector-53, Golf Course Road, Gurgaon 122
002, India
Phone: (91)-0124-4671000